# AMS LCT Software Operation Guide

Class: User Guide

Product Name: AMS LCT
Product Version: 4.4.9.0

Doc. No.: BCD3-TM-E-210502

Doc. Version: 1.1.6

Publish Date: 2007-Oct-12

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. PRODUCT AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL PRODUCT OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF PRODUCT OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

AMSLCT

Software Operation Guide Text Part Number: 2105-0200

## **Table of Contents**

Chapter 1 Preface	1
Purpose	1
Organization	
Conventions	
2	
Revision History	2
<b>Chapter 2 DAS4 Series Management System</b>	em Overview5
AMS LCT Overview	
AMS LCT Features	
System Hardware and Software Requirement	
Chapter 3 Getting Started AMS LCT	
Installing the AMS LCTStarting a AMS LCT Session	
Navigating of AMS LCT	
Keyboard Commands	
Right Mouse Button	
AMS LCT Window Overview	10
Managing the Trap Log View	
Icons and LED Sign Overview	12
Error Handling DialogData Exporting and Graphic Displaying	
Chapter 4 Initiating the NE	17
Constructing the NE Objects	17
NE SNMP Management	
Configuring the SNMP Trap Manager	
Configuring the SNMP Community	
User Account Management  Secured Host Management	
NE Date and Time Management	
DNS Server Setting	
Time Server Setting	
Saving the NE Configuration	32
Chapter 5 Profile Management	33
Configuring the xDSL Profile	
ADSL Profile	
SHDSL Profile	
Configuring the VLAN Profile	
IP Traffic Profile	
TV Channel Profile  Multicast Service Profile	
Configuring the Alarm Definition Profile	
Chapter 6 Interface Port Management	
xDSL Line Interface Management	
GE Network Interface Management	
Link Aggregation (Static / Dynamic) RSTP Configuration	
CoS Configuration	
Manual VLAN Setting	
Chapter 7 Connection Port Management	
VC-to-VLAN Connection Management	71 77

	Access Control List	
	NetBIOS/NetBEUI Packet Filtering	
	Source MAC Access Control List	
	Multicast Channel Configuration	
	IGMP snooping/IGMP proxy Configuration	
	System Services Configuration	85
	MAC Aging for Bridged Services	
	VLAN MAC Limit	
	DHCP Service Configuration PPPoE Sub-option Configuration	
	xDSL Port Agent ID Management	
Chap	oter 8 Fast Provision Management	93
	Interface and VC-VLAN Fast Provisioning	93
	Multicast Service Fast Provisioning	101
<u>Chap</u>	oter 9 Performance Management	1 <u>05</u>
	xDSL Line Current Performance Information	105
	xDSL Line Historical Performance Information	
	GE Interface Performance Statistics	110
<u>Chap</u>	oter 10 Fault Management	<u>113</u>
	NE Alarm Information	113
	System Alarm Management	
	Alarm Synchronization	
	Relay Input ManagementHardware Status Monitoring	
Chan	<u> </u>	
Gnap	oter 11 Diagnosis Management	
	xDSL Line Status DiagnosisPort Rate Status	
	Bits Allocation Monitoring	
	Loop Monitoring	
	Loop Diagnosis (DELT < Dual-Ended Line Test>)	128
	Loop SELT Test (Single End Loop Test)	131
	xDSL Service Status Diagnosis	
	Bridge Filtering Database	132
	VLAN MembershipxDSL MAC Spoofing Status	13 <del>4</del>
	Multicast Channel Status	
	Multicast Group Membership	
	xDSL Downstream Broadcast Forwarding VLANs	139
	Trunk Current Status Diagnosis	
	LACP Diagnosis	
	RSTP Diagnosis	
	UGE VLAN List	
	Network Diagnosis Ping NE	
	Traceroute	
	Telnet	
	Check SNMP Connection	149
<u>Chap</u>	oter 12 General System Management	151
	AMS LCT Options	
	Configuring the Alarm Warning Options	151
<u>Chap</u>	oter 13 Administrating and Maintenance	1 <u>5</u> 3
	NE Inventory Information	153

NE Firmware Upgrade	.154
SHDSL LC Firmware Upgrade	
NE Boot Partition	
Reset the Unit	.158

IV Chapter of Contents

This page is leave in blank for note or memo use

List of Figures

# **List of Figures**

Figure 3-1 AMS LCT Login Dialog	9
Figure 3-2 AMS LCT Operation Window	10
Figure 3-3 AMS LCT Trap Log View	11
Figure 3-4 Detailed Alarm & Event Dialog	11
Figure 3-5 Trap Log Filter Dialog	12
Figure 3-6 Error Handling Message	14
Figure 3-7 Export Dialog	15
Figure 3-8 2D/3D Data Graph Displaying Dialog	16
Figure 4-9 Board Setting List Dialog	18
Figure 4-10 xDSL Board Setting Dialog	20
Figure 4-11 NC Boarding Setting Dialog	20
Figure 4-12 NE SNMP Manager IP Address List Dialog	23
Figure 4-13 Add NE SNMP Manager IP Address Dialog	24
Figure 4-14 NE SNMP Community List Dialog	25
Figure 4-15 Add NE SNMP Community Dialog	26
Figure 4-16 NE User Account List Dialog	26
Figure 4-17 NE User Account Setting Dialog	27
Figure 4-18 NE Secured Host List Dialog	28
Figure 4-19 NE Secured Host Setting Dialog	29
Figure 4-20 NE System Time Dialog	29
Figure 4-21 DNS Server Setting Dialog	30
Figure 4-22 NE Time Server Status Dialog	31
Figure 4-23 NE Time Server Setting Dialog	32
Figure 4-24 NE Write Flash Confirm Dialog	32
Figure 5-25 Interrelationship of Data Transport Related Profiles	33
Figure 5-26 xDSL Profile List Dialog Function Button	35
Figure 5-27 ADSL Profile List – Line Dialog	36
Figure 5-28 Add ADSL Line Profile- Transmission Rate Dialog	37
Figure 5-29 Add ADSL Line Profile- SNR Margin Dialog	38
Figure 5-30 Add ADSL Line Profile- PSD Dialog	40
Figure 5-31 Add ADSL Line Profile Power Management Dialog	41

II List of Figures

Figure 5-32 Add ADSL Line Profile- INP Dialog	42
Figure 5-33 xDSL Profile List- PM Threshold Dialog	43
Figure 5-34 Add ADSL PM Threshold Profile Dialog	43
Figure 5-35 xDSL Profile List– Traffic Policing Dialog	44
Figure 5-36 Add Traffic Policing Profile Dialog	45
Figure 5-37 SHDSL Profile List- Line Dialog	46
Figure 5-38 Add SHDSL Line Profile- Transmission Rate Dialog	46
Figure 5-39 Add SHDSL Line Profile- SNR Margin Dialog	47
Figure 5-40 Add SHDSL Line Profile- Miscellaneous Dialog	48
Figure 5-41 SHDSL Profile List- PM Threshold Dialog	49
Figure 5-42 Add SHDSL PM Threshold Profile Dialog	49
Figure 5-43 VLAN Profile List- IP Traffic Dialog	51
Figure 5-44 Add xDSL IP Traffic Profile Dialog	51
Figure 5-45 VLAN Profile List- TV Channel Dialog	52
Figure 5-46 Add xDSL TV Channel Profile Dialog	53
Figure 5-47 VLAN Profile List- Multicast Service Dialog	54
Figure 5-48 Add xDSL Multicast Service Profile Dialog	54
Figure 5-49 Alarm Definition List Dialog	55
Figure 5-50 Modify Alarm Definition Dialog	56
Figure 6-51 ADSL Port List Dialog	57
Figure 6-52 ADSL Port Modification Dialog	58
Figure 6-53 SHDSL Port Modification Dialog	59
Figure 6-54 Trunk Port Dialog	60
Figure 6-55 Trunk Port Configuration Dialog	61
Figure 6-56 GE Network Interface Packet Forward Illustrate	62
Figure 6-57 Link Aggregation Setting Dialog	62
Figure 6-58 Trunk RSTP Setting- Bridge Dialog	64
Figure 6-59 Trunk RSTP Setting- Port GE1/Port GE2 Dialog	65
Figure 6-60 DiffServ Field	67
Figure 6-61 Trunk CoS Mapping and DSCP Re-mapping Dialog	69
Figure 6-62 Manual VLAN Setting Dialog	70
Figure 7-63 VC-to-VLAN Mapping Illustrate	71
Figure 7-64 xDSL VC-to-VLAN List Dialog	72

Chapter of Contents III

Figure 7-65 xDSL VC-to-VLAN Setting – IP Traffic Dialog72
Figure 7-66 xDSL VC-to-VLAN Setting – 802.1Q/1P Dialog (only for the RFC2684 bridged mode)73
Figure 7-67 xDSL VC-to-VLAN Setting – 802.1P Dialog (only for the RFC2684 routed mode)73
Figure 7-68 xDSL VC-to-VLAN Setting – MAC Limit Dialog (only for the RFC2684 bridged mode)74
Figure 7-69 xDSL VC-to-VLAN Setting – Next-hop Dialog (only for the RFC2684 routed mode)74
Figure 7-70 xDSL VC-to-VLAN Setting – Service Type Dialog75
Figure 7-71 RFC 2684 Route Mode Connection Method77
Figure 7-72 xDSL Next-hop List for IPoA Dialog78
Figure 7-73 Add xDSL Next-hop for IPoA Dialog78
Figure 7-74 Packet Filtering Dialog79
Figure 7-75 VC-to-VLAN Access Control List dialog80
Figure 7-76 Add xDSL Access Control Dialog80
Figure 7-77 xDSL Access Control List81
Figure 7-78 xDSL Multicast Channel List Dialog83
Figure 7-79 xDSL Multicast Channel Setting Dialog83
Figure 7-80 IGMP Snooping / IGMP Proxy Setting Dialog84
Figure 7-81 MAC Aging Setting Dialog85
Figure 7-82 VLAN MAC Limit List Dialog86
Figure 7-83 VLAN MAC Limit Configure Dialog87
Figure 7-84 DHCP Setting Dialog88
Figure 7-85 DHCP Server List for DHCP Relay Dialog89
Figure 7-86 DHCP Broadcast Control Dialog89
Figure 7-87 PPPoE Sub-option Setting Dialog90
Figure 7-88 xDSL Port Agent ID List91
Figure 8-89 xDSL Port & VC-to-VLAN Fast Provision – Port Setting Dialog 94
Figure 8-90 xDSL Port & VC-to-VLAN Fast Provision – Channel Setting Dialog 94
Figure 8-91 xDSL Port & VC-to-VLAN Fast Provision – IP Traffic Dialog 95
Figure 8-92 xDSL Port & VC-to-VLAN Fast Provision – MAC Limit

IV List of Figures

Dialog (only for the RFC2684 bridged mode)	95
Figure 8-93 xDSL Port & VC-to-VLAN Fast Provision – Next-hop D (only for the RFC2684 routed mode)	ialog 96
Figure 8-94 xDSL Port & VC-to-VLAN Fast Provision – 802.1P Dial	og96
Figure 8-95 xDSL Port & VC-to-VLAN Fast Provision – Service Typ Dialog 97	Эе
Figure 8-96 xDSL Fast Provision List Dialog	100
Figure 8-97 xDSL Multicast Channel Fast Provision – Multicast Service Profile Dialog	102
Figure 8-98 xDSL Multicast Channel Fast Provision – Channel Lin Dialog 102	nit
Figure 8-99 xDSL Multicast Channel Fast Provision List Dialog	103
Figure 9-100 xDSL Current PM Port Selection	105
Figure 9-101 ADSL Current PM Dialog	105
Figure 9-102 SHDSL Current PM Dialog	107
Figure 9-103 xDSL History Port Selection Dialog	108
Figure 9-104 ADSL History PM Dialog	108
Figure 9-105 SHDSL History PM Dialog	110
Figure 9-106 Trunk PM Statistics Dialog	111
Figure 10-107 Active Alarm & Event List Dialog	113
Figure 10-108 Detailed Alarm & Event Dialog	115
Figure 10-109 Completed Alarm Sync Dialog	116
Figure 10-110 NE Relay Input List Dialog	
Figure 10-111 NE Relay Input Modification Dialog	117
Figure 10-112 Hardware Monitoring List Dialog	118
Figure 10-113 Hardware Monitoring Threshold Setting Dialog	119
Figure 11-114 xDSL Port Selection Dialog	121
Figure 11-115 ADSL Port Rate Status Dialog	122
Figure 11-116 ADSL Bit Allocation Status Dialog	124
Figure 11-117 Graph of Bit Allocation	125
Figure 11-118 ADSL Loop Monitoring Dialog	126
Figure 11-119 Graph of Loop Monitoring – Magnitude	127
Figure 11-120 Graph of Loop Monitoring – Quiet Line Noise PSD	127
Figure 11-121 ADSL Loop Diagnosis Dialog	128

Figure 11-122 Graph of DELT result – Magnitude	130
Figure 11-123 Graph of DELT result – Quiet Line PSD	130
Figure 11-124 Graph of DELT result – SNR	131
Figure 11-125 ADSL Loop SELT Test	131
Figure 11-126 Bridge Filtering Database Entry List Dialog	133
Figure 11-127 VLAN Membership List Dialog	134
Figure 11-128 MAC Spoofing Status List Dialog	135
Figure 11-129 Multicast Channel Status List Dialog	137
Figure 11-130 Multicast Group Membership List Dialog	138
Figure 11-131 xDSL Forwarding Broadcast VLANs List	139
Figure 11-132 Current Status of Link Aggregation Dialog	140
Figure 11-133 Current Status of Rapid Spanning Tree Protocol – Bridge Dialog	142
Figure 11-134 Current Status of Rapid Spanning Tree Protocol –I GE1/Port GE2 Dialog	
Figure 11-135 Ping NE from Client Dialog	145
Figure 11-136 Tracer Route NE from Client Dialog	147
Figure 11-137 Telnet Pop-up Window	148
Figure 11-137 Telnet Pop-up WindowFigure 11-138 Check NE SNMP Connection Dialog	
•	149
Figure 11-138 Check NE SNMP Connection Dialog	149 151
Figure 11-138 Check NE SNMP Connection Dialog Figure 12-139 Client Options Dialog – Alarm Warning	149 151 153
Figure 11-138 Check NE SNMP Connection Dialog Figure 12-139 Client Options Dialog – Alarm Warning Figure 13-140 Inventory Information List	149 151 153 og .154
Figure 11-138 Check NE SNMP Connection Dialog  Figure 12-139 Client Options Dialog – Alarm Warning  Figure 13-140 Inventory Information List  Figure 13-141 NE Configuration Backup & Restore File List Dialo	149 151 153 og .154 155
Figure 11-138 Check NE SNMP Connection Dialog  Figure 12-139 Client Options Dialog – Alarm Warning  Figure 13-140 Inventory Information List  Figure 13-141 NE Configuration Backup & Restore File List Dialo  Figure 13-142 NE Firmware Upgrade Dialog	149 151 153 og .154 155

VI List of Figures

This page is leave in blank for note or memo use

List of Tables

### **List of Tables**

### **Chapter 1Preface**

This preface describes the "AMS LCT Software Operation Guide" about how it is organized, and its document conventions. It contains the following topics.

- Purpose
- Organization
- Conventions
- Revision History

#### **Purpose**

The purpose of this guide is to provide detailed information and description of AMS (Advanced Management System) LCT(Local Craft Terminal) software, despite the variation in experience of the technicians. This document is intended to help them to operate the software and connect the D-Link DAS4 Series IP-DSLAM to the network as quickly as possible.

#### Organization

This guide contains the following chapters:

- Preface
- DAS4 Series Management System Overview
- Getting Started AMS
- Initiating the NE
- Profile Management
- Interface Port Management
- Connection Port Management
- Fast Provision Management
- Performance Management
- Fault Management
- Diagnosis Management
- General System Management
- Administrating and Maintenance
- Abbreviations and Acronyms
- Alarm Definition

#### Conventions

This section describes the conventions used in this guide.

**NE/NEs** mentioned in this document means DAS4 Series IP-DSLAM. unless specifically indicated.

**ADSL** mentioned in this document covers ADSL, ADSL2, and ADSL2+, unless specifically indicated. The **ADSL** specified in this document complies with ITU-T Rec. G.992.1, G.992.2, G.992.3 and G.992.5.

SHDSL mentioned in this document complies with ITU-T Rec. G.991.2,

**xDSL** hereinafter is referred as both the ADSL and SHDSL, unless specifically indicated.

**CLI Ex** – The command line management with a local console or Telnet through in-band or out-of-band IP interface for CIT (Craft Interface Terminal) connection.



This sign indicates the **NOTICE**. A note contains helpful suggestions or reference relay on the topical subjects.



This sign indicates the **TIP**. Performing the information described in the paragraph will help you solve a problem. The tip information might not be troubleshooting or even an action, but could be useful information.



This sign indicates the **CAUTION**. In this situation, you might do something that could result in equipment damage or loss of data.



This sign indicates the DANGER. You are in situation that could cause bodily injury. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.

#### **Revision History**

1) Revision Date: 2007/5/18 Release version:1.1.3 Author: Julia Shen Summary of Change(s):

- (1) "Figure 3-1 AMS LCT Login Dialog" is changed due to typo-error.
- (2) "Figure 3-7 Export Dialog" and its corresponding Table 3-2 are changed due to typoerror
- (3) "Figure 4-20 NE System Time" and its corresponding Table 4-15 are changed to add parameter "*unit:hour*" in Time Zone
- (4) "Figure 4-22 NE Time Server Status Dialog" and its corresponding Table 4-17 are changed due to typo-error.
- (5) "Figure 5-36 Add Traffic Policing Profile Dialog" and its corresponding Table 5-27 are changed to remove the parameter "*PIR*".
- (6) "Figure 8-89 xDSL Port & VC-to-VLAN Fast Provision Port Setting Dialog" and its corresponding Table 8-66 are changed to remove the parameter "wireless function".
- (7) "Figure 6-57 Link Aggregation Setting Dialog" and its corresponding Table 6-42 are changed due to typo-error.
- (8) "Figure 6-58 Trunk RSTP Setting–Bridge Dialog" and its corresponding Table 6-43 are changed due to typo-error.
- (9) "Table 7-56 xDSL Multicast Channel Setting Description" is changed to improve the readability.
- (10) "Table 8-68 xDSL Multicast Channel Fast Provision Description" is changed to improve the readability.
- (11) "Table 8-69 xDSL Multicast Channel Fast Provision List Dialog Description" is changed to improve the readability.
- (12) "Table 10-77 NE Relay Input List Dialog Description" and its corresponding are changed due to typo-error.

(13) "Table 10-79 Hardware Monitoring List Dialog Description" and its corresponding are changed due to typo-error.

- (14) "Figure 11-128 MAC Spoofing Status List Dialog" and its corresponding are changed due to typo-error.
- (15)"Figure 11-130 Multicast Group Membership List Dialog" and its corresponding are changed due to typo-error.
- (16) The titles of Figure 11-132 and Table 11-91 are changed to improve the readability.
- (17) "Figure 11-133 Current Status of Rapid Spanning Tree Protocol Bridge Dialog" and its corresponding Table 11-92 are changed due to typo-error.
- (18) "Figure 13-143 NE SHDSL Firmware Upgrade Dialog" and its corresponding are changed due to typo-error.
- 2) Revision Date: 2007/5/28

Release version: 1.1.3 Author: Julia Shen Summary of Change(s):

- (1) "Figure 6-52 ADSL Port Modification Dialog" and Table 6-38 are changed to improve the readability.
- (2) "Figure 6-53 SHDSL Port Modification Dialog" and Table 6-39 are changed to improve the readability.
- (3) "Figure 10-111 NE Relay Input Modification Dialog" and Table 10-78 are changed to improve the readability.
- 3) Revision Date: 2007/7/16

Release version: 1.1.4 Author: William Fu Summary of Change(s):

- (1) Replace Appendix C "index" with "Quick Configuration Guide for LCT"
- 4) Revision Date: 2007/10/01

Release version: 1.1.5 Author: William Fu Summary of Change(s):

(1) Add descriptions of 802.1Q tagged mode in Section "Constructing the NE Objects" and modify/add the following tables. (CWFu)

Table 4-4 Board Setting List Description

Table 4-5 Board Setting Dialog Description

Table 4-6 The NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.

- (2) Add sub-section "Manual VLAN Setting" to describe the manual VLAN setting for when the 2<sup>nd</sup> GE port is enabled to work as a subtended port in Section "GE Network Interface Management"
- 5) Revision Date: 2007/10/12

Release version: 1.1.6 Author: Julia Shen Summary of Change(s):

- (1) "Figure 4-16 NE User Account List Dialog" is changed to improve the readability.
- (2) "Figure 5-32 ADSL Line Profile– INP Dialog" is changed due to typo-error.

(3) "Figure 7-81MAC Aging Setting Dialog" and its corresponding Table 7-58 are changed to remove the parameter "*Admin Sratus*". And move "MAC Aging" menu item from "xDSL" to "NE Management".

- (4) "Figure 7-82 VLAN MAC Limit List Dialog" is changed to add the option that shows LC's information and its corresponding Table 7-59 is changed to add the parameter "Rsfresh".
- (5) "Table 5-35" is changed to improve the readability.
- (6) Change the name of "ISP server" to "Next-hop" and change the following table and figures.

Figure 7-65 xDSL VC-to-VLAN Setting – IP Traffic Dialog-(b).

Figure 7-67 xDSL VC-to-VLAN Setting – 802.1P Dialog (only for the RFC2684 routed mode).

Figure 7-69 xDSL VC-to-VLAN Setting – Next-hop Dialog (only for the RFC2684 routed mode).

Figure 7-70 xDSL VC-to-VLAN Setting – Service Type Dialog-(d).

Table 7-49 xDSL VC-to-VLAN Setting Description.

Figure 8-90 xDSL Port & VC-to-VLAN Fast Provision – Channel Setting Dialog-(b)

Figure 8-93 xDSL Port & VC-to-VLAN Fast Provision – Next-hop Dialog (only for the RFC2684 routed mode)

Figure 8-95 xDSL Port & VC-to-VLAN Fast Provision – Service Type Dialog-(d)

Table 8-66 xDSL Port & VC-to-VLAN Fast Provision Description

Figure 8-96 xDSL Fast Provision List Dialog

Table 8-67 xDSL Fast Provision List Dialog Description

- (7) "Figure 8-95-(a), (b), (c)" are changed to improve the readability.
- (8) Change the name of "Mac Limit" to "Channel Limit" and change the following table and figures.

Figure 7-79 xDSL Multicast Channel Setting Dialog

Table 7-56 xDSL Multicast Channel Setting Description

Figure 8-97 xDSL Multicast Channel Fast Provision – Multicast Service Profile Dialog

Figure 8-98 xDSL Multicast Channel Fast Provision – Channel Limit Dialog Table 8-68 xDSL Multicast Channel Fast Provision Description

(9) Change the name of "Stream Count" to "Channel Limit" and change the following table and figures.

Figure 7-79 xDSL Multicast Channel Setting Dialog

Table 7-56 xDSL Multicast Channel Setting Description

Figure 8-98 xDSL Multicast Channel Fast Provision – Channel Limit Dialog

Table 8-68 xDSL Multicast Channel Fast Provision Description

Figure 8-99 xDSL Multicast Channel Fast Provision List Dialog

Table 8-69 xDSL Multicast Channel Fast Provision List Dialog Description

### **Chapter 2DAS4 Series Management System Overview**

This chapter describes the AMS LCT user interface. This chapter contains the following sections:

- AMS LCT Overview
- AMS LCT Feature
- System Hardware and Software Requirement

#### **AMS LCT Overview**

AMS LCT is designed according to the following principles:

- Monitor and configure the network in real-time such as diagnostics, status gathering, service provision and NE reset
- Easy to maintain. The AMS LCT is designed on the PC platform and is compatible to Microsoft Windows 98SE/ME/2000/XP
- Easy to operate. The AMS LCT provides user-friendly configuration interface
- Various alarm severity levels are provided for all possible events/conditions

#### **AMS LCT Features**

The AMS LCT system supports various functions for the effective operation and maintenance of the NE. The system supports, fault management (FM), performance management (PM), configuration management (CM), and security management (SM) of DAS4 Series IP-DSLAM.

#### **Real-time System Status Monitoring**

The AMS LCT collects the SNMP traps for the discrete alarm, faceplate LEDs, and system failures in real time for monitoring and displays of the xDSL and network interfaces, and Fan, Power, and Alarm relay status.

The NE indicated with colors for different status by GUI interface. Any addition and deletion of element or plug-in unit of NE will automatically detect and reflected in AMS LCT.

#### Administration

Administrative function allows operator to plan or manage their NEs on the network.

#### **Error Handling**

When execution is not successful, error message will be displayed, and the operator has to configure problem entries and the process before proceeding further.

AMS LCT support function to depict the failure status of the NE in registered manage network.

### System Hardware and Software Requirement

AMS LCT is designed on a high stability and reliability platform, for performing fluent in management. The AMS LCT recommends the hardware/software in list below to achieve the performance.

#### The recommend hardware & OS for AMS LCT:

- Pentium 4 1.6 GHz or higher
- 256 MB RAM
- 40 GB Hard disk
- 10/100 Base-T Ethernet network card

The Software require for AMS LCT System:

- Operating System Microsoft Windows 98SE/ME/2000/XP (2000 is recommend)
- AMS Installation Package

### **Chapter 3Getting Started AMS LCT**

This chapter describes on how to install the AMS LCT, and provides the general navigating concept of AMS LCT to help you to quickly handle it.

This chapter contains the following sections:

- Installing the AMS LCT
- Starting AMS LCT Session
- Navigating in AMS Client
- Managing the Trap Log View
- Icon and LED Sign Overview
- Error Handling Dialog
- Data Exporting and Graphic Displaying


#### Installing the AMS LCT

Before installing the AMS LCT software, please make sure both of your requirement of hardware and software are completed with recommend specification list in "Chapter 2 System Hardware and Software Requirement".

Insert the 'AMS Installation Package' CD to your CD/DVD driver, from the directory of 'AMS\_LCT' double click on the 'AMS\_GUI\_LCT\_setupVx.x.x.x' executable file.




**Step 2** Select 'Yes' from the launched window to continuous the installation.




**Step 3** Click the 'Next' button to start the setup wizard.



**Step 4** Identify the program directory and additional task before processing installation.



Step 5 Once the installation is completed, you will have an 'AMS Client' icon on your desktop; double click this icon to run the AMS Client software.





### Starting a AMS LCT Session

Double click the 'AMS Client' icon on your desktop to launch the AMS LCT login dialog.

Use default user and community to access with read-write privilege.

User: admin

Community: netman

For default read-only privilege using:

User: guest

Community: public


You can change the login account and privilege from CLI Ex mode or later from AMS LCT.

To start an AMS LCT session, follow these steps.

Step 1 Open AMS LCT session by double clicking the 'AMS Client' icon on the MS-Windows.

The Login window appears.

#### Figure 3-1 AMS LCT Login Dialog



- **Step 2** Specify NE IP address and enter the associated user name and SNMP community.
- Step 3 Click Login to proceed.

If you enter an unknown user name or invalid community, the system will display an error message. To continue, click **OK**, and then enter a valid user name and SNMP community.

When you enter a valid user name and SNMP community, the session starts and the AMS LCT application appears.



Both the user name and SNMP community are case-sensitive.



If you don't have any account creates initially or you have trouble to login, please refer to DAS4 Series System Configuration Guide "Chapter 2 Managing the Session Login Account" to managing the user account, also refer to "Chapter 3 Configuring the SNMP Manager" to managing the SNMP community.

### **Navigating of AMS LCT**

AMS LCT software uses familiar functionality and menus found in most MS-Windows-based graphical user interface. This section describes the functions available in AMS LCT.

#### **Keyboard Commands**

Certain Keyboard commands are available in AMS LCT. These commands serve as an alternative

to mouse functionality.

<b>Keyboard Command</b>	Description
Operation	
Tab	Move among the fields in a window/dialog.
Arrow Keys	Scroll through the text in a data entry field or through the values of a list box.
Alt Key	Access a menu by typing the appropriate keyboard command.

#### **Right Mouse Button**

AMS LCT software provides right-click mouse functionality. By positioning the mouse cursor over an "NE object", you can click the right mouse button to view the launched **Function Menu**. The **Function Menu** options available depend on selected "NE object". You can then use the left or right mouse button to open the associated function dialog window.




The "NE object" denotes the NE entity, Shelf, Slot/Box, and Port displaying on the Rack tab of Multimedia View area or Network Tree View area.

#### **AMS LCT Window Overview**

The AMS LCT Operation window contains several parts; each part varies depending on the window in which you are viewing or configuring.

Figure 3-2 AMS LCT Operation Window



### Managing the Trap Log View


Click the 'Trap Log' tab view to display the system trap (alarm) information.

The NE would send SNMP traps to a designated host IP address when there is one or more status are changed. The "Trap Log" records and saves the SNMP traps on the host which is specified a trap station since the host logged in LCT.

Operator will not see the trap logs on LCT if the host IP address is not one of the trap stations.


Chapter 4 "Configuring the SNMP Trap Manager" shows you how to configure the SNMP trap station.

Figure 3-3 AMS LCT Trap Log View



Select a specific trap from **List Table** and using right mouse button to launch the **Function Menu**, select '**Detail**' to view the detailed alarm & event dialog.


Figure 3-4 Detailed Alarm & Event Dialog



You can also select the 'Pause' or 'Reset' from launched Function Menu to stop refreshing traps or clearing all traps cached in the AMS LCT.

Click the 'Filter' button at top-left corner of 'Trap Log' tab view to open the Trap Log Filter dialog. Here you can define the rule of showing filtering new coming traps. This is a useful tool to filter out unnecessary traps.

Figure 3-5 Trap Log Filter Dialog



### Icons and LED Sign Overview

Table 3-1 lists the icons and LED signs used inside the AMS LCT.

Table 3-1 Icon and LED Sign Description

Symbol	Description		
Tool Combo-box	Tool Combo-box		
-	System active alarm (current alarm).		
	System history alarm (history alarm).		
	System alarm profile (alarm definition).		
profile	System profile configuration.		
	NE management.		
1	AMS LCT Options.		
3	Exit AMS LCT.		

Table 3-1 Icon and LED Sign Description (Continued)

Status Combo-b  Int in information.  PC data and time.  PC data and t	Symbol	Description			
PC data and time.  PC data and time.  PC onnection status. ( idle, disconnected, in communication)  Network List View  NE contains critical alarm  NE contains major alarm  NE contains minor alarm  NE contains events  NE is in normal status  Network Alarm View  Critical Alarm  Major Alarm  Minor Alarm  NE offline  NE offline  NE offline  NE online  Rack View  Port disable or no such profile  Port contains retical alarm  Port contains major alarm  Port contains mor alarm  Port contains mor alarm  Port contains more darm  Port contains no alarm/Port linked  W NC card in working mode (DAS4672 only)  NC /LC card type is mismatch  NC /LC card not exist  The LC board is operated in VLAN tag Pass-through enable mode.  Trap Log View  Current Major alarm  Current Event alarm  Alarm clear / No alarm  Alarm clear / No alarm  Alarm clear / No alarm  Identify as card alarm	Status Combo-l	box			
Network List View    NE contains critical alarm   NE contains major alarm   NE contains minor alarm   NE contains minor alarm   NE contains minor alarm   NE contains minor alarm   NE contains events   NE is in normal status   Network Alarm View   Critical Alarm   Major Alarm   Major Alarm   NE offline   NE offline   NE offline   NE offline   NE offline   NE offline   Port disable or no such profile   Port contains major alarm   Port contains major alarm   Port contains minor alarm   Port contains minor alarm   Port contains minor alarm   Ne offline   Port contains warning alarm   NE offline   Port disable or no such profile   Port contains warning alarm   NE offline   Port disable or no such profile   Port contains warning alarm   NE offline   Port disable or no such profile   Port contains warning alarm   NE offline   Port disable or no such profile   Port contains warning alarm   NE offline   Port disable or no such profile   NE offline   Port disable o	•	Hint information.			
Network List View        NE contains critical alarm	<b>⊗</b>	PC data and time.			
NE contains critical alarm   NE contains major alarm   NE contains minor alarm   NE contains minor alarm   NE contains events   NE is in normal status   Network Alarm View   Critical Alarm   Major Alarm   Major Alarm   NE offline   NE offline   NE offline   NE offline   Port disable or no such profile   Port contains critical alarm   Port contains major alarm   Port contains major alarm   Port contains minor alarm   Port contains more alarm   Port contains no alarm / Port linked   NC card in working mode (DAS4672 only)   NC / LC card type is mismatch   NC / LC card not exist   The LC board is operated in VLAN tag Pass-through enable mode.   Trap Log View   Current Major alarm   Current Minor alarm   Current Event alarm   Alarm clear / No alarm   Identify as card alarm	🍑 / 🤡 / 5	Connection status. ( idle, disconnected, in communication)			
NE contains major alarm  NE contains minor alarm  NE contains events  Network Alarm View  Critical Alarm  Major Alarm  Minor Alarm  NE offline  NE off	Network List View				
NE contains minor alarm  NE is in normal status  Network Alarm View  Critical Alarm  Major Alarm  Minor Alarm  NE offline  NE online  Rack View  Port disable or no such profile Port contains critical alarm  Port contains major alarm  Port contains warning alarm  Port contains warning alarm  Port contains warning alarm  NC card in working mode (DAS4672 only)  NC / LC card type is mismatch  NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode.  Trap Log View  Current Major alarm  Current Major alarm  Current Major alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	<b>( )</b>	NE contains critical alarm			
NE is in normal status  Network Alarm View	<b>(iii)</b> / <b>(iii)</b>	NE contains major alarm			
Network Alarm View  ○ Critical Alarm ○ Major Alarm ○ Minor Alarm ○ NE offline ○ NE online  Rack View  ○ Port disable or no such profile ○ Port contains critical alarm ○ Port contains major alarm ○ Port contains minor alarm ○ Port contains moralarm ○ Port contains moralarm ○ Port contains moralarm ○ NC card in working mode (DAS4672 only) ○ NC / LC card type is mismatch	<b>(iii)</b> / <b>(iii)</b>	NE contains minor alarm			
Network Alarm View  Critical Alarm  Major Alarm  Minor Alarm  NE offline  NE online  Rack View  Port disable or no such profile  Port contains critical alarm  Port contains major alarm  Port contains major alarm  Port contains mor alarm  Port contains warning alarm  Port contains warning alarm  Port contains warning alarm  NC card in working mode (DAS4672 only)  NC / LC card type is mismatch  NC / LC card not exist  The LC board is operated in VLAN tag Pass-through enable mode.  Trap Log View  Trap Log View  Trap Log View  Current Major alarm  Current Minor alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm  Identify as card alarm  Identify as card alarm	<b>i</b> / <b>=</b>	NE contains events			
✔       Critical Alarm         ✔       Major Alarm         ✔       Minor Alarm         ✔       NE offline         ✔       NE offline         ✔       NE online         Rack View         ✔       Port disable or no such profile         ✔       Port contains critical alarm         ✔       Port contains major alarm         ✔       Port contains minor alarm         ✔       Port contains warning alarm         ✔       Port contains no alarm / Port linked         ✔       NC card in working mode (DAS4672 only)         ✔       NC / LC card type is mismatch         ✔       NC / LC card type is mismatch         ✔       NC / LC card not exist         The LC board is operated in VLAN tag Pass-through enable mode.         The LC board is operated in VC MUX mode.         Trap Log View         ✔       Current Critical alarm         ✔       Current Major alarm         ✔       Current Minor alarm         ✔       Current Event alarm         ✔       Alarm clear / No alarm         Identify as card alarm	<b>(i)</b> /	NE is in normal status			
Major Alarm Minor Alarm NE offline NE online  Rack View  Port disable or no such profile Port contains critical alarm Port contains major alarm Port contains minor alarm Port contains warning alarm Port contains no alarm / Port linked NC card in working mode (DAS4672 only) NC / LC card type is mismatch NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. Trap Log View Current Critical alarm Current Major alarm Current Minor alarm Current Minor alarm Current Minor alarm Current Minor alarm Alarm clear / No alarm Identify as card alarm	Network Alarm	ı View			
Minor Alarm  NE offline  NE online  Rack View  Port disable or no such profile  Port contains critical alarm  Port contains major alarm  Port contains maior alarm  Port contains warning alarm  Port contains warning alarm  Port contains no alarm / Port linked  NC card in working mode (DAS4672 only)  NC card in standby mode (DAS4672 only)  NC / LC card type is mismatch  NC / LC card tot exist  The LC board is operated in VLAN tag Pass-through enable mode.  Trap Log View  Current Critical alarm  Current Major alarm  Current Minor alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	<b>a</b>	Critical Alarm			
NE online  Rack View  Port disable or no such profile Port contains critical alarm Port contains major alarm Port contains minor alarm Port contains warning alarm Port contains warning alarm Port contains warning alarm Port contains warning alarm NC card in working mode (DAS4672 only) NC card in standby mode (DAS4672 only) NC / LC card type is mismatch NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. Trap Log View Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	<b>()</b>	Major Alarm			
Rack View Port disable or no such profile Port contains critical alarm Port contains major alarm Port contains minor alarm Port contains warning alarm Port contains warning alarm Port contains no alarm / Port linked NC card in working mode (DAS4672 only) NC card in standby mode (DAS4672 only) NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. The LC board is operated in VC MUX mode.  Trap Log View Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm Identify as card alarm	<u> </u>	Minor Alarm			
Rack View  Port disable or no such profile Port contains critical alarm Port contains major alarm Port contains minor alarm Port contains warning alarm Port contains warning alarm Port contains warning alarm Port contains no alarm / Port linked W NC card in working mode (DAS4672 only) NC / LC card in standby mode (DAS4672 only) NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. The LC board is operated in VC MUX mode.  Trap Log View Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	<del></del>	NE offline			
Port disable or no such profile Port contains critical alarm Port contains major alarm Port contains minor alarm Port contains minor alarm Port contains warning alarm Port contains warning alarm Port contains no alarm / Port linked W NC card in working mode (DAS4672 only) NC card in standby mode (DAS4672 only) NC / LC card type is mismatch NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. The LC board is operated in VC MUX mode.  Trap Log View Current Critical alarm Current Major alarm Current Event alarm Alarm clear / No alarm Identify as card alarm Identify as card alarm	₹	NE online			
Port contains critical alarm Port contains major alarm Port contains minor alarm Port contains warning alarm Port contains warning alarm Port contains no alarm / Port linked NC card in working mode (DAS4672 only) NC card in standby mode (DAS4672 only) NC / LC card type is mismatch NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. The LC board is operated in VC MUX mode.  Trap Log View Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	Rack View				
Port contains major alarm Port contains minor alarm Port contains warning alarm Port contains no alarm / Port linked WnC card in working mode (DAS4672 only) NC card in standby mode (DAS4672 only) NC / LC card type is mismatch NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. The LC board is operated in VC MUX mode.  Trap Log View Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	•	Port disable or no such profile			
Port contains minor alarm Port contains warning alarm Port contains no alarm / Port linked W NC card in working mode (DAS4672 only) NC / LC card in standby mode (DAS4672 only) NC / LC card type is mismatch NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. The LC board is operated in VC MUX mode.  Trap Log View Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	•	Port contains critical alarm			
Port contains warning alarm Port contains no alarm / Port linked  NC card in working mode (DAS4672 only)  NC card in standby mode (DAS4672 only)  NC / LC card type is mismatch NC / LC card type is mismatch NC / LC card not exist The LC board is operated in VLAN tag Pass-through enable mode. The LC board is operated in VC MUX mode.  Trap Log View  Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	•	Port contains major alarm			
Port contains no alarm / Port linked  W NC card in working mode (DAS4672 only)  S NC card in standby mode (DAS4672 only)  NC / LC card type is mismatch  NC / LC card not exist  The LC board is operated in VLAN tag Pass-through enable mode.  The LC board is operated in VC MUX mode.  Trap Log View  Current Critical alarm  Current Major alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	<u></u>	Port contains minor alarm			
NC card in working mode (DAS4672 only)  NC card in standby mode (DAS4672 only)  NC / LC card type is mismatch  NC / LC card type is mismatch  NC / LC card not exist  The LC board is operated in VLAN tag Pass-through enable mode.  The LC board is operated in VC MUX mode.  Trap Log View  Current Critical alarm  Current Major alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	•	Port contains warning alarm			
NC card in standby mode (DAS4672 only)  NC / LC card type is mismatch  NC / LC card not exist  The LC board is operated in VLAN tag Pass-through enable mode.  The LC board is operated in VC MUX mode.  Trap Log View  Current Critical alarm  Current Major alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	•	Port contains no alarm / Port linked			
NC / LC card type is mismatch  NC / LC card not exist  The LC board is operated in VLAN tag Pass-through enable mode.  The LC board is operated in VC MUX mode.  Trap Log View  Current Critical alarm  Current Major alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	W	NC card in working mode (DAS4672 only)			
NC / LC card type is mismatch  NC / LC card not exist  The LC board is operated in VLAN tag Pass-through enable mode.  The LC board is operated in VC MUX mode.  Trap Log View  Current Critical alarm  Current Major alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	S	NC card in standby mode (DAS4672 only)			
The LC board is operated in VLAN tag Pass-through enable mode.  Trap Log View  Current Critical alarm  Current Major alarm  Current Minor alarm  Current Event alarm  Alarm clear / No alarm  Identify as card alarm	?	NC / LC card type is mismatch			
Trap Log View  Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Identify as card alarm Identify as card alarm	×	NC / LC card not exist			
Trap Log View  Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm		The LC board is operated in VLAN tag Pass-through enable mode.			
Current Critical alarm Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm		The LC board is operated in VC MUX mode.			
Current Major alarm Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	Trap Log View	Trap Log View			
Current Minor alarm Current Event alarm Alarm clear / No alarm Identify as card alarm	<ul><li>•</li></ul>	Current Critical alarm			
Current Event alarm Alarm clear / No alarm Identify as card alarm	<b>(a)</b>	Current Major alarm			
Alarm clear / No alarm Identify as card alarm	<b>()</b>	Current Minor alarm			
Identify as card alarm	<u> </u>	Current Event alarm			
· · · · · · · · · · · · · · · · · · ·	<b>(a)</b>	Alarm clear / No alarm			
Identify as port alarm		Identify as card alarm			
	7	Identify as port alarm			

Table 3-1 Icon and LED Sign Description (Continued)


Symbol	Description					
Function Dialog						
<b>&gt;</b>	Indicates data in list table is active and valid.					
	Indicates data in list table is inactive or invalid.					
<b>\$</b>	Indicates the status of specific port in list table is link up.					
*	Indicates the status of specific port in list table is link down.					
~	Indicates the status of task is finished.					
1	Indicates the status of task is successful.					
X	Indicates the status of task is failed.					
✓	Indicates the item is checked.					
	Indicates the item is unchecked.					
A	Indicates the field is sorted by ascendant order in list table.					
▼	Indicates the field is sorted by descendant order in list table.					
D	Indicates the field is sorted by another field in list table.					

### **Error Handling Dialog**

AMS LCT provides the error handling dialog. Each dialog has a text block at button edge, this text block will shown error message and highlight the red rectangle at specifics box where contains invalid or illogical parameter. You must fix the error to proceed with the task.

The following figure depicts the example on how dialog performs the error handling.

Figure 3-6 Error Handling Message



### **Data Exporting and Graphic Displaying**

AMS LCT provides the data exporting of dialog List Table information.

Figure 3-7 Export Dialog




Table 3-2 Export Dialog Description

Field	Description
Data file	Data file location
Add the title and field names at the beginning of file	Check to add the title and field names in the front of output file.
Append data to the end of file	Check to append data to the end of output file.
Browse	Click to select the output file by way of file manager.




Figure 3-8 2D/3D Data Graph Displaying Dialog

Table 3-3 2D/3D Data Graph Displaying Dialog Description

Field	Description			
Print Chart	Click to print the chart diagram			
Save Chart	Click to save the chart diagram in file.			
Select All	Click to check all linear elements.			
Deselect All	Click to uncheck all linear elements.			
3D/2D	Click to toggle the style of chart diagram.			
Close	Exit the data graph displaying Dialog.			

### **Chapter 4Initiating the NE**

This chapter describes how to initially configure the DAS4 Series IP-DSLAMs before the advanced configuration depicted in the rest of this document.

This chapter contains the following sections:

- Constructing the NE Objects
- NE SNMP Management
- User Account Management
- Secured Host Management
- DNS Server Setting
- Time Server Setting
- NE Date and Time Management
- Saving the NE Configuration

#### **Constructing the NE Objects**

As the DAS4 Series IP-DSLAM provides the flexibility to be equipped with various card modules such as ADSL-LC (Line Card) and SHDSL-LC, constructing the NE board type of card module is the first task you need to perform.

Once the card modules to be equipped to the DAS4 Series IP-DSLAM are determined, you need to set the planned type according to their correspondent slot to secure the system operation. For any reason (removed or type error), if the planned type is not the same as the online type detected from the system, the board mismatch alarm message will be reported to AMS LCT and the configured AMS Server..

The NE supports the following functions on a per LC/NC basis.

- Planning the card type of a LC slot
   To ease the operator to plan the usage of each LC slot in advance, the NE support to
   configure the planned type of a LC slot. There will be an alarm arise if the planned card type
   and the actual plug-in card type are different.
- RFC 2684 encapsulation method for ADSL line card, either LLC or VCMUX.
- "Service Type Control" for ADSL line card.

  Operator can define the service which allow user to pass, they are "DHCP", "PPPoE" and "Static IP".
- VLAN tag pass-through function for ADSL line card
  Whenever the VLAN tag pass-through (VTP) is configured as enabled, the LC provides
  transparent transportation of the VLAN traffic from subscriber interface to network interface
  without any VLAN tag attachment. The LC will not attach any VLAN tag to the upstream
  subscriber traffic. In the mean time, the LC will also not replace the existing VLAN tag of
  the upstream subscriber traffic.
  - On the other hand, in the case that the VTP function is configured as disabled, the LC will attach a VLAN tag to all the traffic from subscriber interface to network interface.
- IEEE 802.1Q VLAN forwarding function for ADSL line card and GE ports
  The operator can set the xDSL subscriber ports as well as the GE ports to only forward
  either tagged traffic or untagged traffic.
- Step 1 From the 'Rack' tab view, point the mouse cursor on the NE object (Shelf, NC slot, or LC slot), and then right click the mouse button to launch the function menu and then click 'Board Setting on Function Menu' to open the Board Setting List Dialog, or click Diagnosis → Board Setting on Main Menu to open the Board Setting List Dialog as shown in Figure 4-9 and Table 4-4 depicts the related parameters.

Figure 4-9 Board Setting List Dialog





Table 4-4 Board Setting List Description

Field	Description				
List Table					
No.	This indicates the serial number of entry of the List Table.				
Slot	This indicates the location of board.				
Planned Type	This indicates the board type planned to be equipped to the slot of DAS4 Series IP-DSLAM. If the planned type is mismatched (removed or type error) with online type detected from the system, the board mismatch alarm message will be reported.				
Online Type	This indicates the observed board type of the card module in the slot (current type)				
AAL5 Encapsulation	This indicates the AAL5 encapsulation mode, either "LLC" or "VC-MUX"(VC Based Multiplexing) per RFC-2684.  RFC 2684 defines the encapsulation methods for transporting the routed and bridged Protocol Data Units (PDUs) across a native ATM network.				
Service Type Control	This indicates the "Service Type Control" function is enables or not.  The service type control can be enabled to provide control of PPPoE, DHCP or static IP on a per line card basis.				
Configured Tagged mode	This indicates the tagged mode is configured as either tagged or untagged mode.				
Run-Time Tagged mode	This indicates the operational status of tagged mode.  Tagged-only: LC (or NC) only forwards the tagged Ethernet frame and drops the untagged Ethernet frame.  Untagged-only: LC (or NC) only forwards the untagged Ethernet				
	frame and drops the untagged Ethernet frame.  It is noted that the value of configured Tagged mode and its Run- Time Status may be different. Please refer to Table 4-6 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.				
Configured VLAN Tag Pass Through (VTP)	This indicates the VLAN tag pass-through (VTP) is configured as enables or not. (per LC setting)  The VTP function provides transparent transportation of the VLAN traffic from subscriber interface to network interface without VLAN tag attachment, this allows subscriber deployed their own VLAN ID to associate in the network without double tag or replace the existing VLAN ID by system.				
Run-Time VLAN Tag Pass Through (VTP)	This indicates the operational status of VTP.  It is noted that the value of configured VTP and its Run-Time Status may be different. Please refer to Table 4-6 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.				
<b>Function Button</b>					
Modify	Selected the row and click 'Modify' button to perform the modification of specific item on the selected board.				
Export	Click this button to save the contents of <b>Board Setting List</b> to the Personal Computer.				
Close	Exit the <b>Board Setting List</b> Dialog.				

Step 2 To modify the slot setting, click and highlight a slot from **Board Setting List** and click 'Modify' button to launch the **Board Setting** Dialog as shown in Figure 4-10 and

Figure 4-11 for LC and NC setting, respectively. Table 3-1depicts the related parameters.

Figure 4-10 xDSL Board Setting Dialog






Figure 4-11 NC Boarding Setting Dialog




Table 4-5 Board Setting Dialog Description

Field	Description				
Board Type	Description				
Planned Type [Modify]	This specifies the board type planned to be equipped to the slot of DAS4 Series IP-DSLAM. If the planned type is mismatched (removed or type error) with online type detected from the system, the board mismatch alarm message will be reported.				
Online Type	This specifies the observed board type of the card module in the slot (current type)				
<b>Board Settings</b>					
AAL5 Encapsulation [Modify]	This specifies the AAL5 encapsulation mode, either "LLC" or "VC-MUX"(VC Based Multiplexing) per RFC-2684.  RFC 2684 defines the encapsulation methods for transporting the routed and bridged Protocol Data Units (PDUs) across an native ATM network.				
Service Type Control [Modify]	This specifies the "Service Type Control" function is enables or not.  The service type control can be enabled to provide control of PPPoE, DHCP or static IP on a per line card basis.				
Tagged mode [Modify]	This specifies the tagged mode is configured as either tagged or untagged mode.				
Run-Time Status of Tagged mode	This specifies the operational status of tagged mode.  Tagged-only: LC (or NC) only forwards the tagged Ethernet frame and drops the untagged Ethernet frame.  Untagged-only: LC (or NC) only forwards the untagged Ethernet frame and drops the untagged Ethernet frame.  It is noted that the value of configured Tagged mode and its Run-				
	Time Status may be different. Please refer to Table 4-6 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.				
VLAN Tag Pass Through (VTP)	This specifies the VLAN tag pass-through (VTP) is configured as enables or not. (per LC setting)				
[Modify]	The VTP function provides transparent transportation of the VLAN traffic from subscriber interface to network interface without VLAN tag attachment, this allows subscriber deployed their own VLAN ID to associate in the network without double tag or replace the existing VLAN ID by system.				
Run-Time Status of VTP	This specifies the operational status of VTP.  It is noted that the value of configured VTP and its Run-Time Status may be different. Please refer to Table 4-6 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.				
Function Button					
OK	Press this button to commit setting.				
Cancel	Press this button to cancel setting.				



**Board Setting** Dialog allows you to define the line card (LC) AAL5 encapsulation mode, "VLAN Tag pass-through (VTP)" mode, Tagged mode and "Service Type Control" mode. Those functions indicate as per board, configuration affects the setting of all ports of selected LC.



The ADSL LC needs to be reset to perform the expected system behavior as depicted in Table 4-6 whenever its run-time status changes.



The NC needs to be reset to perform the expected system behavior as depicted in Table 4-6 whenever its configured tagged mode changes.



Whenever the GE2 is set as subtended port and the NC is set as "tagged-only" mode, in order to make the NE forward the VLAN-specific traffic between GE1 and GE2, the operator needs to manually set GE1 and GE2 as the member ports of VLANs in interest. Please refer Section "Manual VLAN Setting" for the VLAN-member port setting of GE1 and GE2 whenever GE2 works as a subtended port.

It is noted that the run-time status of LC may be different to its corresponding configuration. In this case, the behavior of the NE is per the run-time status of NE instead of their configuration. To describe the NE behavior, the following notations are adopted in Table 4-6

- Q<sub>s</sub> represents the service VLAN-tag and its VLAN-ID value is provided by the NE.
- Q<sub>S (CPE)</sub> represents the service VLAN-tag and the notation (CPE) indicates that its VLAN-ID value is provided by the CPE (or the subscriber's PC behind the CPE).
- Q<sub>(CPE)</sub> represents the 802.1Q VLAN-tag.
- $Q_{C (CPE)}$  represents the customer VLAN-tag and the notation  $_{(CPE)}$  indicates that its VLAN-ID value is provided by the CPE (or the subscriber's PC behind the CPE).

Table 4-6 The NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.

NC	ADSL LC setting		ADSL LC Run-Time Status		Expected NE behavior			
Setting					VLAN-tagging Status of Egress Traffic		Acceptable Ingress Traffic	
Tagged mode	Tagged mode	VTP	Tagged mode	VTP	On NC	On the ADSL line	On NC	On the ADSL line
Tagged	Tagged	Enabled	Tagged	Enabled	Qs (CPE)	Q <sub>(CPE)</sub>	Tagged	Tagged
		Disabled	Tagged	Disabled	Q <sub>S</sub> +Q <sub>C (CPE)</sub>	Q <sub>(CPE)</sub>	Tagged	Tagged
	Untagged	Enabled	Untagged	Disabled	Qs	Untagged	Tagged	Untagged
		Disabled	Untagged	Disabled	Qs	Untagged	Tagged	Untagged
Untagged	Tagged	Enabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged
		Disabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged
	Untagged	Enabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged
		Disabled	Untagged	Disabled	Untagged	Untagged	Untagged	Untagged



It is noted that the NE will drop the tagged Ethernet frames of VLAN-ID not configured by the VC-to-VLAN setting (see Figure 7-66) in the following case.

NC tagged mode = Tagged

LC tagged mode Run-Time Status = Tagged

LC VTP Run-Time Status = Enabled



The tagged mode (run-time) indicates the operational status of tagged mode.

Tagged-only: LC (or NC) only forwards the tagged Ethernet frame and drops the untagged Ethernet frame.

Untagged-only: LC (or NC) only forwards the untagged Ethernet frame and drops the tagged Ethernet frame.

It is noted that the value of configured Tagged mode and its Run-Time Status may be different. Please refer to Table 4-6 for the NE behavior when configuring NC and ADSL LC with various Tagged mode and VTP parameters.

## **NE SNMP Management**

SNMP (Simple Network Management Protocol) is an application-layer protocol that facilitates the exchange of management information between a NE and LCT. SNMP enables the administrators to manage the NE by the LCT. In the term of SNMP, the NE plays the role of SNMP agent and the LCT serves as the SNMP server. This section describes how to configure the SNMP on the NE.



Beware of the SNMP community setting, this will affects the communication between the AMS LCT and NE, re-login the AMS LCT if the SNMP community has been modified.

## Configuring the SNMP Trap Manager

SNMP Trap Manager records the hosts (any SNMP server, like LCT, AMS Server, and so on) to be notified whenever the NE encounters abnormalities. When a trap condition happens to the NE, the NE sends the corresponding SNMP trap message to the hosts (SNMP server) specified in the SNMP Manager IP Address List.

Follow the subsequent procedures to configure the NE's SNMP Manager.

Step 1 Click Configuration → NE Management → SNMP Managers on Main Menu to open the NE SNMP Manager IP Address List Dialog as shown in Figure 4-12 and Table 4-7 depicts the related parameters.

Figure 4-12 NE SNMP Manager IP Address List Dialog



Table 4-7 NE SNMP Manager IP Address List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Table.
IP address	This indicates the IP address (Server / Host IP) of SNMP Manager.
Trap Community	This specifies the SNMP trap community of NE (Send Trap).
SNMP Trap Version	This specifies the Trap version.
<b>Function Button</b>	
Add	Click this button to create a new SNMP Manager (Trap) IP Address.
Delete	Select a trap community from the list table to remove.
Export	Click this button to save the contents of NE SNMP Manager IP Address List to the Personal Computer.
Close	Exit the NE SNMP Manager IP Address List Dialog.

Step 2 Click 'Add' button to create a new trap receiver host with community, while to remove the trap receiver, click and highlight a host in the list and click 'Delete' button, as shown in Figure 4-13 and Table 4-8 depicts the related parameters.

Figure 4-13 Add NE SNMP Manager IP Address Dialog




Table 4-8 Add NE SNMP Manager IP Address Dialog Description

Field	Description
IP address	This specifies the IP address (Server / Host IP) of SNMP Manager.
	Valid values: Any valid class A/B/C address
Trap Community	This specifies the SNMP trap community of NE (Send Trap).
	Valid values: String of up to 20 characters and any combination of printable characters ('A' - 'Z', 'a' - 'z', '0' - '9', '-', '_', '@').
SNMP Trap Version	This specifies the Trap version.
	Valid values: SNMP v2c

## Configuring the SNMP Community

The SNMP community is a string representing the password to access the MIB of NE with the associated privilege. The NE supports two levels of privilege (Permission) as follows.

 Read / Write / Create – Allow the SNMP server to read and write all objects in the MIB, as well as the community strings.

 Read-only – Only allow the SNMP server to read all objects in the MIB except the community strings.



The community string definitions on your AMS LCT must match at least one of those community string definitions on the NE. Otherwise, the LCT is not allowed to access the NE.

Follow the subsequent procedures to configure the NE's SNMP Community.

Step 1 Click Configuration → NE Management → SNMP Community on Main Menu to open the NE SNMP Community List Dialog as shown in Figure 4-14 and Table 4-9 depicts the related parameters.

Figure 4-14 NE SNMP Community List Dialog




Table 4-9 NE SNMP Community List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Table.
Community	This indicates the case-sensitive SNMP community name.
Permission	This indicates the permission level, either "read only" or "read & write"
<b>Function Button</b>	
Modify	Select a SNMP community to modify.
Add	Click this button to create a new SNMP community of NE.
Delete	Select a SNMP community to remove.
Export	Click this button to save the contents of <b>NE SNMP Community List</b> to the Personal Computer.
Close	Exit the <b>NE SNMP Community List</b> Dialog.

Step 2 Click 'Add' button to create a new SNMP community strings, while to remove the SNMP community strings, click and highlight a community in the list and click

'Delete' button, as shown in Figure 4-15 and Table 4-10 depicts the related parameters.

Figure 4-15 Add NE SNMP Community Dialog



Table 4-10 Add NE SNMP Community Dialog Description


Field	Description
Community Name	This indicates the case-sensitive SNMP community name.
	<b>Valid values:</b> String of up to 20 characters and any combination of printable characters ('A' - 'Z', 'a' - 'z', '0' - '9', '-', '_', '@').
Permission	This indicates the permission level.
	Valid values: read-only, read/write/create

## **User Account Management**

Follow the subsequent procedures to configure the user account of the NE.

Step 1 Click Configuration → NE Management → NE User Account on Main Menu to open the NE User Account List Dialog as shown in Figure 4-16 and Table 4-11 depicts the related parameters.

Figure 4-16 NE User Account List Dialog



Step 2 Click 'Add' button to create a new user account, while to remove the user account, click and highlight a user name in the list and click 'Delete' button, as shown in Figure 4-17 and Table 4-12 depicts the related parameters.

Table 4-11 NE User Account List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Table.
User Name	This indicates the user account name.
Role	This indicates the permission right of user group.
<b>Function Button</b>	
Modify	Select a user name from the list table to modify.
Add	Click this button to create a new user of NE.
Delete	Select a user from the list table to remove.
Export	Click this button to save the contents of <b>NE User Account List</b> to the Personal Computer.
Close	Exit the NE User Account List Dialog.

Figure 4-17 NE User Account Setting Dialog



Table 4-12 NE User Account Setting Dialog Description

Field	Description
User Name	This indicates the user account name.
	Valid values: String of up to 20 characters and any combination of printable characters ('A' - 'Z', 'a' - 'z', '0' - '9', '-', '_', '@').
Password	This specifies the password.
Verification	This verifies the password again.
Role	This indicates the permission right of user group.
	Administrator – Owns privilege of Read/Write
	Guest – Owns only Read privilege

# **Secured Host Management**

Follow the subsequent procedures to configure the secured (trusted) hosts allowed to access the NE.

Step 1 Click Configuration → NE Management → Secured Hosts on Main Menu to open the NE Secured Host List Dialog as shown in Figure 4-18 and Table 4-13 depicts the related parameters.

Figure 4-18 NE Secured Host List Dialog





Table 4-13 NE Secured Host List Dialog Description

Field	Description
Secured Host Administrative State	
Administrative State	This indicates the state of NE secured host function. In case of enabled state, only the hosts of configured IP addresses are allowed to access the NE via the configured 'Authorized Services'.
List Table	
Index	This indicates the number of List Table.
From IP Address	This indicates the beginning of the IP address range of the secured hosts.
To IP Address	This indicates the end of the IP address range of the secured hosts.
Authorized Services	This indicates the services (any combination of SNMP, TELNET, FTP and TFTP) the specified secured hosts are allowed.
Function Button	
Change State	Click this button to enable or disable the secured host function.
Modify	Click this button to modify the specified secured host list.
Export	Click this button to save the contents of <b>NE Secured Host List</b> to the Personal Computer.
Close	Exit the NE Secured Host List Dialog.

Step 2 Click and highlight a row and click 'Modify' button to modify the secured hosts, as shown in Figure 4-19 and Table 4-14 depicts the related parameters.

Figure 4-19 NE Secured Host Setting Dialog



Assign the IP range and check the authorized services (any combination of SNMP, TELNET, FTP and TFTP) of trusted hosts to be allowed.

Table 4-14 NE Secured Host Setting Dialog Description

Field	Description
IP Address Section	
Index	This indicates the index of IP address section under modifying.
The Beginning of Section	This specifies the beginning of the IP address section of the secured hosts.
The End of Section	This specifies the end of the IP address section of the secured hosts.
Authorized Service	Check the checkbox to select the authorized services.

# **NE Date and Time Management**

Follow the subsequent procedures to configure the NE system time.

Click Configuration  $\rightarrow$  NE Management  $\rightarrow$  System Time on **Main Menu** to open the **NE System Time** Dialog as shown in Figure 4-20 and Table 4-15 depicts the related parameters.

Figure 4-20 NE System Time Dialog




Table 4-15 NE System Time Dialog Description

Field	Description
Date / Time	
Local Date / Time	This indicates the current NE date and time.
Time Zone	
GMT	This indicates the time differences between the Greenwich Mean Time and the local time. Unit: hour
Up Time	
System Up Time	This indicates the period since the NE is rebooted last.
<b>Function Button</b>	
Set Date/Time	Click this button to apply the configured Local Date/Time.
Refresh	Click this button to refresh the Date/Time and Up Time information.
Close	Exit the NE System Time Dialog.

## **DNS Server Setting**

The DNS Server is used for the resolution of domain name. In other words, the DNS replies the corresponding IP address to the URL.

Follow the subsequent procedures to configure the DNS Server.

Click Configuration → NE Management → DNS Servers on **Main Menu** to open the **NE DNS Server Setting** Dialog as shown in Figure 4-21 and Table 4-16 depicts the related parameters.

Figure 4-21 DNS Server Setting Dialog



Table 4-16 DNS Server Setting Dialog Description

Field	Description
<b>DNS Server Information</b>	
The First Server	This specifies the first DNS server IP address.
The Second Server	This specifies the second DNS server IP address.
The Third Server	This specifies the third DNS server IP address.

# **Time Server Setting**

Follow the subsequent procedures to configure the time servers.

Step 1 Click Configuration → NE Management → Time Servers on Main Menu to open the Time Server Status Dialog as shown in Figure 4-22 and Table 4-17 depicts the related parameters.

Figure 4-22 NE Time Server Status Dialog




Table 4-17 NE Time Server Status Dialog Description

Field	Description
Time Server Information	
NE System Time	This indicates the current NE system time.
Network Timing Protocol	This indicates the current network time protocol, SNTP or None.
Update Period	This indicates the time period between two consecutive synchronizations of the NE's local time with the time server.
The First Server	This indicates the first time server the NE tries to synchronize with.
The Second Server	This indicates the second time server the NE tries to synchronize with.
The Third Server	This indicates the third time server the NE tries to synchronize with.
Status	This indicates connection status between the NE and the time server.
<b>Function Button</b>	
Adjust Time	Click this button to enforce the NE to synchronize its local time with the time server immediately.
Refresh	Click this button to refresh this launched window.
Modify	Click this button to set the NE time servers.
Close	Exit the NE Time Server Status Dialog.

Step 2 Click 'Modify' button to modify the Time Server information, as show in Figure 4-23 and Table 4-18 depicts the related parameters.

Figure 4-23 NE Time Server Setting Dialog




Table 4-18 NE Time Server Setting Dialog Description

Field	Description	
Network Time Server Info	Network Time Server Information	
Network Timing Protocol	This specifies the network timing protocol, either SNTP or None.	
Update Period	This specifies the time period between two consecutive synchronizations of the NE's local time with the time server.	
The First Server	This specifies the first time server the NE tries to synchronize with.	
The Second Server	This specifies the second time server the NE tries to synchronize with.	
The Third Server	This specifies the third time server the NE tries to synchronize with.	




The NE will synchronize its local time with the first time server's time as a top priority. If the first time server fails to respond, the NE tries to synchronize it's local time with the second and third time server's time in sequence.

# Saving the NE Configuration

Follow the subsequent procedures to save your NE configuration to Flash.

Click Configuration → NE Write Flash on **Main Menu** to open the **Write Flash Confirm** Dialog, or alternative select from the '**Rack**' tab view, point the mouse cursor on the NE object (Shelf, NC slot, or LC slot), and then right click the mouse button to launch the **Function Menu** and select '**Write Flash**' from this menu, as shown in Figure 4-24.

Figure 4-24 NE Write Flash Confirm Dialog



# **Chapter 5Profile Management**

A profile is a named list of configuration parameters with a value assigned to each parameter. By using a profile, the operator can configure the NE without to key in a lot of configuration parameters. However, whenever the operator modifies a profile, the modification will affect all ports using that profile.

This chapter describes the management of two kinds of profiles, data transport related profiles and alarm definition profile. The alarm definition profile defines the attributes of the report (alarm) of abnormality launched by the NE.

As to the data transport related profiles, they are

- xDSL Profile
- VLAN Profile

The xDSL Profile indicates the ADSL Profile and SHDSL Profile. It defines the attributes of the connection established via the xDSL subscriber loop. As to the VLAN Profile, it defines the attributes of services/applications applied to the xDSL subscriber.

Figure 5-25 and Table 5-19 help you to understand each profile and their interrelationship.

Figure 5-25 Interrelationship of Data Transport Related Profiles




Table 5-19 Data Transport Related Profiles

Profile		Capacity	Level	Category	Description
XDSL Profile	Line Profile	60 sets	Link	Loop	Define the attributes of xDSL loop connection.
	PM Threshold Profile	60 sets	Link	Loop	Report the message if loop connection error across the threshold.
	Traffic Policing Profile (ADSL LC only)	60 sets	Data	User Data	Define the rule of traffic policing for user data.
VLAN Profile	IP Traffic Profile	60 sets	Data	Unicast	Define the traffic bandwidth of Unicast connection.
	Multicast Service Profile	60 sets	Data	Multicast	A set of service selected from menu list.
	TV Channel Profile	800 sets	Data	Multicast	A menu list of multicast channel, it also defines the traffic bandwidth of Multicast connection.



To make Traffic Policing Profile take effect, it needs to set IP Traffic Profile properly. Please refer to the NOTE under Table 5-27.



To make an xDSL line works normally, the IP Traffic Profile is essential. As to the Traffic Policing Profile, it is optional and is only applicable to ADSL LC.



A profile is a named list of configuration parameters with a value assigned to each parameter. When you delete a profile you will affect the change on all port or connection using that profile. If you want to change a single port or a subset of ports, you can create another profile with desired parameters, and then assign the new profile to the desired port.

This chapter contains the following sections:

- Configuring the xDSL Profile
- Configuring the VLAN Profile
- Configuring the Alarm Definition Profile

At first, the usage of **Function Button** in the **ADSL Profile List Dialog** is described as follows. Click Configuration → Profile → ADSL Profile on **Main Menu** to open the **ADSL Profile List** Dialog. Figure 5-26 indicates the position of the **Function Button** by red rectangle.

ADSL Profile List X Line PM Threshold Traffic Policing Profile Name RateMode UpRate Max / Min DnRate Max / Min Channel 2976 / 64 adaptive/startup 29984 / 64 test Modify Add Refresh Profile List Dialog Function Button Disable Close [X]

Figure 5-26 xDSL Profile List Dialog Function Button

Table 5-20 xDSL Line Profile List Dialog Function Button

Field	Description
Show	Click this button to view the details of selected profile.
Modify	Click this button to modify the parameters of selected profile
Add	Click to add a new profile.
Delete	Click this button to delete the selected profile.
Refresh	Click to refresh the xDSL Profile List
Export	Click this button to save the contents of <b>xDSL Profile List</b> to the Personal Computer.
Close	Exit the xDSL Profile List Dialog.

# Configuring the xDSL Profile

The xDSL profiles enable you to simplify the process to configure the different xDSL loops with the same loop/data connection attributes. For example, you may classify the subscribers to several categories like category of residential customers, category of small office customers, category of enterprise customers and so on. Each category of subscribers is with the same loop/data connection attributes. Different categories are with their specific attributes like the line speed and performance monitoring to secure their particular service quality. Once the profiles are created, you can easily assign the xDSL subscriber with the request xDSL loop attributes.

This section depicts the supported xDSL profiles

- ADSL Profile
- SHDSL Profile

#### **ADSL Profile**


Three types of profiles are relative to the ADSL loop, which are Line Profile, Traffic Policing Profile and PM Threshold Profile.

Click Configuration → Profile → ADSL Profile on Main Menu to open the ADSL Profile List Dialog.

## Line Profile

Click the **Line** tab in ADSL Profile List dialog to launch the **ADSL Profile List – Line Dialog** to configure the ADSL Line profile as shown in Figure 5-27.

Figure 5-27 ADSL Profile List – Line Dialog



Click 'Add' button to generate a line profile. Or select an existent profile and click 'Modify' to modify it. It is noted that each profile must have its unique profile name.

The line profile consists of the following groups of ADSL loop related parameters.

- Transmission Rate
- SNR margin
- PSD
- Power management
- INP

#### **Transmission Rate**

Click the **Transmission Rate tab** in **ADSL Line Profile Dialog** to launch the **ADSL Line Profile**—**Transmission Rate Dialog** as shown in Figure 5-28. Table 5-21 depicts the related parameters.

[10.12.3.97] ADSL Line Profile : <new> Profile Information **Profile Name** Transmission Rate | SNR Margin | PSD | Power Management | INP C Fixed ○ Fast Adaptive at Startup ○ Adaptive at Run-time Upstream - Downstream -64 ÷ Kbps 64 ÷ Kbps Min Rate Min Rate - Kbps ÷ Kbps Max Rate Max Rate msec msec Max Delay Max Delay <u>C</u>ancel <u>o</u>K

Figure 5-28 Add ADSL Line Profile- Transmission Rate Dialog

Table 5-21 Add Line Profile- Transmission Rate Dialog Description

Field	Description		
Profile Information			
Profile Name	Enter to give a profile name		
<b>Channel Mode</b>			
Interleave	Click to let the ADSL loop to be in the interleave mode. Interleave mode enhances the immunity to the impulse noise like lighting. However, its side effect is to introduce the transmission latency. Hence it is suitable for the time-insensitive data transmission, like file transfer.		
	Its associated parameters are the 'Upstream/Downstream Max Delay'		
Fast	Click to let the ADSL loop to be in the fast mode. Fast mode is suitable for the transmission of time-sensitive information such as audio.		
Rate Mode			
Fixed	Click to let the ADSL loop to be of a fixed rate as specified by the 'Upstream/Downstream Min Rate'. In this mode, the NE will fail to establish the connection with ATU-R whenever it is not allowed in the physical loop environment. The failure may be due to the loop length, line quality, and so on.		
Adaptive at Startup	Click to let the ADSL loop to be of the rate adapted in the range specified by the 'Upstream/Downstream Min/Max Rate'.  In comparison with 'Adaptive at Run-time', the NE will re-try to establish a new lower-rate connection with the ATU-R whenever the NE or ATU-R detects 10 consecutive SESs (Severely Error Seconds) in this mode.		
Adaptive at Run-time	Click to let the ADSL loop to be of the rate adapted in the range specified by the 'Upstream/Downstream Min/Max Rate'.  In comparison with 'Adaptive at Startup', the NE will trigger the SRA (Seamless Rate Adaptation) process to change the line rates without losing the connection with ATU-R whenever the physical loop environment varies in this mode.		

Table 5-3 Add Line Profile- Transmission Rate Dialog Description (Continued)

Field	Description
Upstream	
Min Rate	Choose the minimum rate for the ATU-R to transmits traffic
Max Rate	Choose the maximum rate for the ATU-R to transmits traffic
Max Delay	Choose the maximum interleaved delay in milliseconds. (interleave mode only)  Interleaved delay applies only to the interleave channel and defines the mapping between subsequent input bytes at the inter-leaver input and their placement in the bit stream at the interleave output. Larger numbers provide greater separation between consecutive input bytes in the output bit stream, allowing for improved impulse noise immunity at the expense of payload latency.
Downstream	
Min Rate	Choose the minimum rate for the ATU-C to transmits traffic
Max Rate	Choose the maximum rate for the ATU-C to transmits traffic
Max Delay	Choose the maximum interleaved delay in milliseconds. (applied to the interleave mode only)



The associated parameters of the Rate Mode 'Adaptive at Run-Time' are as follows.

'Upshift Noise Margin', 'Downshift Noise Margin', 'Upshift Time' and 'Downshift Time'



In the Rate Mode 'Adaptive at Run-Time', the NE will lose the connection with ATU-R if it fails to complete the SRA process to change the line rates

## **SNR Margin**

Click the **SNR Margin tab** in **ADSL Line Profile Dialog** to launch the **ADSL Line Profile—SNR Margin Dialog** as shown in Figure 5-29. Table 5-22 depicts the related parameters.

Figure 5-29 Add ADSL Line Profile- SNR Margin Dialog




Table 5-22 Add Line Profile- SNR Margin Dialog Description

Field	Description
Upstream	
Downstream	
Max Margin	It specifies the maximum margin in 0.1 dB steps. Default value is 310.
Upshift	It specifies the up-shift margin in 0.1dB steps. Default value is 200
Target	It specifies the target margin in 0.1dB steps. Default value is 60.
Downshift	It specifies the downshift margin in 0.1 dB steps. Default value is 30
Min	It specifies the minimum margin in 0.1 dB steps. Default value is 0.
Upshift Time	It specifies the upshift time in sec. It defines the minimum time interval during which the upstream noise margin should stay above the Upshift SNR before the ATU-C triggers the SRA process to increase the line rate.  Default value is 1000.Default value is 1000.
Downshift Time	It specifies the downshift time in sec. It defines the minimum time interval during which the upstream noise margin should stay above the Downshift SNR before the ATU-C triggers the SRA process to decrease the line rate.  Default value is 1000.



'Upshift Noise Margin', 'Downshift Noise Margin', 'Upshift Time' and 'Downshift Time' are only applied to the Rate Mode 'Adaptive at Run-Time'.




Minimum Noise Margin  $\leq$  Downshift Noise Margin  $\leq$  Target Noise Margin  $\leq$  Upshift Noise Margin  $\leq$  Maximum Noise Margin.

## **PSD**

Click the **PSD tab** in **ADSL Line Profile Dialog** to launch the **ADSL Line Profile**– **PSD Dialog** as shown in Figure 5-30. Table 5-23 depicts the related parameters.

Figure 5-30 Add ADSL Line Profile- PSD Dialog



## Table 5-23 Add Line Profile – PSD Dialog Description

Field	Description
Upstream	
Downstream	
Nominal PSD	It specifies the discrepancy with respect to the ITU-T G.992.3-defined MAXNOMPSD value. Its unit is 0.1 dBm/Hz. And its allowed range is from 40 to -400.



It is noted that the MAXNOMPSD settings are different for the following three protocol groups.

- G.992.1 Annex A and B; G.992.2 Annex A and G; G.992.3 Annex A, B and J;
- G.992.5 Annex A, B and M
- G.992.3 Annex L

To ease the configuration, the Nominal PSD is defined to be the discrepancy with respect to the MAXNOMPSD..

## **Power Management**

In order to save power, G.992.3 and G.992.5 define the power management function. The operator can either configure the ADSL line Transmission (Tx) power be either manually or automatically managed.

The automatic power management function enables the ADSL line to automatically transfer from the L0 (full-on) state to the L2 (low power) state whenever the downstream net data rate is lower than expected. And it also enables the ADSL line to automatically transfer from the L2 state to the L0 state once the NE begins to drop the downstream data.

Click the **Power Management tab** in **ADSL Line Profile Dialog** to launch the **ADSL Line Profile—Power Management Dialog** as shown in Figure 5-31. Table 5-24 depicts the related parameters.

[10.12.3.97] ADSL Line Profile : <new> × Profile Information Profile Name Transmission Rate | SNR Margin | PSD | Power Management | INP Management Mode ○ Automatic ← Manual Trigger Criteria of State Transition L2 State Min & Low Rate 32 ÷ Kbps L2 State Max Rate 29984 ÷ Kbps sec L0 State Min Time to Start Monitoring L2 State Low Rate Min Contiguous Time 300 sec **CPE L3 State Request**  Accept C Reject

Figure 5-31 Add ADSL Line Profile Power Management Dialog

## Table 5-24 Add Line Profile – Power Management Dialog Description

Field	Description

<u>o</u>k

<u>C</u>ancel

## **Management Mode**

Automatic – This mode enables the ADSL line to automatically transfer from the L0 (full-on) state to the L2 (low power) state whenever the downstream net data rate is lower than expected. And it also enables the ADSL line to automatically transfer from the L2 state to the L0 state once the NE begins to drop the downstream data.

Manual –This mode allows the operator to manually force the specific ADSL line to transfer from the L2 state to the L0 state, and vice versa.

Trigger Criteria Of State Transition		
L2 State Min & Low Rate	It specifies the minimum rate (manual mode) or Lowest criteria (auto mode) of L2 state. (See the Note below) Default value is 32.	
L2 State Max Rate	It specifies the maximum rate of L2 state. (See the Note below) Default value is 29984.	
L0 State Min Time to Start Monitoring	It specifies the minimum time (seconds) the ADSL line must stay at the L0 state. During this time interval, the ADSL line is not allowed to transfer to the L2 state. It is the so-called L0-TIME as defined in ITU-T G.997.1. (See the Note below)  Default value is 900.	
L2 State Low Rate Min Contiguous Time	It specifies the contiguous time interval for which the downstream mean net data rate is below the 'L2 State Min & Low Rate' on a ADSL line. (See the Note below)  Default value is 300.	
CPE L3 State Request	It specifies whether the ADSL port accepts L3 command from CPE or not. Default value is "Accept".	



In order to let the ADSL line avoid going into and out of L2 too often, the following  $L0 \leftrightarrow L2$  state transition criteria are adopted.

#### L0→L2:

- The ADSL line must stay at the L0 state for a period specified by 'L0 State Min Time to Start Monitoring' (i.e., the L0-TIME as defined in ITU-T G.997.1)
- After the L0-TIME, the NE begins to compute the mean net-data rate for a period of 'L2 State Low Rate Min Contiguous Time' on a ADSL line.
- The ADSL line transfers to the L2 state once the computed mean net-data rate is below the 'L2 State Min & Low Rate'.
- Once an ADSL line is at the L2 state, its downstream ADSL line rate is in the range from 'L2 State Min & Low Rate' to 'L2 State Max Rate'.

#### L2→L0:

 The ADSL line immediately transfers to the L0 state once the NE detects packet loss on the ADSL line in the down stream direction.

#### **INP**

The INP (Impulse Noise Protection) defines the minimum protection symbol time both for upstream and downstream on this ADSL subscriber.

Click the **INP tab** in **ADSL Line Profile Dialog** to launch the **ADSL Line Profile– INP Dialog** as shown in Figure 5-32. Table 5-25 depicts the related parameters.

Figure 5-32 Add ADSL Line Profile- INP Dialog




Table 5-25 Add Line Profile – INP Dialog Description

Field	Description
Upstream	
Downstream	
Minimum INP	It specifies the impulse noise protection symbol time in {0, 1/2, 1, 2, 4, 8, 16}.


#### **PM Threshold Profile**

The PM threshold profile sets the threshold values for the performance parameters associated with

the ADSL line. The NE will report the threshold-over trap (i.e. TCA, Threshold-Crossing Alarm) to the AMS LCT when the specified performance threshold is over. Figure 5-33 shows ADSL PM threshold profiles accommodated in the system and allows adding a new profile or deleting the existing profile, by system (NE) unit.

Click the **PM Threshold** tab in **ADSL Profile List Dialog** to launch the **ADSL Line Profile – PM Threshold Dialog** as shown in Figure 5-33.

Figure 5-33 xDSL Profile List- PM Threshold Dialog



Click 'Add' button to generate a PM threshold profile, each profile must have its unique profile name. Or select an existent profile and click 'Modify' to modify it. Figure 5-34 shows **Add ADSL PM Threshold Profile Dialog**. Table 5-26 depicts the related parameters.

Figure 5-34 Add ADSL PM Threshold Profile Dialog




Table 5-26 Add PM Threshold Profile Field Description

Field	Description

#### 15-Min / CO

This field indicates the CO side errors. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.

#### 1-Day / CO

This field indicates the CO side errors. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day.

#### 15-Min / RT

This field indicates the RT side (CPE) errors. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.

#### 1-Day / RT

This field indicates the RT side (CPE) errors. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 1 day.


ES	It specifies the Error second (0 $\sim$ 900 sec)
SES	It specifies the Several Error Second (0 ~ 900 sec)
UAS	It specifies the unavailable Second (0 ~ 900 sec)

#### **Traffic Policing Profile**

According to SLA (Service Level Agreements) between subscribers and ISP, the edge network equipment marks subscriber's traffic with different service level. The traffic policing profile serves to keep the rule to re-mark the subscriber's upstream traffic with designated DSCP values. The traffic policing profile is design to police on the unicast connection for user's upstream traffic; once it is created you can apply it to distinct ADSL line interfaces (see Chapter 6 xDSL Line Interface).


To set the traffic policing profile, click Configuration  $\rightarrow$  Profile  $\rightarrow$  ADSL Profile  $\rightarrow$  Traffic Policing Dialog.

Figure 5-35 xDSL Profile List- Traffic Policing Dialog



Click 'Add' button to generate a Traffic Policing profile, each profile must have its unique profile name. Or select an existent profile and click 'Modify' to modify it. Figure 5-36 shows the **Add Traffic Policing Profile Dialog**. Table 5-27 depicts the related parameters.

Figure 5-36 Add Traffic Policing Profile Dialog



## Table 5-27 Add Traffic Policing Profile Field Description

Field	Description
<b>Profile Information</b>	
Name	It specifies the name of traffic policing profile.
Rate Limiting	
Upstream CIR (Mbps)	It specifies the CIR (Commit Information Rate). Valid value is 0~2 Mbps.
Action to Out-profile Packets	It specifies the DSCP value to be set, drop packets or do nothing whenever the user's upstream traffic exceeds CIR.



The Service Type Control shall be enabled when Traffic Policing Profile is assign to xDSL subscribers (refer to Figure 6-52).



Please refer to Figure 6-60 for more details of Differentiated Service Code Point.


## SHDSL Profile

Two types of profiles are related with the SHDSL loop, which are Line Profile and PM Threshold Profile.

#### **Line Profile**

The line profile contains parameter relate to the loop connection of SHDSL. Click the **Line** tab in **SHDSL Profile List Dialog** to launch the **SHDSL Profile List – Line Dialog** to configure the ADSL Line profile as shown in Figure 5-37.

Figure 5-37 SHDSL Profile List- Line Dialog



Click 'Add' button to generate a line profile. Or select an existent profile and click 'Modify' to modify it. It is noted that each profile must have its unique profile name.

The line profile consists of the following groups of SHDSL loop related parameters.

- Transmission Rate
- SNR margin
- Miscellaneous

### **Transmission Rate**

Click the **Transmission Rate tab** in **SHDSL Line Profile Dialog** to launch the **SHDSL Line Profile**—**Transmission Rate Dialog** as shown in Figure 5-38. Table 5-28 depicts the related parameters.

Figure 5-38 Add SHDSL Line Profile- Transmission Rate Dialog




Table 5-28 Add SHDSL Line Profile- Transmission Rate Dialog Description

Field	Description
Profile Information	
Profile Name	Enter to give a profile name
Rate Mode	
Fixed	Click to let the SHDSL loop to be of a fixed rate as specified by the 'Min Rate'. In this mode, the NE will fail to establish the connection with STU-R whenever it is not allowed in the physical loop environment. The failure may be due to the loop length, line quality, and so on.
Adaptive at Startup	Click to let the SHDSL loop to be of the rate adapted in the range specified by the 'Min/Max Rate'.
Rate Limit	
Min Rate	Choose your minimum rate.
Max Rate	Choose your maximum rate.

## **SNR Margin**

Click the **SNR Margin tab** in **SHDSL Line Profile Dialog** to launch the **SHDSL Line Profile-SNR Margin Dialog** as shown in Figure 5-39. Table 5-29 depicts the related parameters.

Figure 5-39 Add SHDSL Line Profile- SNR Margin Dialog




Table 5-29 Add SHDSL Line Profile - SNR Margin Dialog Description

Field	Description
Upstream / Downstream	
Current Target Margin	It specifies the current target margin.  Default value is 6.
Worst Target Margin	It specifies the worst target margin.  Default value is 6.

#### Miscellaneous

Click the **Miscellaneous tab** in **SHDSL Line Profile Dialog** to launch the **SHDSL Line Profile—Miscellaneous Dialog** as shown in Figure 5-40. Table 5-30 depicts the related parameters.

Figure 5-40 Add SHDSL Line Profile- Miscellaneous Dialog




Table 5-30 Add SHDSL Line Profile- Miscellaneous Dialog Description


Field	Description
Miscellaneous Parameters	
PSD Mask	It specifies the setting of PSD Mask to be symmetric or asymmetric
Tx Mode	It specifies the setting of Tx mode. A: Indicates the ITU-T G.991.2 Annex A B: Indicates the ITU-T G.991.2 Annex B A+B: Compatible with ITU-T G.991.2 Annex A and Annex B.
Line Probe	Enable or disable the line probe state before training with STU-R. Enable: To make the 'line rate limit' up to 2312Kbps. Disable: To make the 'line rate limit' up to 1.5Mbps.

## **PM Threshold Profile**

The PM threshold profile sets the threshold values for the error status generated in the ADSL line, and sets the system to report the threshold-over trap (alarm) to the AMS LCT when the set error threshold is over. Figure 5-41 lists SHDSL PM threshold profiles accommodated in the system and allows adding a new profile or deleting the existing profile, by system (NE) unit.


Click the **PM Threshold tab** to launch the **PM Threshold Dialog** as shown in Figure 5-41.

Figure 5-41 SHDSL Profile List- PM Threshold Dialog



Click 'Add' button to generate a PM threshold profile, each profile must have its unique profile name. Or select an existent profile and click 'Modify' to modify it. Figure 5-42 shows **Add SHDSL PM Threshold Profile Dialog**. Table 5-31 depicts the related parameters.

Figure 5-42 Add SHDSL PM Threshold Profile Dialog



## Table 5-31 Add SHDSL PM Threshold Profile Dialog Description

Field	Description

## CO SNR Margin and Loop Attenuation Threshold

This field indicates the minimum SNR margin and maximum loop attenuation.

When the minimum SNR margin is set to 10, if the current SNR margin is below 10 dB, a trap (alarm) occurs.

When the maximum loop attenuation is set to 100, if the current loop attenuation exceeds 100 dB, a trap (alarm) occurs.

#### CO 15-Min PM High-Threshold

This field indicates the CO side errors. When the threshold is set to 10, if the count of specific errors exceeds 10 seconds for the last error accumulated, a trap (alarm) occurs.

ES	It specifies the Error second (0 $\sim$ 900 sec)
SES	It specifies the Several Error Second (0 ~ 900 sec)
UAS	It specifies the unavailable Second (0 ~ 900 sec)
LOSWS	It specifies the Loss of Synchronization Word Second (0 ~ 900 sec)
CRC Anomalies	It specifies the count of anomaly of Cyclic Redundancy Check (1 ~ 44100)

## Configuring the VLAN Profile

VLAN Profile contains three categories of profiles.

- IP Traffic Profile
- TV Channel Profile
- Multicast Service Profile

As shown in Figure 5-25, NE forwards traffic on 2 kinds of connections, unicast connection and multicast connection, on the Data Level. For the unicast connection, it carries all traffic (unicast and broadcast) except multicast traffic. The attributes of unicast connection are specified by the IP Traffic Profile. As for the multicast connection, its attributes are specified by the TV Channel Profile. Moreover, the NE also supports to restrict the subscriber to receive a set of specific TV channels. Multicast Service Profile records the set of specific TV channels.


Click Configuration → Profile → VLAN Profile on Main Menu to open the VLAN Profile List Dialog.

## **IP Traffic Profile**

The IP traffic profile is design to specify the traffic attributes of the PVC on the ADSL line. The operator can create the IP Traffic Profile according to the Service Level Agreement (SLA) and apply it to the corresponding VC-to-VLAN on demand. (see Chapter 7 VC-to-VLAN Connection ).

Click the IP Traffic tab in VLAN Profile List Dialog to launch the VLAN Profile List—IP Traffic Dialog as shown in Figure 5-43.

Figure 5-43 VLAN Profile List- IP Traffic Dialog



Click 'Add' button to generate an IP traffic profile, each profile must have its unique profile name. Or select an existent profile and click 'Modify' to modify it. Figure 5-44 shows **Add xDSL IP Traffic Profile Dialog**. Table 5-32 depicts the related parameters.

Figure 5-44 Add xDSL IP Traffic Profile Dialog




Table 5-32 Add xDSL IP Traffic Profile Dialog Description


Field	Description
Profile Information	
Name	Enter the name of traffic profile.
Line Board IP CoS Setting	
Downstream Priority Queue (Kbps)	It specifies the downstream priority queue. Valid values are "Low", "Medium", "High" and "Highest".
Downstream Rate (Kbps)	It specifies the maximum allowed downstream net-data rate. The drops drop packets whenever the downstream traffic exceeds the specified rate.
Upstream Rate (Kbps)	It specifies the maximum allowed upstream net-data rate. The drops drop packets whenever the user's upstream traffic exceeds the specified rate.  Valid values are "no limit", "32", "64", "128", "256", "384", "512", "768"
Broadcast Control	
Downstream Broadcast	This indicates the rule (forward or drop) for downstream broadcast traffic.

## **TV Channel Profile**

The TV channel profile sets value of multicast group IP and the associated downstream bandwidth resource, it is a menu list of the TV channel (multicast group) provided by the Content Service Provider (CSP) or Application Service Provider (ASP).

Click the TV Channel tab in VLAN Profile List Dialog to launch the VLAN Profile List–TV Channel Dialog as shown in Figure 5-45.

Figure 5-45 VLAN Profile List- TV Channel Dialog



Click 'Add' button to generate a TV channel profile, each profile must have its unique profile name. Or select an existent profile and click 'Modify' to modify it. Figure 5-46 shows **Add xDSL TV Channel Profile Dialog.** Table 5-33 depicts the related parameters.

Figure 5-46 Add xDSL TV Channel Profile Dialog




Table 5-33 Add xDSL TV Channel Profile Dialog Description

Field	Description
<b>Profile Information</b>	
Profile ID	It specifies the TV channel ID
Name	Enter the TV channel name
TV Channel IP Address	It specifies the IP address of TV channel (multicast group IP)
IP CoS Settings	
Priority Queue	This specifies the priority queue of TV Channel address. Valid values are "Low", "Medium", "High" and "Highest".
Downstream Rate (Kbps)	It specifies the maximum allowed downstream net-data rate. The drops drop packets whenever the downstream traffic exceeds the specified rate.


#### **Multicast Service Profile**

The multicast service profile is a set of TV channel profiles. Once the TV channel profiles are created, you can generate the multicast service profile to bind suitable TV channel profiles. Each multicast service profile is viewed as a service package for the subscriber to book. The operator then applies the booked multicast service profile to the distinct VC-to-VLAN associated with the subscriber. (see Chapter 7).

Whenever the subscriber clicks his remote controller to watch a TV channel transmitted via the ADSL line, the set-top-box sends the corresponding IGMP report packet. The NE will forward IGMP packet if its multicast IP hits the associated multicast service profile. Otherwise, the NE drops the IGMP packet. As a result, the subscriber is restricted to watch the TV programs that he booked.

Click the **Multicast Service tab** in **VLAN Profile List Dialog** to launch the **VLAN Profile List-Multicast Service Dialog** as shown in Figure 5-47.

Figure 5-47 VLAN Profile List- Multicast Service Dialog



Click 'Add' button to generate a multicast service profile, each profile must have its unique profile name. Or select an existent profile and click 'Modify' to modify it. Figure 5-48 shows **Add xDSL Multicast Service Profile Dialog**. Table 5-34 depicts the related parameters.

Figure 5-48 Add xDSL Multicast Service Profile Dialog




Table 5-34 Add Multicast Service Profile Dialog Description

Field	Description
Profile Information	
Name	Enter the multicast service profile name.
TV Channel	
ID	The serial number for group profile.
Group Profile Name	It specifies the group profile name
TV Channel IP Address	It specifies the multicast IP address
Show	Click this button to view the detail information from List Table.

## **Configuring the Alarm Definition Profile**

The alarm definition profile allows you to define the rule of alarm element in system. Through this profile, you are able to change the severity of individual alarm element and decide to report it or not. Alarm element is specified in the class of module or port. Different types of module may present different alarm element. Different types of port may also present different alarm element.

Step 1 Click Configuration → Profile → Alarm Definition on Main Menu to open the Alarm Definition List Dialog as shown in Figure 5-49. Table 5-35 depicts the related parameters.






Table 5-35 Alarm Definition List Dialog Description

Field	Description
List Table	
Name	It specifies the alarm name.
Severity	It specifies the alarm severity.
Reporting	It specifies the reporting status.
Suppressed By	It specifies the rule of alarm suppression.
Description	It specifies the alarm description.
Top Combo-box	
NE	This indicates the current NE model.
Class	Use this combo-box to select the alarm class, shelf, module or port.
Model	Use this combo-box to select the card module or port module.
<b>Function Button</b>	
Modify	Select the item from List Table to modify.
Export	Click this button to save the contents of <b>Alarm Definition List</b> to the Personal Computer.
Close	Exit the Alarm Definition List Dialog.

Step 2 Click 'Modify' button to modify the Alarm Definition. Figure 5-50 shows Modify Alarm Definition Dialog, and Table 5-36 depicts the related parameters.

Figure 5-50 Modify Alarm Definition Dialog




Table 5-36 Modify Alarm Definition Dialog Description

Field	Description
Alarm Information	
Model	It specifies current module name under modifying.
Alarm Name	It specifies the alarm name.
Description	This describes the current selected alarm.
Alarm Severity	Check the radio button to set the alarm severity of the specified alarm.
Alarm Reporting	Enable or disable reporting of the specified alarm.
Alarm Suppression (Suppressed by)	
Name	Check the check box to choose which the specified alarm to be suppressed by.
Description	This describes the alarm's meaning.



The alarm suppression (suppressed by) allows you to mask specific alarms when there are sequences occurred at the same time. For example, let the LOF (Loss of Frame) be configured to be suppressed by the LOS (Loss of Signal), the LOF will not be display on the screen but only LOS whenever the corresponding ADSL loop is cut.

# **Chapter 6Interface Port Management**

This chapter depicts the management of subscriber interfaces and GE network interfaces. This chapter contains the following sections.

- xDSL Line Interface Management
- GE Network Interface Management

## **xDSL Line Interface Management**

This section helps you to attach the profile to the xDSL line interfaces. The function buttons of xDSL Port List dialog provides shortcut of relative port setting. As the ADSL and SHDSL configuration are similar and hence illustrated together in this section.

Step 1 Click Configuration → xDSL → ADSL Port Setting on Main Menu to open the ADSL Port List Dialog as shown in Figure 6-51. Table 6-37 depicts the related parameters.
 Or

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  SHDSL Port Setting on **Main Menu** to open the **SHDSL Port List** Dialog. Table 6-37 depicts the related parameters.

Figure 6-51 ADSL Port List Dialog




Table 6-37 xDSL Port List Dialog Description

Field	Description
List Table	
No.	This specifies the serial number of entry of List Table.
Slot-Port	This specifies the location of ADSL port
Line Profile	This specifies the line profile.
PM Threshold	This specifies the PM threshold profile.
Traffic Policing	This specifies the Traffic Policing profile. [Only for the <b>ADSL Port List</b> Dialog]
Admin State	This specifies the administrative status (enable or disable)
Link Status	It specifies the link connection status.
<b>Function Button</b>	
Show	Click this button to show.
Modify	Click this button to modify.
VC-to-VLAN	Click this button to configure the VC-to-VLAN parameters
MC Channel	Click this button to configure the multicast channel related parameters. [Only for the <b>ADSL Port List</b> Dialog]
Rate Status	Click this button to monitor the connection rate status.
Profile	Click this button to arrange the profile setting.
Reset Port	Click this button to reset port
Current PM	Click this button to view the current performance
History PM	Click this button to view the historical performance
Export	Click this button to save the contents of <b>ADSL Port List</b> to the Personal Computer.
Close	Exit the ADSL Port List Dialog.

Step 2 Select an ADSL port and click 'Modify' button to modify the ADSL port. Figure 6-52 shows **ADSL Port Modification Dialog**. Table 6-38 depicts the related parameters.

Figure 6-52 ADSL Port Modification Dialog




Table 6-38 ADSL Port Modification Dialog Description

Field	Description	
ADSL Port	This indicates the current ADSL Port under modification.	
Administrative State	Enable or disable the specified ADSL port.	
ADSL Profiles		
Line Profile	Use this combo-box to select an existent ADSL line profile.	
PM Threshold	Use this combo-box to select an existent PM Threshold profile.	
Traffic Policing	Use this combo-box to select an existent Traffic Policing profile.	
Service Type Control	This indicates the state of Service Type Control (STC) of the selected ADSL line card.	
<b>Function Button</b>		
OK	Press this button to commit setting.	
Cancel	Press this button to cancel setting.	



Service Type Control (STC) only takes effect after the applied line card is reset.



To make the applied Traffic Policing Profile take effect, Service Type Control (STC) must be enabled.

For the SHDSL ports, follow the subsequent procedures.

Step 3 Select an SHDSL port and click 'Modify' button to modify the SHDSL port. Figure 6-53 shows SHDSL Port Modification Dialog. Table 6-39 depicts the related parameters.

Figure 6-53 SHDSL Port Modification Dialog




Table 6-39 SHDSL Port Modification Dialog Description

Field	Description	
SHDSL Port	This indicates the current SHDSL Port which is under modifying.	
Administrative State	Enable or disable the specified SHDSL port.	
SHDSL Profiles		
Line Profile	Use this combo-box to select an existent SHDSL line profile.	
PM Threshold	Use this combo-box to select an existent PM Threshold profile.	
Function Button		
OK	Press this button to commit setting.	
Cancel	Press this button to cancel setting.	



In comparison with the ADSL Port List Dialog, the SHDSL Port List Dialog does not support the following function

- Traffic Policing
- Service Type Control

# **GE Network Interface Management**

There are two GE network interfaces, GE1 and GE2, for DAS4 series IP-DSLAM. GE1 is stated as the uplink GE port. All traffic from the xDSL line interface is forwarded to this interface by default. (i.e., the so-called port isolation) GE2 is stated as the subtended GE port, and it connects to other equipment and forward traffics to GE1 if none of LACP or RSTP is enabled.

Step 1 Point mouse pointer at GE port object, click mouse right button Trunk → Port Setting on launched **Menu** to open the **Trunk Port List** Dialog as shown in Figure 6-54 and Table 6-40 depicts the related parameters.

Figure 6-54 Trunk Port Dialog




Table 6-40 Trunk Port Dialog Description

Field	Description		
Trunk Port List Table			
No.	This indicates the serial number of entry of the List Table.		
Slot-Port	This indicates the location of trunk GE port.		
Admin State	This indicates the administrative state of GE port.		
Link Status	This indicates the operational state of GE port.		
Mode	This indicates the mode of GE port, be either an uplink port or a subtended port.		
Auto Negotiation	This indicates the auto negotiation status of GE port.		
<b>Function Button</b>			
Modify	Click this button to modify.		
PM	Click this button to show GE port's performance statistics.		
Export	Click this button to save the contents of <b>Trunk Port List</b> to the Personal Computer.		
Close	Exit the <b>Trunk Port List</b> Dialog.		

Step 2 Click 'Modify' button to modify the trunk port. Figure 6-55 shows the **Trunk Port Configuration Dialog**, and Table 6-41 depicts the related parameters.

Figure 6-55 Trunk Port Configuration Dialog





Table 6-41 Trunk Port Configuration Dialog Description

Field	Description	
Trunk Port	This indicates the GE port under configuring.	
Administrative State	Enable or disable the specified GE port.	
Port Mode	Setting the GE port to uplink mode or subtended mode. Subtended mode is only available on GE2, GE1 is always the uplink port.	
Auto-Negotiation	Enable or disable the auto-negotiation mode of the specified GE port.	

Figure 6-56 GE Network Interface Packet Forward Illustrate



The DAS4 series IP-DSLAM support the so-called "Port Isolation", all xDSL users can not communicate with each other.

Once the GE2 is configured as a subtended port, all the ingress traffic of GE2 is restricted to be forwarded to GE1.

## Link Aggregation (Static / Dynamic)

Link aggregation is to aggregate the 2 GE ports to provide higher uplink bandwidth. This dialog allows you to configure both static link aggregation and LACP (IEEE802.3ad, Link Aggregation Control Protocol).

Follow the subsequent procedures to configure the related parameters.

Click Configuration → Trunk → Link Aggregation on **Main Menu** to open the **Link Aggregation Setting Dialog** as shown in Figure 6-57. Table 6-42 depicts the related parameters.

Figure 6-57 Link Aggregation Setting Dialog




Table 6-42 Link Aggregation Setting Dialog Description

Field	Description		
Link Aggregation Type			
LACP	Set link aggregation type to "LACP" for GE ports.		
Static	Set link aggregation type to "Static" for GE ports.		
Disable	Check this radial button to forbid the GE ports to run any link aggregation function.		
LACP Settings			
System Priority	It specifies the system priority required for the LACP.		
Group1/Group2 (Tab)			
Activity	It specifies the activity of the GE ports of the specified group, active or passive, for the LACP.		
	Passive: The NE does not initiate LACP negotiation procedure		
	on the specified group voluntarily, but waits for its LACP peer (in active state) initiates negotiation. The NE will form the aggregation link with its peer at the end of the negotiation procedure.		
	Active: The NE is willing to initiate the LACP negotiation		
	procedure on the specified group and sends out an		
	LACP packet voluntarily. The aggregation link will be formed if the other end is running in LACP active or passive mode.		
Timeout	It specifies the interval of periodical transmitting LACP BPDU by the peer NE. If the NE does not receive the LACP BPDU after 3 consecutive specified intervals, the NE will remove the port from the aggregation link. For a busy aggregation link, it is recommended to set a short timeout to ensure that a disabled port is removed as soon as possible.  Its value is either long (30 seconds) or short (1 second).		
Port GE1/Port GE2 (Tab)	· ·		
LACP Group	It specifies which the LACP group of GE1/GE2 is.		
Port Priority	It specifies the port priority of GE1/GE2.		

### **RSTP Configuration**

The RSTP protocol smartly prevents the loop connection in your uplink networks. It improves the Spanning Tree Protocol (STP) by reducing the fail-over time whenever there is network topology change. The configuration of RSTP is divided to 2 parts. One is the system-wise configuration, which is described in the subsection "Bridge". The other one is the port-specific configuration, which is described in the subsection "Port GE1/Port GE2".

Follow the subsequent procedures to configure the related parameters.

Click Configuration → Trunk → RSTP Setting on Main Menu to open the Rapid Spanning Tree Protocol for Trunk Ports Dialog

### **Bridge**

Click the **Bridge tab** in **Rapid Spanning Tree Protocol for Trunk Ports Dialog** to launch the **Rapid Spanning Tree Protocol for Trunk Ports – Bridge Dialog** as shown in Figure 6-58. Table 6-43 depicts the related parameters.

Figure 6-58 Trunk RSTP Setting- Bridge Dialog




Table 6-43 Rapid Spanning Tree Protocol for Trunk Ports- Bridge Dialog Description

Field	Description	
RSTP Administrative State		
Administrative State	Enable or disable the RSTP function for GE ports.	
Version	This specifies the RSTP version the NE runs.	
Bridge (Tab)		
Current Bridge ID	It indicates an unique 8-octet bridge ID which consists of a 2-octet Bridge Priority and a 6-octet MAC address.	
Bridge Priority	It specifies the 2-octet bridge priority. If the given value is lower than all the other L2 devices', the NE is selected as the root bridge as defined in IEEE 802.1d/ 802.1w.	
	Its valid range is through 0 to 61440 in steps of 4096	
Max Age	It specifies the maximum age of STP/RSTP information learned from the network on any port before it is discarded.	
Hello Time	It specifies the amount of time between the transmission of configuration bridge PDUs by this node on any port when it is the root of the spanning tree or trying to become so.	
Forward Delay	This specifies the time value that controls how fast a port changes its spanning state when moving towards the Forwarding state. The value determines how long the port stays in the Learning states, which precede the Forwarding state. This value is also used, when topology change has been detected and is underway, to age all dynamic entries in the Forwarding Database.	
Tx Hold Count	This specifies the value used by the port Transmit state machine to limit the maximum transmission rate.	



It is noted that the following relationships have to be maintained.

2 x (Forward Delay - 1 second) >= Max Age Max Age >= 2 x (Hello Time + 1 second)

#### Port GE1/Port GE2

Click the **Port GE1/Port GE2** tab in **Rapid Spanning Tree Protocol Dialog** to launch the **Rapid Spanning Tree Protocol —Port GE1/Port GE2 Dialog** as shown in Figure 6-59. Table 6-44 depicts the related parameters.

Figure 6-59 Trunk RSTP Setting- Port GE1/Port GE2 Dialog




Table 6-44 RSTP for Trunk Ports- Port GE1/Port GE2 Dialog Description

Field	Description	
RSTP Administrative State		
Administrative State	Enable or disable the RSTP function for GE ports.	
Version	This specifies the RSTP version the NE runs.	
Port GE 1 / Port GE 2 (Ta	b)	
Current Port ID	It specifies the GE1/GE2 port's port ID so far.	
Port Enable	The current RSTP enabled/disabled status of the port	
Port Priority	It specifies the port priority of a port. In the case that more than one ports form a loop in the NE, the RSTP/STP will block the ports of lower Port Priority (higher numerical value). Only the port of higher Port Priority (lower numerical value) is to be at the Forwarding state.  Its valid range is through 0 to 240 in steps of 16	
Path Cost	It specifies the contribution of this port to the path cost of paths towards the spanning tree root bridge. A port of higher speed should be configured with lower numerical value.  When set it to be "default", its value follows the definition of IEEE 802.1d Table 17-3.	
Edge Port	Check to let the port become edge port in spanning tree topology. An edge port on an RSTP switch will immediately transition to the forwarding state. However, the port will be a non-edge port if the NE receives RSTP BPDU on that port. And the port state and port role of the non-edge port will be determined by the RSTP hereafter.	
Point-to-Point Link	Select YES to force this port always be treated as if it is connected to a point-to-point link. Select NO to let this port be treated as having a shared media connection. AUTO indicates that this port is considered to have a point-to-point link if it is an aggregator and all of its members are aggregately, or if the MAC entity is configured for full duplex operation, either through auto-negotiation or by management means.	
Protocol Migration	Check to force this port to transmit RSTP BPDUs.	



When set Path Cost to be "default", its value follows the definition of IEEE 802.1d Table 17-3 as follows.

Link Speed	Recommended value		
<=100 Kb/s	200 000 000"	20 000 000-200 000 000	1-200 000 000
1 Mb/s	20 000 000ª	2 000 000-200 000 000	1-200 000 000
10 Mb/s	2 000 000ª	200 000-20 000 000	1-200 000 000
100 Mb/s	200 000ª	20 000-2 000 000	1-200 000 000
1 Gb/s	20 000	2 000-200 000	1-200 000 000
10 Gb/s	2 000	200-20 000	1-200 000 000
100 Gb/s	200	20-2 000	1-200 000 000
1 Tb/s	20	2-200	1-200 000 000
10 Tb/s	2	1-20	1-200 000 000

# **CoS Configuration**

In order for the NE to play the role of edge (boundary) node of a DiffServ domain, the NE supports the the configurable mapping among the following entities.

- IEEE 802.1p User Priority as configured in the VC-to-VLAN configuration.
- Queue (Traffic Class) on each uplink trunk GE port
- DiffServ Code Point (DSCP) of the IP frame to be forwarded via the uplink trunk GE port.

**User priority:** The IEEE 802.1p user priority is a label carried with the frame that communicates the requested priority to the next hop (bridge, router or end systems). Typically, the user priority is not modified in the intermediate hop. Thus, the user priority has end-to-end significance across bridged LANs.

**Queue (traffic class):** A bridge can be configured so that multiple queues are used to hold frames waiting to be transmitted on a given outbound port, in which case the traffic class is used to determine the relative priority of the queues. Whenever the bridge's physical port is configured as strict priority (SP), all waiting frames at a higher traffic class are transmitted before any waiting frames of a lower traffic class. As with access priority, traffic class is assigned by the bridge on the basis of incoming user priority.



Currently, the NE supports 8 traffic classes (queues) on its GE ports with the strict priority (SP) scheduling policy only.

**Differentiated Service Code Point (DSCP):** RFC 2474/2475 defines the DiffServ field, which replaces the Type of Service (ToS) field in the IPv4 header. It facilitates the network devices behind IP-DSLAM to fulfill the end-to-end QoS. Figure 6-60 shows the DiffServ field.

### Figure 6-60 DiffServ Field



The most significant six bits of DiffServ field are called DSCP. The network device classifies packets and marks them with appropriate DSCP value. According to these values, other network devices in the DiffServ domain can make decision for packets behavior and provide the Quality of Service properly.

A network device classify the priorities of traffic with 6 different levels, they are Express Forwarding (EF), Assured Forwarding Class 4 (AF4), Assured Forwarding Class 3 (AF3), Assured Forwarding Class 2 (AF2), Assured Forwarding Class 1 (AF1) and Best Effort (BE). These forwarding classes are represented by the first 3 bits of DSCP as shown in Table 6-45. Moreover, the network device differentiates three drop precedence in AF4~AF1 respectively into last 3 bits of DSCP, they are Low Drop Precedence, Medium Drop Precedence and High Drop Precedence.

Table 6-45 DSCP: DS3~DS5 Bit Representation

Decimal representation of bits DS5, DS4 and DS3	Description
7	For link layer and routing protocol keep alive.
6	For using for IP routing protocols.
5	Express Forwarding (EF)
4	Assured Forwarding Class 4 (AF4)
3	Assured Forwarding Class 3 (AF3)
2	Assured Forwarding Class 2 (AF2)
1	Assured Forwarding Class 1 (AF1)
0	Best Effort (BF)

**Expedited Forwarding:** The code point of EF is 101110, the packets marked with EF is to be transmitted with highest priority, lowest drop probability.

**Assured Forwarding:** Assured Forwarding PHB is suggested for applications that require a better reliability than the best-effort service. There are 4 classes of AF. Within Each AF class, there are 3 drop precedences. In case of congestion, the drop precedence of a packet determines the relative importance of the packet within the AF class. Table 6-46 indicates the relationship of the 4 AF class.

Table 6-46 DSCP Class Relationship

	Class			
Drop	AF1	AF2	AF3	AF4
Low Drop Probability	001010 (AF11)	010010 (AF21)	011010 (AF31)	100010 (AF41)
Medium Drop Probability	001100 (AF12)	010100 (AF22)	011100 (AF32)	100100 (AF42)
High Drop Probability	001110 (AF13)	010110 (AF23)	011110 (AF33)	100110 (AF43)

Follow the subsequent procedure to configure the Trunk CoS mapping.

Click Configuration  $\rightarrow$  Trunk  $\rightarrow$  CoS Mapping on **Main Menu** to open the **CoS Priority** – **Queue Mapping Dialog** as shown in Figure 6-61. Table 6-47depicts the related parameters.

[10.12.3.97] Upstream CoS Priority-Queue Mapping and DSCP Re-mapping 802.1p User Priority-CoS Queue Mapping and DSCP Re-mapping User Priority Queue (Traffic Class) DiffServ Code Point (DSCP) ▼ Best Effort • • Best Effort • 2 -Best Effort -4 -• Best Effort 5 • Best Effort • -Best Effort • • Best Effort -7 Best Effort • e 8 has the highest priority for packet transmission \* AFxy: Assured Forwarding, service class x, drop precedence y DSCP Re-mapping Administrative State Cancel

Figure 6-61 Trunk CoS Mapping and DSCP Re-mapping Dialog

Table 6-47 Trunk CoS Mapping and DSCP Re-mapping Dialog Description

Field	Description	
802.1p User Priority-CoS Queue Mapping and DSCP Re-mapping		
User Priority	This indicates the 802.1p user priority as configured in the VC-to-VLAN configuration	
Queue (Traffic Class)	Use this combo-box to set the mapping relation between each 802.1p and CoS queues on the uplink trunk GE port	
DiffServ Code Point (DSCP)	Use this combo-box to set the new DSCP value on the IP frame to be forwarded via the uplink trunk GE port.	
DSCP Re-mapping Administrative State		
Administrative State	Enable or disable the DSCP Re-mapping function.	

### Manual VLAN Setting

This section depicts the manual VLAN-member port setting procedure of GE1 and GE2. The operator needs to choose the VLAN between 1 and 4094 to apply to GE ports when the following cases hold.


- GE1 port and GE2 port on NC is configured as tagged-only mode. (See Section "Constructing the NE Objects")
- GE2 port is configured as a subtended port. (See "Figure 6-55 Trunk Port Configuration Dialog")

Follow the subsequent procedures to configure the related parameters.

- Step 1 Click Configuration → Trunk → Manual VLAN Setting on Main Menu to open the Manual VLAN Setting Dialog as shown in Figure 6-62. Table 6-48 depicts the related parameters.
- Step 2 Click the button to change its color to blue to make both the GE ports join as the member port of the VLAN in interest.
  For example, click the button positioned at the cross of the cloumn"10" and row "91-100" will make both the GE ports join as the member port of the VLAN of VLAN-

ID=100.

Figure 6-62 Manual VLAN Setting Dialog



## Table 6-48 Manual VLAN Setting Dialog Description

Leave

Field	Description	
VLAN List		
The combination of VLAN List column and VLAN List row specifies a VLAN.  For example, the button positioned at the cross of the cloumn"1" and row "101-110" indicates the VLAN of VLAN-ID=101.		
<b>Fuction Button</b>		
Join	The blue button indicates the both the GE ports are the member ports of VLAN in interest.	

ports of VLAN in interest.

The grey button indicates the both the GE ports are not the member

# **Chapter 7Connection Port Management**

This chapter describes data channel connection and access services filter control.

This chapter contains the following sections:

- VC-to-VLAN Connection Management
- Access Control List
- Multicast Service Management
- Multicast Service
- System Services Configuration

# **VC-to-VLAN Connection Management**


The VC-to-VLAN setting can easily define the multiple to one or one to one mapping; you can group different PVCs to a single VLAN ID as well as single PVC to one VLAN mapping. Figure 7-63 illustrates the basic principle for VLAN assignment in the DAS4 Series IP-DSLAM. As shown in Figure 7-63, the NE forwards five data flows, A~E, which may be either owned by the same subscriber or by different subscribers. It is noted that these data flows are conveyed in five individual ATM PVCs, and they are grouped into 3 individual VLANs.



The NE supports up to 8 PVCs per xDSL port.

The NE supports up to 4094 VLANs per system.

Figure 7-63 VC-to-VLAN Mapping Illustrate



According to IETF RFC2684, an IP packet is encapsulated in either bridged mode or routed mode. The VC-to-VLAN settings are similar but not the same in these two encapsulation modes. This section depicts their configuration procedures together.




The VC-to-VLAN configuration procedures are the same to both the ADSL port and SHDSL port.

Follow the subsequent procedure to manage your VC-to-VLAN connectivity on a specific xDSL port.

Step 1 Click Configuration → xDSL → VC-to-VLAN on Main Menu to open the xDSL VC-to-VLAN List Dialog as shown in Figure 7-64.

Figure 7-64 xDSL VC-to-VLAN List Dialog




Step 2 Click on the 'Add' button on the right hand side of Figure 7-64 to display the window (Figure 7-65) for adding new PVC and configuring the associated setting. Figure 7-65 ~ Figure 7-70 show the corresponding configuration dialogs in the RFC2684 bridged mode and routed mode. Click either one tab to launch the corresponding dialog to configure the parameters. Table 7-49 depicts the related configuration parameters




According to IETF RFC2684, an IP packet is encapsulated in either bridged mode or routed mode. The VC-to-VLAN settings are similar but not the same in these two encapsulation modes.

Figure 7-65 xDSL VC-to-VLAN Setting – IP Traffic Dialog



(a) IP Traffic Dialog in RFC2684 bridged mode



(b) IP Traffic Dialog in RFC2684 routed mode

Figure 7-66 xDSL VC-to-VLAN Setting – 802.1Q/1P Dialog (only for the RFC2684 bridged mode)




Figure 7-67 xDSL VC-to-VLAN Setting – 802.1P Dialog (only for the RFC2684 routed mode)




Figure 7-68 xDSL VC-to-VLAN Setting – MAC Limit Dialog (only for the RFC2684 bridged mode)




Figure 7-69 xDSL VC-to-VLAN Setting – Next-hop Dialog (only for the RFC2684 routed mode)






Figure 7-70 xDSL VC-to-VLAN Setting – Service Type Dialog




(a) PPPoE service in RFC2684 bridged mode





(c) Static IP service in RFC2684 bridged mode



(d) Static IP service in RFC2684 routed mode

Table 7-49 xDSL VC-to-VLAN Setting Description

Field	Description		
Virtual Channel	Virtual Channel		
Shelf, Slot, Port	This specifies the shelf-slot-port.		
VPI	It specifies the VPI value		
VCI	It specifies the VCI value		
Administrative State	It specifies the state of this VC-VLAN to enable or disable.		
RFC2684 Mode	It specifies the RFC 2684 mode, (Bridge or Route)		
IP Traffic Profile Dialog			
IP Traffic Profile	This specifies the IP traffic profile		
802.1Q/1P Dialog [only for	RFC2684 bridged mode]		
VLAN ID	This specifies the VLAN ID value		
User Priority	This specifies the VLAN priority		
802.1P Dialog [only for RF	C2684 routed mode]		
User Priority	This specifies the VLAN priority of corresponding VC-to-VLAN connection.		
Next-hopDialog [only for F	RFC2684 routed mode]		
Next-hop name	It specifies the next-hop name as specified in the section 'ISP Information for IP over ATM' of Chapter 7.		
MAC Limit Dialog [only for	or RFC2684 bridged mode]		
MAC Count	This specifies the number of subscriber's MACs allowed for the corresponding VC-to-VLAN connection.		
Service Type Dialog			
Service Type	This specifies the service type to be allowed on the PVC of individual subscriber.		
	In RFC2684 routed mode, the following service type is supported.		
	• Static IP		
	In RFC2684 bridged mode, the following three service types are supported.		
	• PPPoE		
	• DHCP		
Maximum IP Count	Static IP  This indicates the number of IP to be allowed while DHCP is		
[only for DHCP Service]	selected		
Continuous IP Count	This indicates the number of IP to be allowed while Static IP is		
[only for Static IP Service]	selected		
Static IP's Basic Address	This specifies the base of the IP address if the service type is Static		
[only for Static IP Service]	IP		



Enabling the Service Type Control makes the NE to provide the IP/MAC anti spoofing function. In the case that the subscriber acquires his IP address dynamically via PPPoE or DHCP, the NE will block the subscriber's traffic before a valid IP address assigning. Once the subscriber possesses a valid dynamic or static IP, the NE will just forward the packet of valid source IP/MAC addresses. IN other words, the NE drops the subscriber's traffic of invalid source IP/MAC addresses.




Whenever the service type is specified as "Static IP Service", it is noted that the following relationship should be maintained.

IP Address Increment/Port ≥ Continuous IP Count

#### ISP Information for IP over ATM

In the RFC 2684 routed mode, IP packets are directly encapsulated, i.e., no MAC layer is presented. Through the IWF (Inter-Work Function) of IPoA of IP-DSLAM, it needs to append the Ethernet MAC layer for particular subscriber interface, the source MAC address is specially generate by IP-DSLAM, and the destination MAC address is the next-hop router toward the ISP's router. The NE determines the MAC address of next-hop router by the (Address Resolution Protocol (ARP). Figure 7-71 illustrates an example of the IWF in the case of RFC 2684 routed mode.

Figure 7-71 RFC 2684 Route Mode Connection Method



Follow the subsequent procedure to launch the ISP Information dialog to resolve the MAC address by just specifying the Next-hop's IP address.

Step 1 Click Configuration → xDSL → Next-hop Info for IP over ATM on Main Menu to open the Next-hop Info for IP over ATM Dialog as shown in Figure 7-72 and Table 7-50 depicts the related parameters.

Figure 7-72 xDSL Next-hop List for IPoA Dialog




Table 7-50 xDSL Next-hop List for IPoA Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Table.
Next-hop Name	It specifies the Next-hop name.
Next-hop IP	It specifies the Next-hop router IP.
VLAN	It specifies the VLAN grouping number for Next-hop connection.
MAC Address	It specifies the MAC address of the next-hop router toward the ISP's router.
<b>Function Button</b>	
Add	Click this button to add a new Next-hop entry
Delete	Click this button to remove the Next-hop entry
Refresh	Click this button to refresh the List Table
Export	Click this button to save the contents of <b>xDSL Next-hop List for IPoA</b> to the Personal Computer.
Close	Exit the xDSL Next-hop List for IPoA Dialog.

Step 2 Click 'Add' button to launch the xDSL Next-hop for IPoA Dialog. Figure 7-73 shows xDSL Next-hop for IPoA Dialog, and Table 7-51 depicts the related parameters.

Figure 7-73 Add xDSL Next-hop for IPoA Dialog




Table 7-51 Add xDSL Next-hop for IPoA Dialog Description

Field	Description
Next-hop Information	
Name	This specifies the Next-hop name.
IP Address	This specifies the Next-hop router IP.
VLAN ID	This specifies the VLAN grouping number for Next-hop connection.

## **Access Control List**

The NE supports packet filtering functions allows you to forward or drop subscriber traffics received on the subscriber interfaces.

- NetBIOS/NetBEUI Packet Filtering
- Source MAC Access Control List

## **NetBIOS/NetBEUI Packet Filtering**

The NE allows the operator to configure to forward or drop the name server protocol (NetBIOS and NetBEUI) traffics received on the subscriber interfaces.

Follow the subsequent procedures to configure the related parameters.

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  Packet Filter on **Main Menu** to open the **Packet Filtering** Dialog as shown in Figure 7-74 and Table 7-52 depicts the related parameters.

Figure 7-74 Packet Filtering Dialog



Table 7-52 Packet Filtering Dialog Description

Field	Description
Packet Filtering Setting	
NetBIOS/NetBEUI	Set the packet filtering function to "forward" or "drop" for NetBIOS and NetBEUI packets.

### Source MAC Access Control List

- Step 1 Click Configuration → xDSL → VC-to-VLAN on Main Menu to open the xDSL VC-to-VLAN List Dialog as shown in Figure 7-64.
- Step 2 Select a port in VC to VLAN List dialog and click "ACL" button on the right hand side of Figure 7-64 to configure the Access Control List option of the selected port. Figure 7-75 illustrated the VC-to-VLAN Access Control List dialog, and Table 7-53 depicts the related parameters. Figure 7-76 illustrated the window for adding new MAC

into the access control list.

Figure 7-75 VC-to-VLAN Access Control List dialog




Table 7-53 VC-to-VLAN Access Control List Dialog Description

Field	Description		
xDSL PVC			
PVC	This indicates the specified xDSL port and specified PVC.		
<b>Current Control State</b>			
State	This indicates the current access control state of the specified PVC.		
Controlled Source MAC List			
Source MAC Address	This indicates the MAC address under controlling.		
Function Button	Function Button		
Add	Click this button to add or modify the role of access control.		
Delete	Click this button to delete the specified access control entry.		
Refresh	Click this button to refresh the access control state.		
Close	Exit the Access Control List Dialog.		

Step 3 Click 'Add' button to launch the xDSL Access Control Dialog. Figure 7-76 shows the xDSL Access Control Dialog, and Table 7-54 depicts the related parameters.

Figure 7-76 Add xDSL Access Control Dialog



Table 7-54 Add xDSL Access Control Dialog Description

Field	Description
Control State (Add)	
Current State	This indicates the current access control state of the specified PVC.
New State	Check the radio button to select the role of new state.
Controlled Source MAC Address (Add)	
MAC Address (Hex)	This specifies the MAC address under controlling.



The roles of access control function, Deny and Permit, are repulsive, i.e. a "deny" role will be replaced while a new role "permit" is be configured.

Users can review the access control list from the menu combo-box. Follow the subsequent procedures to review the access control list configuration.

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  Access Control List on **Main Menu** to open the **xDSL Access Control List** Dialog as shown in Figure 7-77 and Table 7-55 depicts the related parameters.

Figure 7-77 xDSL Access Control List




Table 7-55 xDSL Access Control List Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the access control list.
Slot-Port	This indicates the location of xDSL port.
VPI	This indicates the VPI of the specified xDSL subscriber.
VCI	This indicates the VCI of the specified xDSL subscriber.
Control State	This indicates the control state of access control of the specified xDSL subscriber.
Source MAC Address	This indicates the source MAC address which is under controlling of the specified xDSL subscriber.
<b>Function Button</b>	
Modify	Click this button to open the VC-to-VLAN Access Control List.
Export	Click this button to save the contents of <b>xDSL Access Control List</b> to the Personal Computer.
Close	Exit the xDSL Access Control List Dialog.

# **Multicast Service Management**

To provide multicast service, the operator needs to properly configure the multicast channel and IGMP snooping /IGMP proxy. This section contains the following two subsections.

- Multicast Channel Configuration
- IGMP snooping/IGMP proxy Configuration

## **Multicast Channel Configuration**

To forward the multicast stream, you are required to establish a VC-to-VLAN tunnel and specify the associated multicast service profile.

Follow the subsequent procedures to configure the related parameters.

- Step 1 Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  Multicast Service on Main Menu to open the xDSL Multicast Channel Dialog.
- Step 2 Click on the 'Modify' or 'Add' button on the right hand side of Figure 7-78 to open the window (Figure 7-79) for adding new multicast channel and configure the associated setting.

In Figure 7-79, it is noted that two individual tabs (Multicast Service Profile and MAC Limit) are provided to set the Multicast Channel related parameters. Click either one **tab** to launch the corresponding dialog to configure the parameters. Table 7-56 depicts the related parameters

Figure 7-78 xDSL Multicast Channel List Dialog




Figure 7-79 xDSL Multicast Channel Setting Dialog




Table 7-56 xDSL Multicast Channel Setting Description

Field	Description	
Ethernet over ATM		
Shelf, Slot, Port	This specifies the physical connection information.	
VPI	This specifies the VPI values.	
VCI	This specifies the VCI values.	
VLAN ID	This specifies the multicast VLAN ID.	
Administrative State	Enable: Apply the specified multicast setting to the indicated PVC Disable: Do not apply specified multicast setting to the indicated PVC	
<b>Multicast Service Profile 1</b>	Dialog	
Profile	This specifies the multicast service profile. Please refer to the section "Multicast Service Profile" in 5.	
Channel Limit Dialog		
Channel Limit	This specifies the allowed number of multicast streams to be forwarded via the VC-to-VLAN connection.	

# IGMP snooping/IGMP proxy Configuration

Follow the subsequent procedures to configure the IGMP snooping and IGMP proxy related parameters.

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  IGMP Snooping / Proxy on **Main Menu** to open the **IGMP Snooping** / **IGMP Proxy Setting** Dialog as shown in Figure 7-80 and Table 7-57 depicts the related parameters.

Figure 7-80 IGMP Snooping / IGMP Proxy Setting Dialog




Table 7-57 IGMP Proxy Setting Dialog Description

Field	Description	
IGMP Snooping / IGMP Proxy Setting		
Disable IGMP snooping and IGMP proxy	This disables the IGMP Snooping and Proxy functionality. (Default)	
Enable IGMP Snooping	This enables the IGMP Snooping functionality.	
Enable IGMP Proxy	This enables the IGMP Proxy functionality.	
IGMP Snooping MAC Aging		
Aging Time	This specifies the aging time of snooped legal multicast group MAC address.	
IGMP Proxy Setting		
Robustness (Query Retry)	This specifies the IGMP Robustness retry times. Available value is $1 \sim 5$ (times).	
Query Response Interval	This specifies the period between the NE send 2 consecutive IGM queries to the xDSL subscriber. Available value is $1\sim30$ (seconds).	
Immediate Leave	This specifies the immediate leave.	

# **System Services Configuration**

The system services configuration covers the following settings.

- MAC Aging for Bridged Services
- VLAN MAC Limit
- •
- PPPoE Sub-option Configuration
- xDSL Port Agent ID

# **MAC Aging for Bridged Services**

The MAC aging time sets the lifetime for the learned MAC address. A specific MAC address will be dropped when aging out until it get learning again. Disable this function will keep the learned MAC addresses permanent in the learning table.

Click Configuration →NE Mangement → MAC Aging on **Main Menu** to open the **MAC Aging** Dialog as shown in Figure 7-81 and Table 7-58 depicts the related parameters.

Figure 7-81 MAC Aging Setting Dialog




Table 7-58 MAC Aging Setting Dialog Description

Field	Description
Unicast MAC Aging	
Aging Time (seconds)	This specifies the MAC aging time. Default value is 300 seconds. The valid range: 10 ~ 1000.

## **VLAN MAC Limit**

To limit the number of source MAC address learned in a specific VLAN, the users can enable the MAC limiting function and configure the upper limit of allowed MAC for a specific VLAN.

Step 1 Click Configuration → xDSL → VLAN MAC Limit on Main Menu to open the VLAN MAC Limit Dialog as shown in Figure 7-82 and Table 7-59 depicts the related parameters.

Figure 7-82 VLAN MAC Limit List Dialog




Table 7-59 VLAN MAC Limit List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Table.
VLAN ID	It specifies the VLAN.
Admin State	It specifies the administrative state.
MAC Limit	It specifies the number of MACs allowed for the corresponding VC-to-VLAN connection.
VLAN ID Range	
Range	Specify the range of VLAN ID as indicated by the red rectangle.
<b>Function Button</b>	
Modify	Click this button to open the MAC limit configure dialog.
Export	Click this button to save the contents of <b>VLAN MAC Limit List</b> to the Personal Computer.
Close	Exit the VLAN MAC Limit List Dialog.
Refresh	Click this button to display the List Table with configured VLAN ID range.

Step 2 Click 'Modify' button to launch the VLAN MAC Limit Configure Dialog. Figure 7-83 shows VLAN MAC Limit Configure Dialog, and Table 7-60 depicts the related parameters.

Figure 7-83 VLAN MAC Limit Configure Dialog




Table 7-60 VLAN MAC Limit Setting Dialog Description

Field	Description
MAC Limit ( Modify)	
VLAN ID	It specifies the VLAN.
Administrative State	Enable or disable the MAC limit function. Default state is "disable".
MAC Limit	This specifies the number of MAC allowed for the VLAN, from 5 $\sim$ 50000. Default value is 12288.

# **DHCP Service Configuration**

Four dialogs are related to the DHCP Service Configuration.

- DHCP Setting
- DHCP Server List for DHCP Relay
- DHCP Broadcast Control

### **DHCP Setting**

The DHCP relay intercepts the DHCP request packets from subscriber interface and forwards them to the specified DHCP server. In the opposite direction, the DHCP relay transfers the DHCP reply packets from DHCP server to the specified xDSL subscriber.



The setting of DHCP option 82 contents is performed by configuring the xDSL Port Agent ID

Follow the subsequent procedures to configure the related parameters.

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  DHCP  $\rightarrow$  DHCP Setting on **Main Menu** to open the **DHCP Setting** Dialog as shown in Figure 7-84 and Table 7-61 depicts the related parameters.

### Figure 7-84 DHCP Setting Dialog



### Table 7-61 DHCP Setting Dialog Description

Field	Description
DHCP Relay	Enable or disable the DHCP Relay function.
DHCP Option82	Enable or disable the DHCP option 82 function.  Enable: The relayed DHCP packet is to be appended with the configured DHCP option 82 information as specified in the xDSL Port Agent ID List

### **DHCP Server List for DHCP Relay**

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  DHCP  $\rightarrow$  DHCP Server for DHCP Relay on **Main Menu** to open the **DHCP Server List for DHCP Relay** Dialog as shown in Figure 7-85 and Table 7-62 depicts the related parameters.

Figure 7-85 DHCP Server List for DHCP Relay Dialog




Table 7-62 DHCP Server List for DHCP Relay Dialog Description

Field	Description
Table List	
No.	This indicates the serial number of entry of the List.
Server IP	This specifies the DHCP server IP address.
<b>Function Button</b>	
Add	Click this button to add a new DHCP server IP address.
Delete	Click this button to delete a specified DHCP server.
Export	Click this button to save the contents of <b>DHCP Server List</b> to the Personal Computer.
Close	Exit the DHCP Server List for DHCP Relay table dialog.

#### **DHCP Broadcast Control**

Users can set the DHCP broadcast packet rate limit and set the action applied to the out-of-profile traffic.

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  DHCP  $\rightarrow$  DHCP Broadcast Control on **Main Menu** to open the **DHCP Broadcast Control s** Dialog as shown in Figure 7-86. Table 7-63 depicts the related parameters.

Figure 7-86 DHCP Broadcast Control Dialog




Table 7-63 DHCP Broadcast Control Dialog - Description

Field	Description
Rate Limit	
Admin State	Enable or disable the DHCP broadcast control. The default setting is "disable".
Rate Limit	This specifies the rate limit based on packets per second. Available value is $1 \sim 100000$ (packet per second). Default value is 100 packets per second.
Action to Violation	This specifies the action to be taken for the packets over the limit. "No action", "Drop packet", "Send alarm" and "Drop packet and send alarm".



When the action is set to be either "Send alarm" and "Drop packet and send alarm", the NE will launch SNMP traps to the SNMP trap managers as specified in the section "Configuring the SNMP Trap Manager" in Chap 4.

## **PPPoE Sub-option Configuration**

PPPoE sub-option has similar mechanism as DHCP option 82. The NE can insert Circuit ID and Remote ID in all upstream PPPoE discovery stage packets, i.e. the PADI, PADR and upstream PADT packets. Figure 7-87 illustrates the enable/disable window for this functionality.



The setting of PPPoE sub-option contents is performed by configuring the xDSL Port Agent ID

Follow the subsequent procedures to configure the related parameters.

Click Configuration  $\rightarrow$  xDSL  $\rightarrow$  PPPoE on **Main Menu** to open the **PPPoE setting** Dialog as shown in Figure 7-87 and Table 7-64 depicts the related parameters.

Figure 7-87 PPPoE Sub-option Setting Dialog



Table 7-64 PPPoE Sub-option Setting Dialog Description

Field	Description
Administrative State	
PPPoE Sub-option 1 & 2	Enable or disable the PPPoE sub-option function.  Enable: The relayed PPPoE packet is to be appended with the configured PPPoE Sub-option 1 &2 information as specified in the xDSL Port Agent ID List  Default value is "Disable".

### **xDSL Port Agent ID Management**

The xDSL Port Agent ID List keeps the Agent Circuit ID (intended for circuits terminated by the system hosting the Relay agent) and Agent Remote ID (intended to identify the remote host end of a circuit). The NE allows the operator to specify Agent Remote ID with an ASCII string of up to 63 characters. As to the Agent Circuit ID, it is not permitted to be modified. The format of Agent Circuit ID is as follows.

"NE-InbandIP-userSrcMAC atm slot-port:VPI.VCI"

Here is one example Agent Circuit ID

"IP\_DSLAM-100.168.3.97-00:11:d8:80:93:23 atm 3-1:100.33",

which represents

NE's inband IP=100.168.3.97,

MAC address of subscriber's personal computer (or the CPE)= 00:11:d8:80:93:23, slot = 3, port = 1, vpi = 100, vci = 33.



xDSL Port Agent ID is to be inserted into either all upstream DHCP messages sent by the client and all upstream PPPoE discovery stage packets

Follow the subsequent procedures to configure the xDSL Port Agent ID.

- Step 1 Click Configuration → xDSL → Port Agent ID on Main Menu to open the xDSL Port Agent IDs Dialog as shown in Figure 7-88 and Table 7-65 depicts the related parameters. To modify the
- Step 2 Click and highlight a row and click 'Modify' button to modify the Agent Remote ID.






Table 7-65 xDSL Port Agent IDs Dialog Description

Field	Description
Table List	
No,	This indicates the number of Table List.
Slot-Port	This indicates the slot-port address.
Agent Circuit ID	This indicates the agent circuit ID of the specified xDSL subscriber. Its format is as follows.  "NE-InbandIP-userSrcMAC atm slot-port:VPI.VCI"
Agent Remote ID	This indicates the agent remote ID of the specified xDSL subscriber.  It is an ASCII string of up to 63 characters.
<b>Function Button</b>	
Modify	Click this button to modify the selected xDSL port's agent ID.
Export	Click this button to save the contents of <b>xDSL Port Agent ID List</b> to the Personal Computer.
Close	Exit the <b>xDSL Port Agent ID List</b> Dialog.

# **Chapter 8Fast Provision Management**

This chapter describes the Fast Provision function. Through this function, you are able to efficiently apply the profiles to a mass of xDSL subscriber ports.

This chapter contains the following sections:

- Interface and VC-VLAN Fast Provisioning
- Multicast Service Fast Provisioning

# Interface and VC-VLAN Fast Provisioning

The AMS LCT provides a fast provision function that helps you to build-up the principal connection setting of interface ports in fast and efficient way. Through this function, you can apply the profile and VC-to-VLAN setting to a mass of xDSL subscriber interfaces simultaneously, instead of configuring the individual subscriber interfaces one by one.

Follow the subsequent procedure to configure the interface fast provision.

Step 1 Click Configuration → xDSL → Fast Provision → Port & VC-to-VLAN on Main Menu to open the xDSL Port & VC-to-VLAN Fast Provision Dialog as shown in Figure 8-89.

Note that the configuration tabs are not exact the same for the RFC2684 bridged mode and routed mode. Figure  $8-89 \sim \text{Figure } 8-95 \text{ show}$  the corresponding configuration dialogs. Click either one tab to launch the corresponding dialog to configure the parameters. As to the description of the configuration parameters, please refer to Table 8-66.



It is noted that the configuration dialog may be different between the RFC2684 bridged mode and routed mode. If the configuration dialogs are the same for both the bridged mode and routed mode, Figure 8-89 ~ Figure 8-95only show the ones in the bridged mode without any additional description. Otherwise, Figure 8-89 ~ Figure 8-95show the configuration dialogs with description to indicate it. The rule of description also applies to Table 8-66.

Figure 8-89 xDSL Port & VC-to-VLAN Fast Provision – Port Setting Dialog







Figure 8-90 xDSL Port & VC-to-VLAN Fast Provision – Channel Setting Dialog







(b) Channel setting in RFC2684 routed mode

Figure 8-91 xDSL Port & VC-to-VLAN Fast Provision – IP Traffic Dialog




Figure 8-92 xDSL Port & VC-to-VLAN Fast Provision – MAC Limit Dialog (only for the RFC2684 bridged mode)




Figure 8-93 xDSL Port & VC-to-VLAN Fast Provision – Next-hop Dialog (only for the RFC2684 routed mode)




Figure 8-94 xDSL Port & VC-to-VLAN Fast Provision – 802.1P Dialog






Figure 8-95 xDSL Port & VC-to-VLAN Fast Provision – Service Type Dialog




(a) PPPoE service in RFC2684 bridged mode

(b) DHCP service in RFC2684 bridged mode

[10.12.3.132] xDSL Fort && VC-to-VLAN Fast Provision



(c) Static IP service in RFC2684 bridged mode



(d) Static IP service in RFC2684 routed mode

Table 8-66 xDSL Port & VC-to-VLAN Fast Provision Description

Field	Description
Module Criteria	
Shelf	This specifies the location of shelf. It is obsolete in the current release.
Slot	It specifies the location of the line card.
Type	It specifies the board type of line card.
RFC2684 Mode	It specifies the RFC 2684 encapsulation mode (Bridged or Routed mode)
Port Setting Dialog	
Admin State	It specifies the administrative state. (enable or disable)
Line Profile	It specifies the line profile. (xDSL Profile)
PM Threshold	It specifies the PM threshold profile.
Traffic Policing	It specifies the Traffic Policing profile. [Only for the ADSL port]
Channel Setting Dialog Start – Identify the number of start Increment – Identify the number to	ting value. b be increment if more then one <b>PVCs / Port</b> is defined.
Admin State	It specifies the administrative state. (enable or disable)
VPI (Start, Increment)	It specifies the VPI value of PVCs.
VCI (Start, Increment)	It specifies the VCI value of PVCs.
VLAN ID (Start, Increment)	It specifies the VLAN ID value of corresponding VC-to-VLAN connections.
PVCs / Port	It specifies the number of PVCs to be applied to each xDSL port.
VLAN ID is continuous among port	Check to sequentially increase the VLAN ID values to be assigned to the PVCs.
IP Traffic Profile Dialog	
IP Traffic Profile	This specifies the IP Traffic Profile of corresponding VC-to-VLAN connection.
802.1P Dialog	
User Priority	This specifies the VLAN priority of corresponding VC-to-VLAN connection.
Next-hop Dialog [only for	RFC2684 routed mode]
Next-hop Name	It specifies the next-hop name as specified in the section 'ISP Information for IP over ATM' of Chapter 7.
MAC Limit Dialog [only f	or RFC2684 bridged mode]
MAC Count	It specifies the number of subscriber's MACs allowed for the corresponding VC-to-VLAN connection.

Table 8-1 xDSL Port & VC-to-VLAN Fast Provision Description (Continued)

Field	Description
Service Type Dialog	
Service Type	This specifies the service type to be allowed on the PVC of individual subscriber. The following three service types are supported now.  PPPoE DHCP Static IP
Maximum IP Count [only for DHCP Service]	This indicates the number of IP to be allowed while DHCP is selected
Continuous IP Count [only for Static IP Service]	This indicates the number of IP to be allowed while Static IP is selected
Static IP's Basic Address [only for Static IP Service]	This specifies the base of the IP address if the service type is Static IP
IP Address Increment/Port [only for Static IP Service]	This indicates the increment of IP address between two consecutive ports while Static IP is selected and Continuous IP Count is greater than 1.



Whenever the service type is specified as "Static IP Service", it is noted that the following relationship should be maintained.

IP Address Increment/Port ≥ Continuous IP Count




Enabling the Service Type Control makes the NE to provide the IP/MAC anti spoofing function. In the case that the subscriber acquires his IP address dynamically via PPPoE or DHCP, the NE will block the subscriber's traffic before a valid IP address assignment. Once the subscriber possesses a valid dynamic or static IP, the NE will just forward the packet of valid source IP/MAC addresses. In other words, the NE drops the subscriber's traffic of invalid source IP/MAC addresses.

Step 2 Click 'List' button to launch the xDSL Fast Provision List dialog. Figure 8-96 summarizes what you set via the xDSL Port & VC-to-VLAN Fast Provision dialog. As shown in Figure 8-96, it depicts the list of subscriber ports you wish to apply to. If you do no want to apply the setting to any port or PVC, just remove it from the List Table by clearing the corresponding check-box.


Table 8-67 depicts the related parameters.

Step 3 Click 'Go' button to apply the given setting to all ports in the List Table. The checks are removed when the setting is successfully applied. Click 'Stop' to stop the fast provisioning immediately if you want.

Figure 8-96 xDSL Fast Provision List Dialog



(a) List Dialog in the RFC2684 bridged mode



(b) List Dialog in the RFC2684 routed mode

Table 8-67 xDSL Fast Provision List Dialog Description

Field	Description
Condition  Port Setting – Check to allow the correspondent setting to be applied to the ports in List Table.  VC-to-VLAN – Check to allow the correspondent setting to be applied to the ports in List Table.	
Administrative State	This specifies the administrative state. (enable or disable)
Line Profile	This specifies the line profile. (xDSL Profile)
PM Threshold Profile	This specifies the PM threshold profile.
Traffic Policing Profile	This specifies the Traffic Policing profile. [Only for the ADSL port]
Encapsulation Mode	This specifies the RFC2684 encapsulation mode of corresponding PVC.
User Priority	This specifies the VLAN priority of corresponding VC-to-VLAN connection.
IP Traffic Profile	This specifies the IP traffic profile of corresponding VC-to-VLAN connection.
MAC Count Limit	It specifies the number of subscriber's MACs allowed for the corresponding VC-to-VLAN connection. [only for RFC2684 bridged mode]
Service Type	This specifies the service type of corresponding VC-to-VLAN connection. The following three service types are supported now.  PPPoE DHCP Static IP
List Table	
No.	This indicates the serial number of entry of the List Table.
Slot-Port	This specifies the location of subscriber port.
VPI	This specifies the VPI value of PVC.
VCI	This specifies the VCI value of PVC.
VLAN / Next-hop	This specifies the VLAN ID (in RFC2684 bridged mode) or Nexthop name (in RFC2684 routed mode) of corresponding VC-to-VLAN connection.
Base IP / Count	This specifies the IP Base address and count of IP address of corresponding VC-to-VLAN connection. It applies whenever the Service Type Control is enabled and Static IP or DHCP is selected
Function Button	
Go	Click this button to start fast provisioning.
Stop	Click this button to force the fast provision terminating.
Export	Click this button to save the contents of <b>xDSL Fast Provision List</b> to the Personal Computer.
Close	Exit this <b>xDSL Fast Provision List</b> Dialog.

# **Multicast Service Fast Provisioning**

The multicast service fast provision function helps you to build-up the multicast connection and the associated service profile efficiently.

Follow the subsequent procedures to configure the multicast service fast provision.

Step 1 Click Configuration → xDSL → Fast Provision → Multicast Channel on Main Menu to open the xDSL Multicast Channel Fast Provision Dialog, as shown in Figure 8-97

and Table 8-68 depicts the related parameters.

In Figure 8-97, it is noted that two individual tabs (Multicast Service Profile and Channel Limit) are provides to set the Multicast Service Fast Provision related parameters. Figure 8-97 ~ Figure 8-98 show the corresponding configuration Dialog. Click either one tab to launch the corresponding dialog to configure the parameters. As to the description of the configuration parameters, please refer to Table 8-68.

Figure 8-97 xDSL Multicast Channel Fast Provision – Multicast Service Profile Dialog




Figure 8-98 xDSL Multicast Channel Fast Provision – Channel Limit Dialog




Table 8-68 xDSL Multicast Channel Fast Provision Description

Field	Description	
<b>Ethernet over ATM</b>		
Shelf	This specifies the shelf ID.	
Slot	It specifies the slot range.	
Туре	It specifies the LC board type.	
VPI	It specifies the VPI value.	
VCI	It specifies the VCI value.	
VLAN ID	It specifies the VLAN ID value.	
Admin State	Enable: Apply the specified multicast setting to the indicated PVCs Disable: Do not apply specified multicast setting to the indicated PVCs	
Multicast Service Profile Dialog		
Show – Click this button to display the details of multicast service profile collocated.		
Profile	It specifies the Multicast Service Profile	
Channel Limit Dialog		
Channel Limit	This specifies the allowed number of concurrent multicast streams to be forwarded via each VC-to-VLAN connection.	

Step 2 Click 'List' button to launch the xDSL Multicast Channel Fast Provision List dialog. Figure 8-99 summarizes what you set via the xDSL Multicast Channel Fast Provision dialog. As shown in Figure 8-99, it depicts the list of subscriber ports you wish to apply to. If you do not want to apply the setting to any port in the list table, just clear the corresponding check-box

Table 8-69 depicts the related parameters.

Step 3 Click 'Go' button to apply the given setting to all ports listing in the List Table. The checks are removed when the setting is successfully applied. Click 'Stop' to stop the fast provision immediately if you want.

Figure 8-99 xDSL Multicast Channel Fast Provision List Dialog




Table 8-69 xDSL Multicast Channel Fast Provision List Dialog Description

Field	Description
Condition	
VPI / VCI	This specifies the VPI / VCI value of corresponding PVC.
VLAN ID	This specifies the VLAN ID value of corresponding VC-to-VLAN connection.
Administrative State	Enable: Apply the specified multicast setting to the indicated PVCs Disable: Do not apply specified multicast setting to the indicated PVCs
Channel Limit	This specifies the allowed number of multicast streams to be forwarded via each VC-to-VLAN connection.
Multicast Service Profile	This specifies the multicast service profile.
List Table	
No.	This indicates the serial number of entry of the List Table.
Slot-Port	This specifies the location of subscriber port.
Function Button	
Go	Click this button to start fast provisioning.
Select All	Click this button to select all rows from List Table.
Deselect All	Click this button to deselect all rows from List Table
Stop	Click this button to force the fast provision terminating.
Export	Click this button to save the contents of <b>xDSL Multicast Channel Fast Provision List</b> to the Personal Computer.
Close	Exit the xDSL Multicast Channel Fast Provision List Dialog.

# **Chapter 9Performance Management**

This chapter describes system performance monitoring and related management.

This chapter contains the following sections:

- xDSL Line Current Performance Information
- xDSL Line Historical Performance Information
- GE Interface Performance Statistics

#### **xDSL Line Current Performance Information**

Follow the subsequent procedure to obtain data for evaluating the current xDSL line performance.

- Step 1 Click Performance → xDSL Current PM on Main Menu to open the xDSL Current PM Port Selection Dialog as shown in Figure 9-100.
- Step 2 Select the port you want to show and press Query button to get the current PM data. Depending on the type of selected port, the current PM dialog looks different. Figure 9-101 shows the ADSL Current PM Dialog. The corresponding descriptions are depicted in Table 9-70. As to the SHDSL Current PM Dialog, it is shown in Figure 9-102. The corresponding descriptions are depicted in Table 9-71.

Figure 9-100 xDSL Current PM Port Selection




Figure 9-101 ADSL Current PM Dialog




Table 9-70 ADSL Current PM Dialog Description

Field	Description
List Table	
Time Interval	This indicates the PM time interval
Side	This indicates the location where the PM parameters are observed. (Either central side (CO) or remote side (RT))
LOSs	This indicates the count of Loss of Signal Second during the current accumulated period.
ESs	This indicates the count of Error Second during the current accumulated period.
SESs	This indicates the count of Severely Error Second during the current accumulated period.
UASs	This indicates the count of Unavailable Error Second during the current accumulated period.
Tx Cells / Rate (Kbps)	This indicates the transmitted number of ATM cells and net data rate during the current accumulated period.
Rx Cell / Rate (Kbps)	This indicates the received number of ATM cells and net data rate during the current accumulated period.
CVs	This indicates the count of Code Violation during the current accumulated period.
FullInits	This indicates the count of the total number of full initializations attempted on the line (successful and failed) during the current accumulated period.
FailedInits	This indicates the total number of failed full initializations during the current accumulated period.  A failed full initialization is when showtime is not reached at the end of the full initialization procedure, e.g., when:  • A CRC error is detected.  • A time-out occurs.  • Unexpected message content is received.
TxBlks	This indicates the transmitted number of FEC block during the current accumulated period.
RxBlks	This indicates the received number of FEC block during the current accumulated period.
CrtBlks	This indicates the count of all blocks received with errors that were corrected during the current accumulated period.
UncrtBlks	This indicates the count of all blocks received with uncorrectable errors during the current accumulated period.
<b>Function Button</b>	•
Refresh	Click this button to refresh the List Table
Graph	Click this button to draw the 2D/3D diagram
Export	Click this button to save the contents of <b>ADSL Current PM List</b> to the Personal Computer.
Close	Exit the ADSL Current PM Dialog.

Figure 9-102 SHDSL Current PM Dialog




Table 9-71 SHDSL Current PM Dialog Description

Field	Description
List Table	
Time Interval	This indicates the PM time interval
Side	This indicates the location where the PM parameters are observed. (Either central side (CO) or remote side (RT))
ESs	This indicates the count of Error Second during the current accumulated period.
SESs	This indicates the count of Severely Error Second during the current accumulated period.
UASs	This indicates the count of Unavailable Error Second during the current accumulated period.
LOSWs	This indicates the count of LOSW second during the current accumulated period.
CRCs	This indicates the count of the SHDSL CRC anomalies occurring during the current accumulation period.
Function Button	
Refresh	Click this button to refresh the List Table
Graph	Click this button to draw the 2D/3D diagram
Export	Click this button to save the contents of <b>SHDSL Current PM List</b> to the Personal Computer.
Close	Exit the SHDSL Current PM Dialog.

#### **xDSL Line Historical Performance Information**

Follow the subsequent procedure to obtain data for evaluating the history xDSL line performance.

- Step 1 Click Performance → xDSL History PM on Main Menu to open the xDSL History PM Port Selection Dialog as shown in Figure 9-103.
- Step 2 Select the port you want to show and press Query button to get the historical PM data. Depending on the type of selected port, the historical PM dialog looks different. Figure 9-104 shows the ADSL History PM Dialog. The corresponding descriptions are depicted in Table 9-72. As to the SHDSL History PM Dialog, it is shown in Figure 9-105. The

corresponding descriptions are depicted in Table 9-73.

Figure 9-103 xDSL History Port Selection Dialog




Figure 9-104 ADSL History PM Dialog




Table 9-72 ADSL History PM Dialog Description

Field	Description
List Table	
Create Time	This indicates the time when the xDSL historical PM is recoreded.
Side	This indicates the location where the PM parameters are observed. (Either central side(CO) or remote side(RT))
LOSs	This indicates the count of Loss of Signal Second during the indicated period.
ESs	This indicates the count of Error Second during the indicated period.
SESs	This indicates the count of Severely Error Second during the indicated period.
UASs	This indicates the count of Unavailable Error Second during the indicated period.
Tx Cells / Rate (Kbps)	This indicates the transmitted number of ATM cells and net data rate during the indicated period.
Rx Cell / Rate (Kbps)	This indicates the received number of ATM cells and net data rate during the indicated period.
CVs	This indicates the count of Code Violation during the indicated period.
FullInits	This indicates the count of the total number of full initializations attempted on the line (successful and failed) during the indicated period.
FailedInits	This indicates the total number of failed full initializations during the indicated period.
	A failed full initialization is when showtime is not reached at the end of the full initialization procedure, e.g., when:  • A CRC error is detected.  • A time-out occurs.
	<ul> <li>Unexpected message content is received.</li> </ul>
<b>Function Button</b>	
Graph	Click this button to draw the 2D/3D diagram
Export	Click this button to save the contents of <b>ADSL History PM</b> to the Personal Computer.
Close	Exit the <b>ADSL History PM</b> Dialog.

Figure 9-105 SHDSL History PM Dialog




Table 9-73 SHDSL History PM Dialog Description

Field	Description
List Table	
Create Time	This indicates the time when the PM is reported
Side	This indicates the location where the PM parameters are observed. (Either central side (CO) or remote side (RT))
ESs	This indicates the count of Error Second during the indicated period.
SESs	This indicates the count of Severely Error Second during the indicated period.
UASs	This indicates the count of Unavailable Error Second during the indicated period.
LOSWs	This indicates the count of LOSW second during the indicated period.
CRCs	This indicates the count of the SHDSL CRC anomalies occurring during the current accumulation period.
<b>Function Button</b>	
Graph	Click this button to draw the 2D/3D diagram
Export	Click this button to save the contents of <b>SHDSL History PM List</b> to the Personal Computer.
Close	Exit the SHDSL History PM Dialog.

### **GE Interface Performance Statistics**

Follow the subsequent procedure to obtain data for evaluating the GE interface performance.

Click Performance → Trunk Port PM on **Main Menu** to open the **Trunk Port PM** Dialog as shown in Figure 9-106. Table 9-74 depicts the related parameters.

Figure 9-106 Trunk PM Statistics Dialog




Table 9-74 Trunk PM Dialog Description

Field	Description	
List Table	List Table	
Octets	This indicates the numbers of incoming/outgoing octets via the specified GE port.	
Unicast Packets	This indicates the numbers of incoming/outgoing unicast packets via the specified GE port.	
Non-Unicast Packets	This indicates the numbers of incoming/outgoing non-unicast packets via the specified GE port.	
Discarded Packets	This indicates the numbers of incoming/outgoing discarded packets on the specified GE port per RFC1213.	
Erroneous Packets	This indicates the numbers of incoming/outgoing erroneous packets on the specified GE port per RFC1213.	
PAUSE Frame	This indicates the numbers of incoming/outgoing IEEE 802.3x pause frames on the specified GE port.	
Function Button		
Port	Select the GE port you want to observe.	
Refresh	Click this button to refresh the List Table	
Graph	Click this button to draw the 2D/3D diagram	
Export	Click this button to save the contents of <b>Trunk Port PM</b> to the Personal Computer.	
Close	Exit the Trunk Port PM Dialog.	

This page is leave in blank for note or memo use

## **Chapter 10Fault Management**

This chapter describes the system fault management. The AMS LCT supports real time monitoring of the NE.

This chapter contains the following sections:

- NE Alarm Information
- System Alarm Management

### **NE Alarm Information**

AMS LCT detects alarms from the NE system and interface card modules. Alarm detection is accomplished by way of either polling NE actively or receiving SNMP trap passively.

AMS LCT allows you to temporarily isolate a subset of event messages and display them in the List Table. By applying condition filters at top of dialog, the List Table will only contain the events that meet the specified filter criteria.

Follow the subsequent procedure to observe the current alarm information.

- Step 1 Click Diagnosis → NE Alarm → Active Alarm on Main Menu to open the Active Alarm & Event dialog, or alternative select the object form Rack Tab and use right mouse button to bring out the menu, select the Alarm → Active Alarm, as shown in Figure 10-107. Table 10-75 depicts the definition of fields..
- Step 2 Select the event from the List Table and click '**Detail**' button to view the detail of a specific event, as shown in Figure 10-108 and Table 10-76 depicts the related parameters.

Figure 10-107 Active Alarm & Event List Dialog




Table 10-75 Active Alarm & Event List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the Table List.
Severity	This indicates the severity of the specified alarm/event.
NE	This indicates the NE IP address.
Slot-Port	This indicates where the alarm/event occurred.
Entity Type	This indicates the hardware type of the entity where the alarm/event occurred.
Alarm Type	This indicates the alarm type.
Alarms	This indicates the description of alarm.
Occur Time	This indicates the time when the indicated alarm/event occurs at the NE.
Receive Time	This indicates the time when the indicated alarm/event received by the AMS LCT.
Function Button	
Detail	Click this button to display the detail information of the specified alarm/event.
Refresh	Click this button to refresh the List Table
Export	Click this button to save the contents of <b>Active Alarm &amp; Event List</b> to the Personal Computer.
Close	Exit the Active Alarm & Event List Dialog.



The right-hand side of dialog provides a summary of all the active alarm status under the selected object (Slot-Port), with a display of the alarm of severity.



The List Table of Active Alarm & Event dialog displays the selected object. The title of dialog shows the scope of selecting object.

Figure 10-108 Detailed Alarm & Event Dialog




Table 10-76 Detailed Alarm & Event Dialog Description

Field	Description
Alarm Information	
Location	This indicates the location of the NE
NE	This indicates the NE IP address.
Entity	This indicates the module where the alarm/event occurred.
Online Model	This indicates the online model name associated with the "Entity".
Planned Model	This indicates the planned model name associated with the "Entity".
Alarm Severity	This indicates the severity of the observed alarm/event.
Occur Time	This record occur time of the observed alarm/event.
Receive Time	This record receives time of the specified alarm/event.
Detailed Alarm	This describes the detailed alarm information.

## **System Alarm Management**

The system alarm management allows you to manually gather the alarm information from NE. You can also configure the system alarm relay input and monitor the NE hardware operation status (like voltage, temperature).

This section contains the following three subsections.

- Alarm Synchronization
- Relay Input Management
- Hardware Status Monitoring

### **Alarm Synchronization**


The AMS LCT provides automatic alarm synchronization. However, since the AMS LCT polls

the NE periodically, the polling may not reflect the real-time status. To supplement this issue, the AMS LCT supports the real-time manually alarm synchronization function.

Follow the subsequent procedure to perform the alarm synchronization function.

Click Diagnosis → NE Alarm → Alarm Sync on **Main Menu** to process the alarm synchronization, as shown in Figure 10-109.

Figure 10-109 Completed Alarm Sync Dialog



### **Relay Input Management**

The relay input management allows you to define the alarm relay input. Please see "System Installation Guide" for the definition. Once the normal status of input signal is different from the current status, the NE will launch an "abnormal status" alarm of the specified relay input to LCT.

Follow the subsequent procedure to manage the relay input.

Step 1 Click Diagnosis → NE Alarm → Relay Input on Main Menu to open the NE Relay Input Dialog as shown in Figure 10-110 . Table 10-77 depicts the related parameters.

Figure 10-110 NE Relay Input List Dialog




Table 10-77 NE Relay Input List Dialog Description

Field	Description
List Table	
Point	This indicates the location of relay input port.

Field	Description
Name	This indicates the name of replay input port.
Current Status	This indicates the current status of the specified relay input.
Normal Status	This indicates the normal status of the specified relay input that configured by operator.
Severity	This indicates the alarm severity while the status is abnormal.

Step 2 Select the row and click 'Modify' button to modify the normal status of the relay input port as shown in Figure 10-111. Table 10-78 depicts the related parameters.

Figure 10-111 NE Relay Input Modification Dialog




Table 10-78 NE Relay Input Modification Dialog Description

Field	Description
Relay Input Setting	
Name	This gives a meaningful name to the specified relay input.
Normal Status	
Disable	Check this radio button to disable the specified relay input.
Close	Check this radio button to define normal status of the specified relay input is "Close".
Open	Check this radio button to define normal status of the specified relay input is "Open".

#### **Hardware Status Monitoring**

In the hardware monitoring list dialog, you can monitor the temperature and voltage status of any specific card module.

- Step 1 Click Diagnosis → NE Alarm → Hardware Monitoring on Main Menu to open the Hardware Monitoring List Dialog as shown in Figure 10-112. Table 10-79 depicts the related parameters.
- Step 2 Select the row and click 'Modify' button to the system temperature threshold value as shown in Figure 10-113.

Figure 10-112 Hardware Monitoring List Dialog





Table 10-79 Hardware Monitoring List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Tale.
Slot	This indicates the location of line card or other card model.
Name	This indicates the name of sensor.
Current Value	This indicates the current value of the specified sensor.
Reference Value	This indicates the normal value of the specified sensor.
Threshold – Low/High	This indicates the low-high threshold value of the specified sensor.
<b>Function Button</b>	
Modify	Click this button to modify the system temperature threshold value as shown in Figure 10-113.
Refresh	Click this button to refresh the table list.
Export	Click this button to save the contents of <b>Hardware Monitoring</b> List to the Personal Computer.
Close	Exit the <b>Hardware Monitoring List</b> dialog.

Figure 10-113 Hardware Monitoring Threshold Setting Dialog



This page is leave in blank for note or memo use

# **Chapter 11Diagnosis Management**

This chapter describes the diagnosis of xDSL line interface, GE interface, and system network connectivity.

This chapter contains the following sections:

- xDSL Line Interface Diagnosis
- Trunk Current Status Diagnosis
- Network Diagnosis

## **xDSL Line Status Diagnosis**

The NE supports the following five xDSL line status related diagnosis functions.

- Port Rate Status
- Bits Allocation Monitoring
- Loop Monitoring
- Loop Diagnosis (DELT < Dual-Ended Line Test>)
- Loop SELT Test (Single End Loop Test)

#### **Port Rate Status**

Follow the subsequent procedure to monitor the ADSL current rate status.

- Step 1 Click Diagnosis → xDSL Current Status → Port Rate Status on Main Menu to open the xDSL Port Selection Dialog as shown in Figure 11-114.
- Step 2 Select the port you want to show and press Query button on the **xDSL Port Selection**Dialog to observe the current ADSL port status as shown in Figure 11-115. Table 11-80 depicts the related parameters.

Figure 11-114 xDSL Port Selection Dialog




Figure 11-115 ADSL Port Rate Status Dialog




Table 11-80 ADSL Port Rate Status Dialog Description

Field	Description
List Table	
Current Tx Rate (Kbps)	This indicates the current DS/US transmit rate in unit of Kbps. (in the current show-time)
Previous Tx Rate (Kbps)	This indicates the previous DS/US transmit rate in unit of Kbps. (in the last show-time)
Attainable Rate (Kbps)	This indicates the DS/US attainable rate in unit of Kbps.
SNR Margin (dB)	This indicates the DS/US SNR margin in unit of dB.
Attenuation (dB)	This indicates the DS/US attenuation in unit of dB.
Output Power (dBm)	This indicates the DS/US output power in unit of dBm.
Interleave Delay (msec)	This indicates the DS/US interleave delay whenever the line is in the interleaved mode.
Data Block Length (byte)	This indicates the DS/US ADSL data block length in unit of octet.
Line Standard	This indicates the adopted for the current ADSL connection.
Power Management Mode	This indicates the power management mode, either manual or. Automatic.
Power State	This indicates the power management state of this subscriber port per ITU-T 992.3.
Current INP (0.01 symbol time)	This indicates the DS/US INP (Impulse Noise Protection) symbol time in unit of (0.01 symbol time).

Table 11-1 ADSL Port Rate Status Dialog Description (Continued)

Field	Description
<b>Function Button</b>	
Refresh	Click this button to refresh the specified threshold value.
Next	Click this button to display the next subscriber port.
Previous	Click this button to display the previous subscriber port.
First	Click this button to go to the first subscriber status.
Last	Click this button to go to the last subscriber status.
Transit to L0	Click this button to force the power management state to L0 per ITU-T 992.3.
Transit to L2	Click this button to set the power management state to L2 per ITU-T 992.3.
Transit to L3	Click this button to set the power management state to L3 per ITU-T 992.3.
Export	Click this button to save the contents of <b>ADSL Current Rate Status List</b> to the Personal Computer.
Close	Exit the ADSL Current Rate Status Dialog.



Please refer to ITU-T 992.3 for the details of state transition among the power management state L0, L2 and L3.

### **Bits Allocation Monitoring**

The bit allocation monitoring function allows the operator to observe the number of bits carried on each tone of ADSL line in show-time.

Follow the subsequent procedure to monitor the bit allocation status on the specified ADSL connection.

- Step 1 Click Diagnosis  $\rightarrow$  xDSL Current Status  $\rightarrow$  Bits Allocation on Main Menu to open the xDSL Port Selection Dialog as shown in Figure 11-114.
- Step 2 Select the port you want to show and press Query button on the **xDSL Port Selection**Dialog to open the **xDSL Bit Allocation** Dialog as shown in Figure 11-116. Table 11-81 depicts the related parameters.

Figure 11-116 ADSL Bit Allocation Status Dialog





Table 11-81 ADSL Bit Allocation Status Dialog Description

Field	Description
List Table	
Tone	This indicates number of tone index.
Upstream	This indicates the upstream bit allocation of the specified tone.
Downstream	This indicates the downstream bit allocation of the specified tone.
<b>Function Button</b>	
Refresh	Click this button to refresh the bit allocation list table.
Graph	Click this button to display the graph for the bit allocation.
Export	Click this button to save the contents of <b>ADSL Bit Allocation Status List</b> to the Personal Computer.
Close	Exit the ADSL Bit Allocation Status Dialog.

Step 3 Click "Graph" to show the graph of Bit Allocation as shown in Figure 11-117.

Figure 11-117 Graph of Bit Allocation



#### **Loop Monitoring**

The loop monitoring function provides the records of ADSL loop characteristics measured during the last training. It is noted that the measured results are only available in the show-time.

- Step 1 Click Diagnosis  $\rightarrow$  xDSL Current Status  $\rightarrow$  Bits Allocation on Main Menu to open the xDSL Port Selection Dialog as shown in Figure 11-114.
- Step 2 Select the port you want to show and press Query button on the **xDSL Port Selection**Dialog to open the **ADSL Loop Monitoring** Dialog as shown in Figure 11-118. Table 11-82 depicts the related parameters.
- **Step 3** Press Start button to get starting.
- Step 4 Click "Graph" button to show the graph of Magnitude as shown in Figure 11-119 or show the graph of Quiet Line PSD as shown in Figure 11-120



Please refer to ITU-T 992.3 for the details of loop monitoring parameters.



In comparison with the DELT, the ADSL loop is not corrupted whenever the operator performs the loop monitoring function.

Figure 11-118 ADSL Loop Monitoring Dialog




Table 11-82 ADSL Loop Monitoring Dialog Description

Field	Description
Status	This indicates the status of the loop monitoring.
Reason for Failure	This indicates the result of failure case.
Magnitude Dialog	
Tone	This indicates the serial number of tone.
Upstream	This indicates the magnitude of transfer function per tone of the upstream channel.
Downstream	This indicates the magnitude of transfer function per tone of the downstream channel.
<b>Quiet Line PSD Dialog</b>	
Tone	This indicates the serial number of tone.
Upstream	This indicates the quiet line noise PSD per tone of the upstream channel.
Downstream	This indicates the quiet line noise PSD per tone of the downstream channel.
<b>Function Button</b>	
Start	Click this button to start the loop monitoring function.
Graph	Click this button to display the resultant graph of loop monitoring.
Export	Click this button to save the contents of <b>xDSL Loop Monitoring List</b> to the Personal Computer.
Close	Exit the xDSL Loop Monitoring List Dialog.



Please refer to ITU-T 992.3 for the details of loop monitoring parameters.

Figure 11-119 Graph of Loop Monitoring - Magnitude



Figure 11-120 Graph of Loop Monitoring - Quiet Line Noise PSD



#### Loop Diagnosis (DELT < Dual-Ended Line Test>)

The DELT loop diagnosis function provides mechanism to measure the ADSL loop quality. This action will interrupt the ADSL connection. However, more detailed inform are gathered in comparison with the aforementioned loop monitoring function.


- Step 1 Click Diagnosis → xDSL Current Status → Bits Allocation on **Main Menu** to open the **xDSL Port Selection Dialog** as shown in **Figure 11-114**.
- Step 2 Select the port you want to show and press Query button on the xDSL Port Selection Dialog to open the ADSL Loop Diagnosis Dialog as shown in Figure 11-121. Table 11-83 depicts the related parameters.
- Step 3 Press Start button to get starting.
- Step 4 Click "Graph" button to show the graph of Magnitude as shown in Figure 11-122 or the graph of Quiet Line PSD as shown in Figure 11-123 or the graph of SNR as shown in Figure 11-124.



In comparison with the loop monitoring function, the ADSL loop is corrupted whenever the operator performs the DELT.

[10.12.3.97] <Slot-LC1, Port-1 > xDSL Loop Diagnosi Line Profile test ▼ Show succeeded Reason for Failure

### Figure 11-121 ADSL Loop Diagnosis Dialog



The above dialog lists the loop diagnostics parameters that display, see the ITU-T's G.992.3 and G.992.5 for more information.

Table 11-83 ADSL Loop Diagnosis Dialog Description

Field	Description
Line Profile	Use this combo-box to select the line profile to test.
Status	This indicates the status of the DELT.
Reason for Failure	This indicates the result of failure case.
Rate Dialog	
Attainable Rate (bps)	This displays the attainable rate of DELT.
Loop Attenuation (0.1dB)	This displays the loop attenuation of DELT.
Signal Attenuation (0.1dB)	This displays the signal attenuation of DELT.
SNR Margin (0.1dB)	This displays the SNR margin value of DELT.
Tx Power (0.1dB)	This displays the transmit power value of DELT.
Magnitude Dialog (The ma	agnitude of ADSL line transfer function)
Tone	This indicates the number of the tone.
Upstream	This indicates the upstream magnitude of the specified tone.
Downstream	This indicates the downstream magnitude of the specified tone.
Quiet Line PSD Dialog (PS	SD of Quiet Line Noise)
Tone	This indicates the number of the tone.
Upstream	This indicates the upstream PSD of Quiet Line Noise of the specified tone.
Downstream	This indicates the downstream PSD of Quiet Line Noise of the specified tone.
SNR Dialog	
Tone	This indicates the number of the tone.
Upstream	This indicates the upstream SNR of the specified tone.
Downstream	This indicates the downstream SNR of the specified tone.
<b>Function Button</b>	
Show	Click this button to display the selected line profile.
Start	Click this button to start the DELT function.
Graph	Click this button to display the result graph of DELT.
Export	Click this button to save the results of <b>ADSL Loop Diagnosis</b> ( <b>DELT</b> ) to the Personal Computer.
Close	Exit the ADSL Loop Diagnosis (DELT) Dialog.



Please refer to ITU-T 992.3 for the details of DELT.



'Upshift Noise Margin', 'Downshift Noise Margin', 'Upshift Time' and 'Downshift Time' are only applied to the Rate Mode 'Adaptive at Run-Time'.

Figure 11-122 Graph of DELT result - Magnitude



Figure 11-123 Graph of DELT result - Quiet Line PSD






Figure 11-124 Graph of DELT result - SNR

## **Loop SELT Test (Single End Loop Test)**

The SELT loop function diagnosis function is to estimate the distance of the DSL connection from the NE to the subscriber's location without connecting a subscriber device.

- Step 1 Click Diagnosis  $\rightarrow$  xDSL Current Status  $\rightarrow$  Bits Allocation on Main Menu to open the xDSL Port Selection Dialog as shown in Figure 11-114.
- Step 2 Select the port you want to show and press Query button on the xDSL Port Selection Dialog to open the ADSL Loop SELT Test Dialog as shown in Figure 11-125 and Table 11-84 depicts the related parameters.
- **Step 3** Press Start button to get starting.

Figure 11-125 ADSL Loop SELT Test




Table 11-84 ADSL Loop SELT Test Dialog Description

Field	Description
Status	This indicates the status of the SELT.
Reason for Failure	This indicates the result of failure case.
Test Result	
Cable Type	This displays the estimated cable type.
Reach Length (ft.)	This displays the estimated cable length.
<b>Function Button</b>	
Start	Click this button to start the SELT.
Close	Exit the SELT dialog.



Please refer to ITU-T 992.3 for the details of SELT.

## **xDSL Service Status Diagnosis**

The NE supports the following six xDSL service status related diagnosis functions.

- Bridge Filtering Database
- VLAN Membership
- xDSL MAC Spoofing Statu
- Multicast Channel Status
- Multicast Group Membership
- xDSL Downstream Broadcast Forwarding VLANs

## **Bridge Filtering Database**

The filtering database (FDB) displays the status of MAC address recorded in the line card on a per PVC basis.

Click Diagnosis → xDSL Current Status → Bridge Filtering Database on **Main Menu** to open the **Filtering Database Entry List** Dialog as shown in Figure 11-126. Table 11-85 depicts the related parameters.

Figure 11-126 Bridge Filtering Database Entry List Dialog




Table 11-85 Bridge Filtering Database Entry List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Table.
Slot-Port	This indicates the location of xDSL port.
VPI	This indicates the VPI of the specified entry.
VCI	This indicates the VCI of the specified entry.
MAC Address	This indicates the MAC address of the specified entry.
Status	This indicates the reason the MAC address appears in this entry. The definitions of status are as follows.
	• learned: It indicates the MAC address is dynamically learned by the NE.
	• <b>forbidden:</b> It indicates the MAC address is manually set for the NE to drop the upstream Ethernet frame of the identical source MAC address.
	• <b>fixed:</b> It indicates the MAC address is manually set for the NE to forward the upstream Ethernet frame of the identical source MAC address.
Function Button	
Slot	Use this combo-box to select the line card.
Port	Use this combo-box to select the xDSL port.
Refresh	Click this button to refresh the list table.
Export	Click this button to save the contents of <b>Filtering Database Entry List</b> to the Personal Computer.
Close	Exit the Filtering Database Entry List Dialog.

## **VLAN Membership**

The VLAN membership displays the list of xDSL ports belonging to a VLAN of particular VLAN ID.

Click Diagnosis → xDSL Current Status → VLAN Membership on **Main Menu** to open the **VLAN Membership List** Dialog as shown in Figure 11-127. Table 11-86 depicts the related parameters.

Figure 11-127 VLAN Membership List Dialog




Table 11-86 VLAN Membership List Dialog Description

Field	Description
List Table	
Slot	This indicates the location of line card.
Port-List	This indicates the location of xDSL port.  The blue point indicates that the corresponding port is a member port of a VLAN of the specified VLAN ID.
VLAN ID	This specifies the VLAN ID of the VLAN to show its members ports. Change the VLAN ID by clicking VLAN ID value with left button on mouse.
<b>Function Button</b>	
Export	Click this button to save the contents of <b>VLAN Membership List</b> to the Personal Computer.
Close	Exit the VLAN Membership List Dialog.

## **xDSL MAC Spoofing Status**

The xDSL MAC Spoofing displays the duplicate MAC address from two or more individual xDSL subscriber ports.

Click Diagnosis → xDSL Current Status → MAC Spoofing Status on **Main Menu** to open the **MAC Spoofing Status List** Dialog as shown in Figure 11-128. Table 11-87 depicts the related parameters.

Figure 11-128 MAC Spoofing Status List Dialog




Table 11-87 MAC Spoofing Status List Dialog Description

Field	Description
Spoofed MAC Address	This displays the current spoofed MAC address.
List Table	
No.	This indicates the serial number of entry of the List Table.
Slot-Port	This indicates the location of xDSL port where the spoofed MAC address is observed.
VPI	This indicates the VPI of the PVC where the spoofed MAC address is observed.
VCI	This indicates the VCI of the PVC where the spoofed MAC address is observed.
MAC Address	This indicates the spoofed MAC address
Status	This indicates the current status of the recorded MAC address. The definition of possible statuses is as follows.
	• learned (unique): It indicates the dynamically learned MAC address is unique within the NE.
	• <b>spoofed (pass):</b> It indicates the dynamically learned MAC address is spoofed. The NE forwards the packet from this subscriber port as it appears first.
	• spoofed (deny): It indicates the dynamically learned MAC address is spoofed. The NE drop the packet from this subscriber port as it does not appears first.
Function Button	
Refresh	Click this button to refresh the Spoofed MAC Address list.
Export	Click this button to save the contents of <b>Spoofed MAC Address List</b> to the Personal Computer.
Close	Exit the Spoofed MAC Address List Dialog.



Whenever the NE detects spoofed MAC address, the NE launches a SNMP traps to the SNMP trap managers as specified in the section "Configuring the SNMP Trap Manager" in Chap 4.

#### **Multicast Channel Status**

Whenever the subscriber clicks his remote controller to watch a TV channel transmitted via the ADSL line, the set-top-box sends the corresponding IGMP report packet. The NE inspects the received IGMP report packet to check whether its multicast IP hits the associated multicast service profile (MSP) or not. If the multicast IP hits the associated MSP, the NE forwards the IGMP packet. In the meantime, the NE also records the multicast IP in the **Multicast Channel Status List** s shown in Figure 11-129. Refer the related information to the section "Multicast Service Profile" in 5.

Click Diagnosis → xDSL Current Status → Multicast Channel Status on **Main Menu** to open the **Multicast Channel Status List** Dialog as shown in Figure 11-129. Table 11-88 depicts the related parameters.

Figure 11-129 Multicast Channel Status List Dialog




Table 11-88 Multicast Channel Status List Dialog Description

Field	Description
List Table	
No.	This indicates the serial number of entry of the List Table.
Slot-Port	This indicates the location of xDSL port.
Multicast TV Channel	This indicates that recorded multicast channel group IP address which the NE has received the corresponding IGMP report (Join) packet.
Status	This indicates the current status of the multicast channel group. The definition of possible statuses is as follows.
	• Active: The NE received the subscriber's IGMP report.
	<ul> <li>Poll: The NE does not receive the subscriber's IGMP report which responds to the IGMP server/proxy's IGMP query packet.</li> </ul>
	• Idle: The NE retries to query the subscriber for "IGMP Robustness retry" times, but it does not get the response. In fact, the LCT will not show the entries of status equal to Idle.
Function Button	
Shelf	Use this combo-box to select the NE.
Slot	Use this combo-box to select the line card.
Port	Use this combo-box to select the xDSL ports, either one port or all ports.
Refresh	Click this button to refresh the multicast channel status.
Export	Click this button to save the contents of <b>Multicast Channel Status</b> List to the Personal Computer.
Close	Exit the Multicast Channel Status List Dialog.

## **Multicast Group Membership**

The multicast group membership list displays the list of xDSL subscriber ports from which the NE has received the IGMP report (Join) packets to join a particular multicast TV channel. In other word, the multicast group membership list shows the xDSL member ports of a particular multicast TV Channel.

Click Diagnosis → xDSL Current Status → Multicast Group Membership on **Main Menu** to open

the **Multicast Group Membership List** Dialog as shown in Figure 11-130. Table 11-89 depicts the related parameters.

Figure 11-130 Multicast Group Membership List Dialog




Table 11-89 Multicast Group Membership List Dialog Description

Field	Description
Multicast TV Channel	Use this list to select the multicast TV Channel to display its members.
Last Reporter	This indicates the last xDSL subscriber launches an IGMP report to join the specified multicast TV channel. Its representation includes the location of the subscriber as well as its IP address.
Member Count	This indicates the number of xDSL subscribers currently join the specified multicast TV channel.
Up Time (sec)	This indicates the time period since the NE received the first IGMP report to join the specified multicast TV channel.
List Table	
Slot	This indicates the location of line card.
Port-List	This indicates the port list number. The blue point means that the specified port is a member of the specified multicast channel.  Note: In the case that the RSTP is disabled, "Subtend" indicates the port GE2.
	Note: In the case that the RSTP is enabled, "Subtend" indicates the "designated port" (either port GE1 or port GE2).
<b>Function Button</b>	
Refresh	Click this button to refresh the multicast group membership list.
Export	Click this button to save the contents of <b>Multicast Group Membership List</b> to the Personal Computer.
Close	Exit the Multicast Group Membership List Dialog.

## **xDSL Downstream Broadcast Forwarding VLANs**

The xDSL Downstream Broadcast Forwarding VLANs List displays the list of VLANs which are allowed to forward the downstream broadcast traffic.

Click Diagnosis → xDSL Current Status → Broadcast Filter Status on **Main Menu** to open the **xDSL Forwarding Broadcast VLANs List** Dialog as shown in Figure 11-131 and Table 11-90 depicts the related parameters.

Figure 11-131 xDSL Forwarding Broadcast VLANs List




Table 11-90 xDSL Forwarding Broadcast VLANs List Description

Field	Description
List Table	This displays current VLAN ID of VLAN which forwards the broadcast packets.
Function Button	
Slot	Use this combo-box to select the location of xDSL line card.
Refresh	Click this button to refresh the Forwarding Broadcast VLANs list.
Export	Click this button to save the contents of xDSL Forwarding Broadcast VLANs List to the Personal Computer.
Close	Exit the xDSL Forwarding Broadcast VLANs List Dialog.

## **Trunk Current Status Diagnosis**

This section contains the following two subsections.

- LACP Diagnosis
- RSTP Diagnosis

## **LACP Diagnosis**

Follow the subsequent procedures to view the current LACP status.

Click Diagnosis → Trunk Current Status → Link Aggregation Status on Main Menu to open the Current Status of Link Aggregation Dialog. Figure 11-132 shows Current Status of Link Aggregation Dialog, and Table 11-91 depicts the related parameters.

Figure 11-132 Current Status of Link Aggregation Dialog




Table 11-91 Current Status of Link Aggregation Dialog Description

Actor System Priority  It indicates the system priority configured for the LACP running the NE.  Actor System ID  It indicates a 6-octet unique system ID for the LACP running on NE. It is the MAC address of one of the GE port.  Actor Key  It indicates a 2-octet operational Key value of the GE port for the LACP running on the NE.  Actor Port Priority  It indicates a 2-octet port priority configured for the LACP running on the NE.  Actor Port ID  It indicates the port ID for the LACP running on the NE.	eld	Description
Port GE1/ Port GE2 (Tab)  Aggregator ID It indicates the ID of aggregation group which the port belongs to Actor System Priority It indicates the system priority configured for the LACP running the NE.  Actor System ID It indicates a 6-octet unique system ID for the LACP running on NE. It is the MAC address of one of the GE port.  Actor Key It indicates a 2-octet operational Key value of the GE port for the LACP running on the NE.  Actor Port Priority It indicates a 2-octet port priority configured for the LACP running on the NE.  Actor Port ID It indicates the port ID for the LACP running on the NE.  Actor Operation State It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority It indicates the system priority of the peer LACP partner.	nk Aggregation Type	
Actor System Priority  It indicates the ID of aggregation group which the port belongs to the NE.  Actor System ID  It indicates a 6-octet unique system ID for the LACP running on NE. It is the MAC address of one of the GE port.  Actor Key  It indicates a 2-octet operational Key value of the GE port for the LACP running on the NE.  Actor Port Priority  It indicates a 2-octet port priority configured for the LACP running on the NE.  Actor Port ID  It indicates the port ID for the LACP running on the NE.  It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	lministrative State	
Actor System Priority  It indicates the system priority configured for the LACP running the NE.  Actor System ID  It indicates a 6-octet unique system ID for the LACP running on NE. It is the MAC address of one of the GE port.  Actor Key  It indicates a 2-octet operational Key value of the GE port for the LACP running on the NE.  Actor Port Priority  It indicates a 2-octet port priority configured for the LACP running on the NE.  Actor Operation State  It indicates the port ID for the LACP running on the NE.  It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	ort GE1/ Port GE2 (Tab)	b)
the NE.  Actor System ID  It indicates a 6-octet unique system ID for the LACP running on NE. It is the MAC address of one of the GE port.  Actor Key  It indicates a 2-octet operational Key value of the GE port for the LACP running on the NE.  Actor Port Priority  It indicates a 2-octet port priority configured for the LACP running on the NE.  Actor Port ID  It indicates the port ID for the LACP running on the NE.  It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	ggregator ID	It indicates the ID of aggregation group which the port belongs to.
NE. It is the MAC address of one of the GE port.  Actor Key  It indicates a 2-octet operational Key value of the GE port for the LACP running on the NE.  Actor Port Priority  It indicates a 2-octet port priority configured for the LACP running on the NE.  Actor Port ID  It indicates the port ID for the LACP running on the NE.  It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	ctor System Priority	It indicates the system priority configured for the LACP running on the NE.
LACP running on the NE.  Actor Port Priority  It indicates a 2-octet port priority configured for the LACP running on the NE.  Actor Port ID  It indicates the port ID for the LACP running on the NE.  It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	ctor System ID	It indicates a 6-octet unique system ID for the LACP running on the NE. It is the MAC address of one of the GE port.
on the NE.  Actor Port ID  It indicates the port ID for the LACP running on the NE.  It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	ctor Key	It indicates a 2-octet operational Key value of the GE port for the LACP running on the NE.
Actor Operation State  It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.  A: lacpActivity,  T: lacpTimeout(1),  G: aggregation(2),  S: synchronization(3),  C: collecting(4),  D: distributing(5),  F: defaulted(6),  E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	ctor Port Priority	It indicates a 2-octet port priority configured for the LACP running on the NE.
IEEE 802.3 Annex 30C.6.  A: lacpActivity, T: lacpTimeout(1), G: aggregation(2), S: synchronization(3), C: collecting(4), D: distributing(5), F: defaulted(6), E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	ctor Port ID	It indicates the port ID for the LACP running on the NE.
T: lacpTimeout(1), G: aggregation(2), S: synchronization(3), C: collecting(4), D: distributing(5), F: defaulted(6), E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.	etor Operation State	It indicates the current port status of the LACP on the NE per the IEEE 802.3 Annex 30C.6.
G: aggregation(2), S: synchronization(3), C: collecting(4), D: distributing(5), F: defaulted(6), E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.		
S: synchronization(3), C: collecting(4), D: distributing(5), F: defaulted(6), E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.		1
C: collecting(4), D: distributing(5), F: defaulted(6), E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.		
D: distributing(5), F: defaulted(6), E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.		
F: defaulted(6), E: expired(7)  Partner System Priority  It indicates the system priority of the peer LACP partner.		
E: expired(7)  Partner System Priority		- · · · · · · · · · · · · · · · · · · ·
Partner System Priority		\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
	rtner System Priority	
	-	It indicates a 2-octet operational Key value of GE port of the peer
Partner Port Priority	rtner Port Priority	
Partner Port ID It indicates the port ID of GE port of the peer LACP partner.	,	
		It indicates the current GE port status of the peer LACP partner per
A: lacpActivity,		1 27
T: lacpTimeout(1),		1
G: aggregation(2),		
S: synchronization(3),		
C: collecting(4),		
D: distributing(5), F: defaulted(6),		= 1 1
E: expired(7)		N. C.

## **RSTP Diagnosis**

Follow the subsequent procedures to view the current RSTP-Bridge status.

Click Diagnosis→ Trunk Current Status → RSTP Status on **Main Menu** to open the **Current Status of Rapid Spanning Tree Protocol**– **Bridge Dialog** as shown in Figure 11-133. Table 11-92 depicts the related parameters.

[10.12.3.107] Current Status of Rapid Spanning Tree Protocol × RSTP State disable RSTP Refresh Bridge | Port GE1 | Port GE2 | Configured Value / Current Status Bridge ID 0x8000-ac:01:ac:12:c5:20 **Bridge Priority** 32768 Bridge Max Age 20 seconds Bridge Hello Time 2 seconds **Bridge Forward Delay** 15 seconds Tx Hold Count 3 seconds 0 days 00:00:00 Time Since Last Topology Change **Topology Change Count** Designated Root ID Root Cost 0x8000-ac:01:ac:12:c5:20 Root Port Root Max Age 20 seconds Root Hello Time 2 seconds **Root Forward Delay** 15 seconds Export Close [X]

Figure 11-133 Current Status of Rapid Spanning Tree Protocol – Bridge Dialog

Table 11-92 Current Status of Rapid Spanning Tree Protocol – Bridge Dialog Description

Field	Description
RSTP State	This indicates the enable/disable the RSTP function at GE ports.
Version	This indicates the RSTP version the NE runs.
Bridge (Tab)	
Bridge ID	It indicates an unique 8-octet bridge ID which consists of a 2-octet Bridge Priority and a 6-octet MAC address.
Bridge Priority	It indicates the configured 2-octet bridge priority.
Bridge Max Age	It indicates the configured maximum age of STP/RSTP.
Bridge Hello Time	It indicates the configured amount of time between the transmission of configuration bridge PDUs by this node on any port when it is the root of the spanning tree or trying to become so.
Bridge Forward Delay	It indicates the configured time value that controls how fast a port changes its spanning state when moving towards the Forwarding state.
Tx Hold Count	It indicates the configured Bridge Tx Hold Count.
Time Since Last Topology Change	It indicates the time since last topology change.
Topology Change Count	It indicates the count of topology changes.
Designated Root ID	It indicates the Root Bridge ID once the RSTP selects a bridge as a root bridge.
Root Cost	It indicates the total cost from the NE to the root bridge.
Root Port	It indicates the port toward the root bridge
Root Max Age	It indicates the Max Age determined by RSTP.
Root Hello Time	It indicates the Hello Time determined by RSTP.
Root Forward Delay	It indicates the Forward Delay determined by RSTP.

#### Port GE1/Port GE2

Follow the subsequent procedures to view the current RSTP- Port GE1/Port GE2 status.

Click the Port GE1/Port GE2 tab in Current Status of Rapid Spanning Tree Protocol Dialog to launch the Current Status of Rapid Spanning Tree Protocol —Port GE1/Port GE2 Dialog as shown in Figure 11-134. Table 11-93 depicts the related parameters.

Figure 11-134 Current Status of Rapid Spanning Tree Protocol –Port GE1/Port GE2 Dialog





Table 11-93 Current Status of Rapid Spanning Tree Protocol –Port GE1/Port GE2 Dialog Description

Field	Description
RSTP State	This indicates the enable/disable the RSTP function at GE ports.
Version	This indicates the RSTP version the NE runs.
Port GE 1 / Port GE 2 (Ta	b)
Port ID	It indicates the port ID the GE port.
RSTP Port Enable State	It indicates the current RSTP enabled/disabled status of the GE port.
Priority	It indicates the configured port priority the GE port.
Configured Path Cost	It indicates the configured path cost of the GE port.
Configured Edge Port	It indicates whether the GE port is configured as Edge Port or not.
Configured Point-to-Point Link	It indicates the configured status of the LAN segment attached to this GE port.  Yes: It indicates that this port should always be treated as if it is connected to a point-to-point link.  No: It indicates that this port should be treated as having a shared media connection  Auto-detection: It indicates that this port is considered to have a point-to-point link if it is an Aggregator and all of its members are aggregatable, or if the MAC entity is configured for full duplex operation, either through auto-negotiation or by management means.
Current Operation State	It indicates the current operation state of GE port.
Forward Transitions	It indicates the number of times this port has transitioned from the Learning state to the Forwarding state.
Current Path Cost	It indicates the configured numerical path cost of the GE port.
Current Edge Port State	It indicates whether the GE port is edge port or not.
Current Point-to-Point Link State	It indicates whether the GE port connects with point-to-point link or not.
Designated Root ID	It indicates the unique Bridge Identifier of the Bridge recorded as the Root in the Configuration BPDUs transmitted by the designated Bridge for the segment to which the port is attached.
Designated Cost	It indicates the path cost of the Designated Port of the segment connected to this port. This value is compared to the Root Path cost field in received bridge BPDUs
Designated Bridge ID	It indicates the Bridge Identifier of the bridge which this port considers to be the Designated Bridge for this port's segment.
Designated Port ID	The Port Identifier of the port on the Designated Bridge for this port's segment.

## **UGE VLAN List**

Follow the subsequent procedures to view the current UGE VLAN status.

Click Diagnosis  $\rightarrow$  Trunk Current Status  $\rightarrow$  UGE VLAN Status on Main Menu to open the UGE VLAN Status Dialog as shown in



## **Network Diagnosis**

The AMS LCT supports the following three network related diagnosis functions to check the connection between the AMS LCT and NE.

- Ping NE
- Traceroute
- Telnet
- Check SNMP Connection

## **Ping NE**

Use the 'Ping NE' echo to check the NE connection from AMS LCT host.

Click Diagnosis → NE Connection → Ping NE on **Main Menu** to open the **Ping NE** Dialog as shown in Figure 11-135 and Table 11-94 depicts the related parameters.

Figure 11-135 Ping NE from Client Dialog




Table 11-94 Ping NE from Client Dialog Description

Field	Description
NE	
Location	Use this combo-box to select location.
NE	Use this combo-box to select NE.
IP	This indicates the IP address of the selected NE.
Ping Parameters	
Count	Use this field to select the number of ICMP ping packets to be launched by the LCT.  Valid value is 1 ~ 99.
Wait (second)	Use this field to select the waiting time of ICMP packet. Valid value is $1 \sim 30$ .
Data Size (byte)	Use this field to select the payload size of ICMP ping packet.  Valid value is 32 ~ 9996.
TTL	Use this field to select the TTL (Time To Live) of ICMP ping packet.  Valid value is 1 ~ 255.
ToS	Use this field to select the ToS (Type of Serveice) of ICMP ping packet. Valid value is $0 \sim 255$ .
Don't fragment	Check this check box to set the "Do not fragment"-bit of ICMP ping packet.

## Table 11-95 Ping NE from Client Dialog Description (continued)

Field	Description
Function Button	
Ping	Start sending ICMP packets.
Clear	Clear all the result above.
Close	Exit the Ping dialog.

## **Traceroute**

Use the 'Traceroute" to check the NE connection from AMS LCT host.

Click Diagnosis → NE Connection → Traceroute on **Main Menu** to open the **Traceroute NE** Dialog as shown in Figure 11-136. Table 11-96 depicts the related parameters.

Figure 11-136 Tracer Route NE from Client Dialog




Table 11-96 Trace Route NE from Client Dialog Description


Field	Description		
NE			
Location	Use this combo-box to select location.		
NE	Use this combo-box to select NE.		
IP	This indicates the IP address of the selected NE.		
Ping Parameters			
Ping Count	Use this field to select the number of ICMP packets to be launched by the LCT. Valid value is $1\sim99$ .		
Wait (second)	Use this field to select the waiting time of ICMP packet. Valid value is $1 \sim 30$ .		
Data Size (byte)	Use this field to select the payload size of ICMP packet. Valid value is 32 ~ 9996.		
Max Hops	Use this field to select the maximum number of hops of tracing. Valid value is $1 \sim 255$ .		
ToS	Use this field to select the ToS (Type of Serveice) of ICMP packet. Valid value is $0 \sim 255$ .		
Do not fragment	Check this check box to set the "Do not fragment"-bit of ICMP packet.		
Function Button			
Trace	Start Traceroute by sending ICMP packets.		
Clear	Clear all the result above.		
Close	Exit the Trace Route dialog.		

## **Telnet**

The AMS LCT allows operator to launch a Telnet window in the LCT environment.

Click Diagnosis → NE Connection → Telnet on **Main Menu** to launch the Telnet window as shown in Figure 11-137.

Figure 11-137 Telnet Pop-up Window



#### **Check SNMP Connection**

Use the 'SNMP Connection' to check whether the connection between NE and AMS LCT host is normal or not.

Click Diagnosis → NE Connection → SNMP Connection on **Main Menu** to open the **SNMP Connection** Dialog as shown in Figure 11-138 and Table 11-97 depicts the related parameters.

Figure 11-138 Check NE SNMP Connection Dialog




Table 11-97 Check NE SNMP Connection Dialog Description

Field	Description		
NE			
Location	Use this combo-box to select location.		
NE	Use this combo-box to select NE.		
IP	This indicates the IP address of the selected NE.		
Function Button			
Check	Start checking the SNMP connection.		
Clear	Clear all the result above.		
Close	Exit the Check NE SNMP Connection Dialog.		

## **Chapter 12General System Management**

This chapter details the various operations that need to be carried out to setup and start services.

AMS LCT Options

## **AMS LCT Options**

## **Configuring the Alarm Warning Options**

The AMS LCT supports to notify the operators whenever there is an alarm sent from the NE. The operator is allowed to control the AMS LCT to notify by flashing the alarm on the multimedia view (see Figure 3-2) and/or playing a audio file.

Click System → Option on **Main Menu** to open the **Client Options** Dialog as shown in Figure 12-139. Table 12-98 depicts the related parameters.

Figure 12-139 Client Options Dialog - Alarm Warning




Table 12-98 Client Options Dialog – Alarm Warning Description

Field	Description
Flash Effect	
No flash effect	This option button disables the alarm warning flash effect.
Flashing condition and cycle	This option button enables the alarm warning flash effect. You can control the alarm severity and flashing cycles.
Audio Effect	
No audio effect	This option button disables the audio effect.
Notifying condition and interval	This option button enables the audio effect. You can control the alarm severity and the silence interval between two audio notifications.
Waveform audio file	This specifies the sound file of audio effect. Click 'Browse' button to select file and click 'Play' to test.

This page is leave in blank for note or memo use

## **Chapter 13Administrating and Maintenance**

AMS supports the NE firmware and NE inventory management as follows.

This chapter contains the following sections:


- NE Inventory Information
- NE Configuration Backup and Restore
- NE Firmware Up
- SHDSL LC Firmware Up
- NE Boot Partition
- Reset the Unit

## **NE Inventory Information**

Follow the subsequent procedure to display the inventory information of NE software/ hardware version, card serial number, card type and so on

Step 1 Click Diagnosis → Inventory on Main Menu to open the Inventory Information List as shown in Figure 13-140. xxxxxx depicts the related parameters.

Figure 13-140 Inventory Information List



## **NE Configuration Backup and Restore**

Follow the subsequent procedure to backup and restore the configuration data file of NE on local LCT PC through FTP.

- Step 1 Click Configuration → NE Management → Backup & Restore on Main Menu to open the NE Configuration Backup & Restore Dialog as shown in Figure 13-141 and Table 13-99 depicts the related parameters.
- Step 2 To backup the configuration file, please input a valid administrative level username/password and give your backup file a file name, then click 'Backup' button.

- Step 3 To restore the configuration file, click 'Browse' and choose the target file from the backup file directory, then click 'Restore' button.
- **Step 4** After restoring the configuration data, it is noted that the NE needs to be rebooted to make the configuration data take effect.



You can also select and highlight the NE from the **Network Tree View** to progress the NE configuration Backup & Restore by right click of pop-up menu, NE Management → NE Backup & Restore.

Figure 13-141 NE Configuration Backup & Restore File List Dialog




Table 13-99 NE Configuration Backup & Restore File List Dialog Description

Field	Description		
FTP Login			
FTP User Name	Fill the administrative level username of FTP.		
FTP Password	Fill the comparative password of the administrative level username.		
Local Backup File			
Browse	Click this button to open the file choice window.		
<b>Function Button</b>			
Backup	Start to backup the configuration data file of NE by saving it as the specified file on the local LCT PC through FTP.		
Restore	Start to restore the configuration of NE by sending the specified NE configuration file to NE from the the local LCT PC via FTP.		
Close	Exit the Configuration Backup & Restore Dialog.		

## **NE Firmware Upgrade**

AMS LCT provides the "NE Firmware Upgrade" dialog to upgrade the NC/ADSL LC firmware image to NE through FTP.


Follow the subsequent procedure to upgrade the NC/ADSL LC firmware image. It is noted that the NE needs to be rebooted to execute the new image.

Step 1 Click Configuration → NE Management → Firmware Upgrade on Main Menu to open

the **NE Firmware Upgrade** Dialog as shown in Figure 13-142. depicts the related parameters.

- **Step 2** Click 'Browse' button to choose the suitable code file from host directory.
- Step 3 Click 'Upgrade' button to process.
- **Step 4** Reset the NC or ADSL LC to execute the upgraded firmware.

Figure 13-142 NE Firmware Upgrade Dialog





Make sure the source image file that you select is accordant to the NE model, else the NE may not run well with the upgraded firmware image after rebooting.

Table 13-100 NE Firmware Upgrade Dialog Description

Field	Description		
FTP Login			
FTP User Name	This indicates the user name of NE with administrator right.		
FTP Password	This indicates the password of FTP to access NE with administrator right.		
<b>Local Firmware File</b>			
File Name	Click the 'Browse' button to select a file of NC firmware or an ADSL LC firmware from your local host.		
Firmware Type	This indicates the firmware type for upgrade. Click 'Detail' button to display the information of selected file.		
NE Boot Partition (also re	fer to NE Boot Partition)		
Backup / Restore Partition	This specifies the boot partition where the upgraded file to be placed to or backup from.		
Current Boot Partition	This specifies the current boot partition.		
Next Time Boot Partition	This indicates the partition of NE for next booting. Click 'Change' button to change boot partition.		
<b>Function Button</b>			
Backup	Start to backup the NC/ADSL LC firmware image of NE by saving it as the specified file on the local LCT PC through FTP.		

Field	Description
Upgrade	Start to upgrade the NC/ADSL LC firmware image of NE by sending the specified file on the local LCT PC through FTP.
Close	Exit the Configuration Backup & Restore Dialog.

## **SHDSL LC Firmware Upgrade**

AMS LCT provides the "NE SHDSL Firmware Upgrade" dialog to upgrade the SHDSL LC firmware image to NE through FTP.

Follow the subsequent procedure to upgrade the SHDSL LC firmware image. It is noted that the NE needs to be rebooted to execute the new image.

AMS LCT provides the "NE SHDSL Firmware Upgrade" dialog to upload the firmware image to NC through FTP and then upgrade the new image from NC to SHDSL card. Follow the subsequent procedures to upgrade your SHDSL line card if necessary.

- Step 1 Click Configuration → NE Management → NE SHDSL Firmware Upgrade on Main Menu to open the NE SHDSL Firmware Upgrade Dialog as shown in Figure 13-143. Table 13-101 depicts the related parameters.
- **Step 2** Click 'Browse' button to choose the suitable code file from host directory.
- **Step 3** Click 'FTP' button to upload new firmware to NC card.
- Step 4 Mark the SHDSL LC which you want to upgrade firmware, and then click "Upgrade" to proceed.
- Step 5 Reset the SHDSL LC to execute the upgraded firmware.



In comparison with the NC/ADSL LC firmware upgrade procedure, you need take one more step (**Step 4**) to upgrade the SHDSL firmware.



It is noted that the SHDSL LC must be reset at the completion of **Step 4**.

Figure 13-143 NE SHDSL Firmware Upgrade Dialog




Table 13-101 NE SHDSL Firmware Upgrade Dialog Description

Field	Description		
FTP Login			
FTP User Name	This indicates the user name of NE with administrator right.		
FTP Password	This indicates the password of NE with administrator right.		
Local SHDSL Firmware F	Tile		
File Name	Click the 'Browse' button to select a file of SHDSL firmware from your local host.		
FTP	Click this button to upload SHDSL firmware to the NC.		
Current Upgrading Status	This indicates the status of SHDSL line card. Upgrading is available only when the status is "initial".		
Upgrade	Click this button to upgrade the new image from NC to SHDSL LC.		
Refresh	Click this button to refresh the status during firmware updating.		
Export	Click this button to save the contents of <b>NE SHDSL Firmware Upgrade</b> to the local LCT PC.		
Close	Exit the NE SHDSL Firmware Upgrade Dialog.		

## **NE Boot Partition**

As the NE needs to be rebooted to execute the new image running on NC, follow the subsequent procedure to select boot partition when the NC reboots.

- Step 1 Click Configuration → NE Management → Boot Partition on Main Menu to open the NE Firmware Boot Partition Dialog as shown in Figure 13-144 .Table 13-102 depicts the related parameters.
- Step 2 Select the boot partition form 'Next Time Boot Partition' field to decide the booting image the NE will run whenever it is rebooted.

Figure 13-144 NE Firmware Boot Partition Dialog




Table 13-102 NE Firmware Boot Partition Dialog Description

Field	Description		
Current Boot Partition	This indicates the current boot partition.		
Next Time Boot Partition	Use this combo-box to select the next boot partition.		
Function Button			
OK	Commit the configuration.		
Cancel	Cancel the setting.		

## **Reset the Unit**

Select the NC/LC or Port object, use right mouse button to bring out the menu, select the 'Reset' option to launch the **Reset the Unit Dialog** as shown in Figure 13-145.

Figure 13-145 Reset the Unit Dialog



# **Appendix AAbbreviations and Acronyms**

The abbreviations and acronyms used in this document.

Table A-1 Abbreviations and Acronyms Table

Abbreviations	Full Name		
AAL	ATM Adaptation Layer		
ADSL	Asymmetric Digital Subscriber line		
AIS	Alarm Indication Signal		
ATM	Asynchronous Transfer Mode		
ATU-C	ADSL Transceiver Unit at the central office end		
ATU-R	ADSL Transceiver Unit at the remote end		
CBR	Constant Bit Rate		
CV	Coding Violation		
DSLAM	Digital Subscriber line Access Multiplexer		
ES	Error Seconds		
EOA	Ethernet over ATM		
GE	Gigabit Ethernet		
IP	Internet Protocol		
LAN	Local Area Network		
LOF	Loss of Frame		
LOS	Loss of Signal		
LPR	Loss of Power		
OAM	Operation, Administration, and Maintenance		
PADI	PPPoE active discovery initiation		
PADR	PPPoE active discovery request		
PADT	PPPoE active discovery terminate		
PCR	Peak Cell Rate		
PSD	Power Spectral Density		
PVC	Permanent Virtual Channel		
rtVBR	Real time Variable Bit Rate		
SCR	Sustainable Cell Rate		
SNR	Signal-to Noise Ratio		
SNMP	Simple Network Management Protocol		
UAS	Unavailable Seconds		
UBR	Unspecified Bit Rate		
VC	Virtual Channel		
VCI	Virtual Channel Identify		
VCL	Virtual Channel Link		
VDSL	Very high-speed Digital Subscriber line		
VLAN	Virtual Local Area Network		
VP	Virtual Path		
VPI	Virtual Path Identifier		
VTU-O	VDSL Transmission Unit at the Optical network interface		
VTU-R	VDSL Transmission Unit at the remote end		
WAN	Wide Area Network		
xDSL	ADSL/VDSL		

This page is leave in blank for note or memo use

# **Appendix BAlarm Definition**

Describe all the alarm in the AMS.

Table B-2 Alarm Definition

NE Model	Module Name	Alarm Name	<b>Default Severity</b>	Alarm Description
All	noEntity	ЕМРТҮ	No	Neither plan type nor on-line type configured
DAS4192		MISSING	Major	CPU Module is off-line
		TEMP	Major	Temperature is over the threshold
	CDYLY C. L.	VOL	Major	Voltage is below the threshold
	CPU Module	MISMATCH	Major	Planned type and online type are mismatched
		TCA_DHCP_BC	Warning	DHCP broadcast request rate threshold- crossing alert
		MISSING	Major	ADSL module is off-line
		TEMP	Major	Temperature is over the threshold
	ADSL Module	VOL	Major	Voltage is below the threshold
	ADSL Wioduic	MISMATCH	Major	Planned type and online type are mismatched
		NOT_OPERABLE	Major	ADSL line card is not operable
	D M 11	MISSING	Major	Power module is off-line
	Power Module	NOT_OPERABLE	Major	Power card is not operable
		MISSING	Major	Fan module is off-line
		FAN1_SPEED	Major	Fan1 speed is below the threshold
	Fan Module	FAN2_SPEED	Major	Fan2 speed is below the threshold
		VOL	Major	Voltage is below the threshold
		ES_NE_15_MIN	Minor	15 min near end ES is over threshold
		SES_NE_15_MIN	Minor	15 min near end SES is over threshold
		UAS_NE_15_MIN	Minor	15 min near end UAS is over threshold
		ES_FE_15_MIN	Minor	15 min far end ES is over threshold
		SES_FE_15_MIN	Minor	15 min far end SES is over threshold
	ADSL Port	UAS_FE_15_MIN	Minor	15 min far end UAS is over threshold
		ES_NE_1_DAY	Minor	1 day near end ES is over threshold
		SES_NE_1_DAY	Minor	1 day near end SES is over threshold
		UAS_NE_1_DAY	Minor	1 day near end UAS is over threshold
		ES_FE_1_DAY	Minor	1 day far end ES is over threshold
		SES_FE_1_DAY	Minor	1 day far end SES is over threshold
		UAS_FE_1_DAY	Minor	1 day far end UAS is over threshold
		LOS	Minor	Loss of signal
		LOF	Minor	Loss of frame
		LPWR	Warning	CPE loss of power
		GEN_LINE_INIT_FAIL	Minor	Generic line initialization failure
		CONFIG_ERROR	Minor	Line initialization failure - configuration error
		HIGH_BIT_RATE	Minor	Line initialization failure - high bit rate
		COMM_PROBLEM	Minor	Line initialization failure - communication problem
		NO_PEER_DETECTED	Minor	No peer detected
		TRAINING	Warning	Port is under training
		NO_CONFIG	Information	Port is not configured
		PS_L2_MANUAL	Information	ADSL2/ADSL2+ Power State transfers to L2 by manual mode

NE Model	Module Name	Alarm Name	Default Severity	Alarm Description
DAS4192		PS_L2_AUTO	Information	ADSL2/ADSL2+ Power State transfers to L2 by automatic mode
		PS_L3_CO	Information	ADSL2/ADSL2+ Power State transfers to L3 by CO side
	ADSL Port	PS_L3_CPE	Information	ADSL2/ADSL2+ Power State transfers to L3 by CPE side
		ILLEGAL_IP	Warning	Packets with illegal IP addresses have been dropped
		ILLEGAL_MAC	Warning	duplicated MAC addresses from different line ports are made out
		DISABLED	Information	The port is disabled
		MISSING	Major	GE Port is off-line
		NOT_OPERABLE	Major	GE Port is not operable
	GE Port	STP_LEARN	Information	GE port is transited to STP-learning state
		STP_BLOCK	Information	GE port is transited to STP-blocking state
		DISABLED	Information	GE port is disabled
	Alarm Relay Module	MISSING	Major	Alarm relay module is off-line
	,	MISSING	Major	Alarm relay port is off-line
	Alarm Relay Port	RELAY_ABNORMAL	Major	The alarm relay port is under abnormal status
		DISABLED	Information	The alarm repay port is disabled
		MISSING	Major	SHDSL module is off-line
		TEMP	Major	Temperature is over the threshold
	SHDSL Module	VOL MISMATCH	Major Major	Voltage is below the threshold Planned type and online type are mismatched
		NOT_OPERABLE	Major	Line card is not operable
		TCA_ES_NE_15_MIN	Minor	15-min near end ES is over the threshold
		TCA_SES_NE_15_MIN	Minor	15-min near end SES is over the threshold
		TCA_UAS_NE_15_MIN	Minor	15-min near end UAS is over the threshold
		TCA_CRC_NE_15MIN	Minor	15-min near end CRC is over the threshold
		TCA_LOSW_NE_15MIN	Minor	15-min near end LOSW is over the threshold
	SHDSL Port	TCA_SNR_NE	Minor	Near end SNR margin is over the threshold
		TCA_ATTN_NE	Minor	Near end loop attenuation is over the threshold
		OPI	Information	Operation state change indication
		LOS	Minor	Loss of signal (FOH lost bit)
		SEGA	Minor	Segment anomaly - CRC anomaly (FOH sega bit)
		LPR	Minor	Loss of power - power status (FOH ps bit)
		SEGD	Minor	Segment defect - LOSW defect (FOH segd bit)
		PBO NE	Minor	Near end enhanced power back off
		DEVFAULT_NE	Minor	Near end device fault - Diagnostic or self- test fault
		DCCONT_NE	Minor	Near end DC continuity fault - interfere with span powering
		LOSW_NE	Minor	Near end LOSW failure
		INI_CFG_NE	Minor	Near end indicates Far end not able to support requested configuration
		INI_PROTOCOL_NE	Minor	Near end indicates incompatible protocol used by Far end
		NOPEER	Minor	No peer detected
		PBO_FE	Minor	Far end enhanced power back off
		DEVFAULT_FE	Minor	Far end device fault - Diagnostic or self- test fault
		DCCONT_FE	Minor	Far end DC continuity fault - interfere with span powering

NE Model	Module Name	Alarm Name	<b>Default Severity</b>	Alarm Description
DAS4192	SHDSL Port	LOSW_FE	Minor	Far end LOSW failure
		INI_CFG_FE	Minor	Far end indicates Near end not able to support requested configuration
		INI_PROTOCOL_FE	Minor	Far end indicates incompatible protocol used by Near end
		DISABLED	Information	The port is disabled
DAS4672		MISSING	Major	CPU Module is off-line
		TEMP	Major	Temperature is over the threshold
		VOL	Major Major	Voltage is below the threshold Planned type and online type are
		MISMATCH	,	mismatched
	CPU Module	NOT_OPERABLE	Major	CPU card is not operable DHCP broadcast request rate threshold-
		TCA_DHCP_BC	Warning	crossing alert
		STANDBY	Information	Running in standby mode
		HW_VERSION	Major	Hardware version is inconsistent Standby CPU module has been changed as
		SWAP	Information	active.
		MISSING	Major	ADSL module is off-line
		TEMP VOL	Major Major	Temperature is over the threshold  Voltage is below the threshold
	ADSL Module	MISMATCH	Major	Planned type and online type are
		NOT OPERABLE	Major	mismatched Line card is not operable
		MISSING	Major	Fan module is off-line
		FAN1_SPEED	Major	Fan1 speed is below the threshold
	Fan Module	FAN2 SPEED FAN3 SPEED	Major Major	Fan2 speed is below the threshold Fan3 speed is below the threshold
		VOL	Major	Voltage is below the threshold
		ES_NE_15_MIN	Minor	15 min near end ES is over the threshold
		SES_NE_15_MIN	Minor	15 min near end SES is over the threshold
		UAS_NE_15_MIN ES_FE_15_MIN	Minor Minor	15 min near end UAS is over the threshold 15 min far end ES is over the threshold
		SES_FE_15_MIN	Minor	15 min far end SES is over the threshold
		UAS FE 15 MIN ES NE 1 DAY	Minor Minor	15 min far end UAS is over the threshold 1 day near end ES is over the threshold
		SES_NE_1_DAY	Minor	1 day near end SES is over the threshold
		UAS NE 1 DAY	Minor	1 day near end UAS is over the threshold
		ES FE 1 DAY SES FE 1 DAY	Minor Minor	1 day far end ES is over the threshold 1 day far end SES is over the threshold
		UAS FE 1 DAY	Minor	1 day far end UAS is over the threshold
	ADSL Port	LOS LOF	Minor Minor	Loss of signal Loss of frame
		LPWR	Warning	CPE Loss of power
		GEN LINE INIT FAIL	Minor	Generic line initialization failure
		CONFIG_ERROR	Minor	Line initialization failure - configuration
		HIGH_BIT_RATE	Minor	error Line initialization failure - high bit rate
		COMM PROBLEM	Minor	Line initialization failure - communication
		NO PEER DETECTED	Minor	problem No peer detected
		TRAINING	Warning	Port is under training
		NO_CONFIG	Information	Port is not configured
		PS_L2_MANUAL	Information	ADSL2/ADSL2+ Power State transfers to L2 by manual mode.
		PS_L2_AUTO	Information	ADSL2/ADSL2+ Power State transfers to L2 by automatic mode.
		PS_L3_CO	Information	ADSL2/ADSL2+ Power State transfers to L3 by CO side
	ADSL Port	PS_L3_CPE	Information	ADSL2/ADSL2+ Power State transfers to L3 by CPE side
		ILLEGAL_IP	Warning	Packets with illegal IP addresses have been dropped
		ILLEGAL_MAC	Warning	duplicated MAC addresses from different line ports are made out
		DISABLED	Information	The port is disabled
	GE Port	MISSING	Major	GE Port is off-line

NE Model	Module Name	Alarm Name	<b>Default Severity</b>	Alarm Description
DAS4672	GE Port	NOT_OPERABLE	Major	GE Port is not operable
		STP_LEARN	Information	GE port is transited to STP-learnning state
		STP_BLOCK	Information	GE port is transited to STP-blocking state
		DISABLED	Information	GE port is disabled
	Alarm Relay Module	MISSING	Major	Alarm relay module is off-line
	Alarm Relay Port	MISSING	Major	Alarm relay port is off-line
		RELAY_ABNORMAL	Major	The alarm relay port is under abnormal status
		DISABLED	Information	The port is disabled
	SHDSL Module	MISSING	Major	SHDSL module is off-line
		TEMP	Major	Temperature is over the threshold
		VOL	Major Major	Voltage is below the threshold Planned type and online type are
		MISMATCH	Major	mismatched
		NOT_OPERABLE	Major	Line card is not operable
	SHDSL Port	ES_NE_15_MIN	Minor	15-min near end ES is over the threshold
		SES_NE_15_MIN	Minor	15-min near end SES is over the threshold
		UAS NE 15 MIN	Minor	15-min near end UAS is over the threshold
		TCA CRC NE 15MIN	Minor Minor	15-min near end CRC is over the threshold 15-min near end LOSW is over the
		TCA_LOSW_NE_15MIN	Willion	threshold
		TCA_SNR_NE	Minor	Near end SNR margin is over the threshold
		TCA_ATTN_NE	Minor	Near end loop attenuation is over the threshold
		OPI	Minor	Operation state change indication
		LOS	Minor	Loss of signal (FOH lost bit)
		SEGA	Minor	Segment anomaly - CRC anomaly (FOH sega bit)
		LPR	Minor	Loss of power - power status (FOH ps bit)
		SEGD	Minor	Segment defect - LOSW defect (FOH segd bit)
		PBO NE	Minor	Near end enhanced power back off
		DEVFAULT_NE	Minor	Near end device fault - Diagnostic or self- test fault
		DCCONT_NE	Minor	Near end DC continuity fault - interfere with span powering
		LOSW_NE	Minor	Near end LOSW failure
		INI_CFG_NE	Minor	Near end indicates Far end not able to support requested configuration
		INI_PROTOCOL_NE	Minor	Near end indicates incompatible protocol used by Far end
		NOPEER	Minor	No peer detected
		PBO_FE DEVFAULT_FE	Minor Minor	Far end enhanced power back off Far end device fault - Diagnostic or self- test fault
		DCCONT_FE	Minor	Far end DC continuity fault - interfere with span powering
		LOSW_FE	Minor	Far end LOSW failure
		INI_CFG_FE	Minor	Far end indicates Near end not able to support requested configuration
		INI_PROTOCOL_FE	Minor	Far end indicates incompatible protocol used by Near end
		DISABLED	Information	The port is disabled
	Chassis	PWR1_FAIL	Warning	Power1 failed
		PWR2_FAIL	Warning	Power2 failed
		PWR1_NOT_OPERABLE	Major	Power1 is not operable
		PWR2_NOT_OPERABLE	Major	Power2 is not operable
		1 WK2_NOT_OFERABLE	1710101	1 0 W C1 2 13 HOT OPERADIC


## **Appendix CQuick Configuration Guide for LCT**

This appendix contains the following "How to" for the operator to be familiar with the DAS4-series product.

- HowTo 1. How to configure to provide a unicast/broadcast and bridged data service on the DAS4-series series IP-DSALM
- HowTo 2. How to configure to provide a multicast and bridged data service on the DAS4series series IP-DSALM
- HowTo 3. How to configure to provide a Trunk CoS Mapping on the DAS4-series series IP-DSALM
- HowTo 4. How to backup and restore the NE Configuration

# HowTo 1. How to configure to provide a unicast/broadcast and bridged data service on the DAS4-series series IP-DSALM

#### **Environment**



#### Set Up via AMS LCT

Step | Procedure and example of parameter value (Procedure with blue background, Example with yellow background)

#### AStatepa ADSL line profile to system..

Follow the procedures in Section "Configuring the xDSL Profile" to set the profiles by filling the indicated dialogs as follows

Line Profile (Please refer the corresponding OID definition in Table C-103)

- 2. Figure 5-4 Add ADSL Line Profile– Transmission Rate Dialog
- 3. Figure 5-5 Add ADSL Line Profile– SNR Margin Dialog
- 4. Figure 5-6 Add ADSL Line Profile– PSD Dialog
- 5. Figure 5-7 Add ADSL Line Profile– Power Management Dialog
- 6. Figure 5-8 Add ADSL Line Profile– INP Dialog

PM Threshold Profile (optional) (Please refer the corresponding OID definition in Table C-104)

2. Figure 5-10 Add ADSL PM Threshold Profile Dialog

Traffic Policing Profile (Please refer the corresponding OID definition in Table C-105)


1. Figure 5-12 Add Traffic Policing Profile Dialog

#### **Example:**


Please see the example setting as follows.


#### **Line Profile**

1. Figure 5-4 Add ADSL Line Profile—Transmission Rate Dialog





2. Figure 5-5 Add ADSL Line Profile – SNR Margin Dialog








AMS LCT Software Operation Guide
















AMS LCT Software Operation Guide




AMS LCT Software Operation Guide


## HowTo 2. How to configure to provide a multicast and bridged data service on the DAS4-series series IP-DSALM


#### **Environment**



### Set Up via AMS LCT








Step 5	Enable IGMP snoopy function on IP-DSLAM.									
1	Follow the procedures in Section "IGMP snooping/IGMP proxy Configuration" to fill the									
	following dialogs (Please refer the corresponding OID definition in Table C-112)									
	1. Figure 7-18 IGMP Snooping / IGMP Proxy Setting Dialog									
	Example:									
	Please see the example setting as follows.									
	1. Figure 7-18 IGMP Snooping / IGMP Proxy Setting Dialog [10.12.3.124] IGMP Snopping / IGMP Proxy Setting									
	IGMP Snooping / IGMP Proxy Setting									
	C Disable IGMP snooping and IGMP proxy									
	© Enable IGMP Snooping									
	IGMP Snooping MAC Aging									
	Aging Time 300 seconds									
	© Enable IGMP Proxy									
	IGMP Proxy Settings									
	Robustness (Query Retry) 5  Query Response Interval 10 seconds									
	Immediate Leave									
	<u>Q</u> K <u>C</u> ancel									
	[10.12.3.124] IGMP Snopping / IGMP Proxy Setting									
	IGMP Snooping / IGMP Proxy Setting									
	C Disable IGMP snooping and IGMP proxy									
	G Forth 1940 Consider									
	© Enable IGMP Snooping									
	IGMP Snooping MAC Aging									
	Aging Time 300 seconds									
	© Enable IGMP Proxy									
	IGMP Proxy Settings									
	Robustness (Query Retry) 5									
	Query Response Interval 30 seconds									
	Immediate Leave   ✓									
	OK Cancel									
	<u> </u>									


HowTo 3. How to configure to provide a Trunk CoS Mapping on the DAS4-series

### series IP-DSALM

Set Up via AMS LCT



# HowTo 4. How to backup and restore the NE Configuration Backup and Restore the NE Configuration via AMS LCT





It is noted that the NE configuration is saved in "default.cfg" on the NE. The LCT allows to backup the "default.cfg" and save it with a different filename on the local host. In the mean time, the LCT also allows to restore the "default.cfg" with a NE configuration different filename on the local host.

#### Set Up via CLI

NE provides NC/ADSL LC backup and restore related CLI commands to backup or restore the NE configuration via FTP. The backup procedures are as following:

**Step 1** Open the DOS prompt window (or environment) on personal computer (PC).

**Step 2** Go to the directory where the backup file is saved, and then login the

DAS4-Series by FTP

**Step 3** Get the configuration file from NE to the target partition via FTP by following

commands:

ftp> cd cfg:

ftp> get default.cfg

or

ftp> put default.cfg



It is noted that login device via FTP must be used the read-write authorization. The default username/password is **admin/admin**.



It is noted that the NE configuration is saved in "default.cfg" on the NE. The operator can backup the "default.cfg" and save it with a different filename on the local host. However, the operator has to restore (by the ftp "put" command) the NE configuration with filename of "default.cfg".

The following example shows how to backup the configurations from NE21

```
1.
2.D:\>ftp 10.12.3.160
3.Connected to 10.12.3.160.
4.220-----
5.220-
            Welcome to the IP-DSLAM FTP Server
6.220-
7.220- CAUTION: It's your responsibility to use the FTP service correctly -
         , please put the right files into the right file system. -
10.User (10.12.3.160:(none)): admin
11.331 Password required
12.Password:
13.230 User logged in
14.ftp> cd cfg:
15.250 Changed directory to "cfg:/"
16.ftp> get default.cfg D:\DSLAM-TPE-4.txt
17.200 Port set okay
18.150 Opening BINARY mode data connection
19.226 Transfer complete
20.ftp: 152231 bytes received in 0.45Seconds 335.31Kbytes/sec.
21.ftp> bye
22.221 Bye...see you later
23.
24.D:\>
```

The following example shows how to restore the configurations to NE.

```
25.
26. \text{D:} \textbf{\ftp 10.12.3.160}
27.Connected to 10.12.3.160.
29.220-
               Welcome to the IP-DSLAM FTP Server
30.220-
31.220- CAUTION: It's your responsibility to use the FTP service correctly -
           , please put the right files into the right file system. -
34.User (10.12.3.160:(none)): admin
35.331 Password required
36.Password:
37.230 User logged in
38.ftp> cd cfg:
39.250 Changed directory to "cfg:/"
40.ftp> put DSLAM-TPE-4.cfg default.cfg
41.200 Port set okay
42.150 Opening BINARY mode data connection
43.226- CAUTION:Please wait for 120 seconds or check the Flash LED -
44.226 Transfer complete
45.ftp: 152231 bytes sent in 0.80Seconds 191.01Kbytes/sec.
46.ftp> bye
```

47.221 Bye...see you later

Table C-103 The mapping of ADSL line profile related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
Profile Name	rfc2662	1.3.6.1.2.1.10.94.1.1.14.	adslLineConfProfileName	This specifies the ADSL line profile name <b>Type:</b> Mandatory <b>Valid values:</b> String of up to 32 characters ('0'~9', 'A'~Z', 'a'~'z', '_', '_', ', '@').

Upstream Min Rate	rfc2662	.1.3.6.1.2.1.10.94.1.1.14. 1.25 .1.3.6.1.2.1.10.94.1.1.14. 1.26	adslAturChanConfFastMi nTxRate (see Note ¹) or adslAturChanConfInterlea veMinTxRate (see Note ²)	Defines upstream minimum transmit rate, this parameter is available for adaptive and dynamic rate mode.  Type: Mandatory  Valid values: 64 ~ 2976 (multiple of 32 kbps)  Default value: 64 kbps (due to profile generated)
Upstream Max Rate	rfc2662	1.3.6.1.2.1.10.94.1.1.14. 1.27 1.3.6.1.2.1.10.94.1.1.14. 1.28	adslAturChanConfFastMa xTxRate (see Note 1) or adslAturChanConfInterlea veMaxTxRate (see Note 2)	Defines upstream maximum transmit rate, this parameter is available for adaptive and dynamic rate mode.  Type: Mandatory Valid values: 64 ~ 2976 (multiple of 32 kbps)  Default value: 64 kbps (due to profile generated)
Downstream Min Rate	rfc2662	.1.3.6.1.2.1.10.94.1.1.14. 1.11 .1.3.6.1.2.1.10.94.1.1.14. 1.12	adslAtucChanConfFastMi nTxRate (see Note 1) or adslAtucChanConfInterle aveMinTxRate (see Note 2)	Defines downstream minimum transmit rate, this parameter is available for adaptive and dynamic rate mode. <b>Type:</b> Mandatory <b>Valid values:</b> 64 ~ 29984 (multiple of 32 kbps) <b>Default value:</b> 64 kbps (due to profile generated)
Downstream Max Rate	rfc2662	1.3.6.1.2.1.10.94.1.1.14. 1.13 1.3.6.1.2.1.10.94.1.1.14. 1.14	adslAtucChanConfFastM axTxRate (see Note 1) or adslAtucChanConfInterle aveMaxTxRate (see Note 2)	Defines downstream maximum transmit rate, this parameter is available for adaptive and dynamic rate mode.  Type: Mandatory  Valid values: 64 ~ 29984 (multiple of 32 kbps)  Default value: 64 kbps (due to profile generated)
Upstream Min Rate	rfc2662	.1.3.6.1.2.1.10.94.1.1.14. 1.25 .1.3.6.1.2.1.10.94.1.1.14. 1.26	adslAturChanConfFastMi nTxRate (see Note 1) or adslAturChanConfInterlea veMinTxRate (see Note 2)	Defines upstream transmit rate, this parameter is available for fixed rate mode. <b>Type:</b> Mandatory <b>Valid values:</b> 64 ~ 2976 (multiple of 32 kbps) <b>Default value:</b> 64 kbps (due to profile generated)
Downstream Min Rate	rfc2662	.1.3.6.1.2.1.10.94.1.1.14. 1.11 .1.3.6.1.2.1.10.94.1.1.14. 1.12	adslAtucChanConfFastMi nTxRate (see Note 1) or adslAtucChanConfInterle aveMinTxRate (see Note 2)	Defines downstream transmit rate, this parameter is available for fixed rate mode. <b>Type:</b> Mandatory <b>Valid values:</b> 64 ~ 29984 (multiple of 32 kbps) <b>Default value:</b> 64 kbps (due to profile generated)
Upstream Downshift Time	rfc2662	.1.3.6.1.2.1.10.94.1.1.14. 1.24	adslAturConfMinDownsh iftTime	It defines the minimum time interval during which the upstream noise margin should stay below the Downshift SNR below the ATU-R triggers the SRA process to decrease the line rate.  Type: Mandatory Valid values: 0 ~ 16384 (seconds) Default value: 0 sec (due to profile generated)
Upstream Upshift Time	rfc2662	.1.3.6.1.2.1.10.94.1.1.14. 1.23	adslAturConfMinUpshift Time	It defines the minimum time interval during which the upstream noise margin should stay above the Upshift SNR before the ATU-R triggers the SRA process to increase the line rate.  Type: Mandatory Valid values: 0 ~ 16384 (seconds) Default value: 0 sec (due to profile generated)
Downstream Downshift Time	rfc2662	.1.3.6.1.2.1.10.94.1.1.14. 1.10	adslAtucConfMinDownsh iftTime	It defines the minimum time interval during which the downstream noise margin should stay below the Downshift SNR before the ATU-C triggers the SRA process to decrease the line

<sup>&</sup>lt;sup>1</sup>Note . Applicable when the channel mode is fast path.

 $<sup>^2\</sup>mbox{Note}$  . Applicable when the channel mode is interleaved path.

 $<sup>^3\</sup>mbox{Note}$  . Applicable when applying to set the upstream SNR margin.

 $<sup>^4\</sup>mbox{Note}$  . Applicable when applying to set the downstream SNR margin.

Table C-104 The mapping of PM Threshold profile related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
Name	rfc2662	.1.3.6.1.2.1.10.94.1.1.15.1.1	adslLineAlarmConfProfileName	This specifies the PM Threshold (performance alarm) profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '-', '-', ''., '@').
15-Min/CO: ES or 15-Min/RT: ES	rfc2662	.1.3.6.1.2.1.10.94.1.1.15.1.6 or .1.3.6.1.2.1.10.94.1.1.15.1.15	adslAtucThresh15MinESs or adslAturThresh15MinESs	When the keyword "near" is set, This field indicates the threshold of Errored Seconds (ES) on the CO (Central Office) side during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.  When the keyword "far" is set, This field indicates the threshold of Errored Seconds (ES) on the RT side (CPE) during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.  Type: Mandatory Valid values: 0 ~ 900 Default value: 0 (due to profile generated)
15-Min/CO: SES or 15-Min/RT: SES	rfc3440	.1.3.6.1.2.1.10.94.3.1.23.1.2 or .1.3.6.1.2.1.10.94.3.1.23.1.4	adslAtucThreshold15MinSesL or adslAturThreshold15MinSesL	When the keyword "near" is set, This field indicates the threshold of Errored Seconds (SES) on the CO (Central Office) side during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.  When the keyword "far" is set, This field indicates the threshold of Severely Errored Seconds (SES) on the RT side (CPE) during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.  Type: Mandatory Valid values: 0 ~ 900 Default value: 0 (due to profile generated)
15-Min/CO: UAS or 15-Min/RT: UAS	rfc3440	.1.3.6.1.2.1.10.94.3.1.23.1.3 or .1.3.6.1.2.1.10.94.3.1.23.1.5	adslAtucThreshold15MinUasL or adslAturThreshold15MinUasL	When the keyword "near" is set, This field indicates the threshold of Unavailable Seconds (UAS) on the CO (Central Office) side during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.  When the keyword "far" is set, This field indicates the threshold of Unavailable Seconds (UAS) on the RT side (CPE) during the last 15 minutes. When the threshold is set to 10, the NE launches a trap (alarm) if the count of specific errors exceeds 10 during the last 15 minutes.  Type: Mandatory Valid values: 0 ~ 900

Table C-105 The mapping of Traffic Policing profile related parameters and their corresponding OID

	corresponding Oib				
Parameters	MIB File	OID-number	OID-Name	Task	
Name	ASKEY-QOS- MIB	.1.3.6.1.4.1.3646.1300.2.16.3.1.1.	trafficPolicingName	This specifies the traffic policing profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', ', ', '@').	
Upstream CIR (Mbps)	ASKEY-QOS- MIB	.1.3.6.1.4.1.3646.1300.2.16.3.1.1.	trafficPolicingCIR	Defines the committed information rate of traffic policing profile.  Type: Mandatory  Valid values: 1 ~ 1000 (mbps)	
Action to Outprofile Packets	ASKEY-QOS- MIB	.1.3.6.1.4.1.3646.1300.2.16.3.1.1.	trafficPolicingAction	This identifies to which value will DSCP be replace, drop packets or do nothing when user's upstream traffic exceeds CIR.  Type: Mandatory  Valid values: no-action(0)   drop(1)   BE(2)   AF11(3)   AF12(4)   AF13(5)   AF21(6)   AF22(7)   AF23(8)   AF31(9)   AF32(10)   AF33(11)   AF41(12)   AF42(13)   AF43(14)   EF(15)	

Table C-106 The mapping of ADSL port configuration parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
Administrative State	rfc2233	.1.3.6.1.2.1.2.2.1.7	ifAdminStatus	This specifies the desired state of the interface.  Type: Mandatory Valid values: Enable   Disable
Line Profile	rfc2662	.1.3.6.1.2.1.10.94.1.1.1.1.4	adslLineConfProfile	This specifies the ADSL line profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', ', ', '@').
PM Threshold (Profile)	rfc2662	.1.3.6.1.2.1.10.94.1.1.1.5	adslLineAlarmConfProfile	This specifies the PM Threshold (performance alarm) profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', ', '\@').
Traffic Policing (Profile)	ASKEY-QOS- MIB	.1.3.6.1.4.1.3646.1300.2.16.1.1.1.	askeyQoSLineTrafficPolicing	This specifies the traffic policing profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', ', '\@').

Table C-107 The mapping of IP Traffic profile related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
Name	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.2.2.1.	ipTrafficProfileName	This specifies the IP traffic profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '.', '@').
Upstream Rate (Kbps)	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.2.2.1.	ipTrafficProfileUsRateLimit	This specifies the rate limit for the upstream IP traffic on the PVC of a specific ADSL port where the IP traffic profile is applied to.  Type: Mandatory  Valid values: nolimit   32k   64k   128k   256k   384k   512k   768k
Downstream Rate (Kbps)	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.2.2.1.	ipTrafficProfileMaxDsRate	This specifies the rate limit for the downstream IP traffic on the PVC of a specific ADSL port where the IP traffic profile is applied to.  Type: Mandatory  Valid values: 0 ~ 29984 kbps (multiple of 32 kbps)
Downstream Priority Queue	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.2.2.1.	ipTrafficProfileDsPriority	This defines the downstream priority of the PVC of a specific ADSL port where the IP traffic profile is applied to. It is noted that the lower the priority of the applied PVC, the higher the chance to get drop due to traffic congestion.  Type: Mandatory  Valid values: low(0)   medium(1)   high(2)   highest(3)
Downstream Broadcast	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.2.2.1.	ipTrafficProfileDsBcastFilte r	This specifies to drop or to forward downstream broadcast on the PVC of a specific ADSL port where the IP traffic profile is applied to.  Type: Mandatory Valid values: drop(2)   forward(3)

Table C-108  $\,$  The mapping of xDSL VC-to-VLAN Setting related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
VPI	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.1	vcVlanEntryVpi	Defines the VPI (Virtual Path Identifier) value.  Type: Mandatory Valid values: 0 ~ 255
VCI	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.2	vcVlanEntryVci	Defines the VCI (Virtual Channel Identifier) value. <b>Type:</b> Mandatory <b>Valid values:</b> 1 ~ 65535 (1 ~ 31 are reserved)
Administrative State	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.13	vcVlanEntryRowStatus	This specifies the desired state of the vc-vlan connection.  Type: Mandatory  Valid values: Enable   Disable
RFC2684 Mode	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.6	vcVlanEntryRfc2684Mode	This specifies the RFC2684 encapsulation mode for the packet on the PVC.  Type: Mandatory  Valid values: routed mode   bridged mode
IP Traffic Profile	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.8	vcVlanEntryIPTrafficProfile	Defines the created IP traffic profile name.  Type: Mandatory  Valid values: The name of "IP traffic profile"
802.1Q/1P: VLAN ID	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.3	vcVlanEntryVlanId	This specifies the VLAN-ID value of VLAN-tag to be added to the upstream traffic on the PVC.  Type: Mandatory  Default value: 1  Valid values: 1 ~ 4093
802.1Q/1P: User Priority	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.4	vcVlanEntry8021pPriority	This specifies the User Priority of VLAN-tag to be added to the upstream traffic on the PVC when it is in the RFC 2684 bridged mode.  Type: Mandatory Default value: 0 Valid values: 0 ~ 7 (low ~ high)
802.1P: User Priority	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.4	vcVlanEntry8021pPriority	This specifies the User Priority of VLAN-tag to be added to the upstream traffic on the PVC when it is in the RFC 2684 routed mode.  Type: Mandatory Default value: 0 Valid values: 0 ~ 7 (low ~ high)
Next-hop Name	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.7	vcVlanEntryRoutedModeNexthop	It specifies the Next-hop name. The NE will use ARP to get its corresponding MAC address. The NE then use this MAC address as the MAC DA of upstream Ethernet frame when the VC-VLAN connection is in the RFC 2684 routed mode.  Type: Mandatory Valid values: The name of "ISP Server"
MAC Limit: MAC Count	askeyVcVlan	.1.3.6.1.4.1.3646.1300.2.11.1.1.5	vcVlanEntryMacLimit	Defines the limit of MAC address learned on the applied PVC when it is in the RFC 2684 bridged mode.  It is noted that each xDSL line port allows maximum of 8 MAC

Table C-109 The mapping of TV Channel Profile related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
Profile ID	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.1.2.1.1	mProfileId	This specifies the multicast channel profile identifier.  Type: Mandatory Valid values:
Name	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.1.2.1.2	mProfileName	This specifies the multicast channel profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_', '.', '@').
TV Channel IP Address	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.1.2.1.3	mProfileIpAddr	This specifies class D IP address of the multicast stream. <b>Type:</b> Mandatory <b>Valid values:</b> 224.0.1.0 ~ 239.255.255.255
Priority Queue	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.1.2.1.5	mProfilePriority	Defines the downstream forwarding priority of the multicast stream.  Type: Mandatory  Valid values: low(0)  medium(1)  high(2)  highest(3)
Downstream Rate (Kbps)	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.1.2.1.4	mProfileRate	Defines the downstream transmission rate limit of multicast stream.  Type: Mandatory Valid values: 0 ~ 29984 kbps

Table C-110 The mapping of Multicast Service Profile related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
Name	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.3.2.1.1	mcastServiceProfileName	This specifies the multicast service profile name  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '-', '-', '', '@').
TV Channel	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.3.2.1.2	mcastServiceProfileBitMap	This specifies the multicast group profile name. Each service profile may book a set of 800 program at most, we use 100 octets to save what it books.  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '-', '-', '-', '-', '@').

Table C-111 The mapping of Multicast Channel Configuration related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
VPI	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.2.1.1	mConfigVpi	Defines the VPI (Virtual Path Identifier) value for multicast channel.  Type: Mandatory  Default value: 8  Valid values: 0 ~ 255
VCI	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.2.1.2	mConfigVci	Defines the VCI (Virtual Channel Identifier) value for multicast channel <b>Type:</b> Mandatory <b>Default value:</b> 35 <b>Valid values:</b> 1 ~ 65535 (1 ~ 31 are reserved)
VLAN ID	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.2.1.3	mConfigVlanId	This specifies the VLAN-ID value of VLAN-tag to be added to the upstream IGMP report packets on the PVC.  Type: Mandatory  Default value: 1  Valid values: 1 ~ 4093
Administrative State	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.2.1.6	mConfigRowStatus	This specifies the desired state of the interface.  Type: Mandatory  Valid values: Enable   Disable
Multicast Service Profile	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.2.1.5	mConfigServiceProfile	This specifies the multicast service profile.  Internally, each line may book 256 program set, we use 256 bits to save what they booked  Type: Mandatory  Valid values: String of up to 32 characters ('0'~'9', 'A'~'Z', 'a'~'z', '-', '_, ', ', ', ', ', ', ', ', ', ', ', ', ',
Channel Limit: Channel Limit	askeyMcast	.1.3.6.1.4.1.3646.1300.2.5.2.1.4	mConfigStreamNum	This specifies the allowed number of multicast streams to be forwarded via the VC-to-VLAN connection.  Type: Mandatory  Valid values: 1~5

Table C-112 The mapping of IGMP snooping/IGMP proxy Configuration related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
Disable IGMP snooping and IGMP proxy / Enable IGMP snooping / Enable IGMP proxy	askeySystemMib	.1.3.6.1.4.1.3646.1300.2.1.16.	askeySystemManagementIgm p	These three parameters correspond to the same OID "askeySystemManagementIgmp" As their names imply, the operator selects one among them.  Type: Mandatory Valid values: enableIgmpsnoop(1), enableIgmpproxy(2),disableIgmp(3)
Enable IGMP snooping: MAC Aging Time (seconds)	askeyIgmpSnoop	.1.3.6.1.4.1.3646.1300.2.3.1.3	askeyMcastAgingTime	Defines the IGMP snooping aging time which the timeout period in seconds for aging out Multicast Groups dynamically learned with IGMP Snooping. Note that aging operates on a per interface per VLAN per multicast group basis. This interval is also used to age out ports that have received IGMP Router Query PDUs on a per VLAN basis.  Type: Mandatory  Valid values: 30 ~ 3600 (sec.)  Default value: 300 (sec.)
Enable IGMP proxy: Robustness(Query Retry)	askeyIGMPprox y	.1.3.6.1.4.1.3646.1300.2.14.2	askeyIgmpProxyRobust	Defines the retry count for the NE to re-send IGMP Query message to the subscriber in the case that the subscriber does not respond.  After sending "retry count" of IGMP Query messages, if he NE does not receive any response, the NE will treat the subscriber as 'leave' and hence will stop forwarding the multicast stream to the particular link.  Type: Mandatory  Valid values: 1 ~ 5  Default value: 3 (count.)
Enable IGMP proxy: Query Response Interval	askeyIGMPprox y	.1.3.6.1.4.1.3646.1300.2.14.3	askeyIgmpProxyQueryInterva l	This specifies the period between the NE send 2 consecutive IGMP queries to the xDSL subscriber.  Type: Mandatory  Valid values: 1 ~ 30 (sec.)  Default value: 30 (sec.)
Enable IGMP proxy: Immediate Leave	askeyIGMPprox y	.1.3.6.1.4.1.3646.1300.2.14.4	askeyIgmpProxyImmediatedL eaveEnable	This specifies to enable the "immediate leave" function or not  Type: Mandatory  Valid values: Enable   Disable

Table C-113 The mapping of Trunk CoS Mapping and DSCP Re-mapping related parameters and their corresponding OID

Parameters	MIB File	OID-number	OID-Name	Task
User Priority	askeySystemMib	.1.3.6.1.4.1.3646.1300.2.1.18. 1.1.1	askeyCosQueueMapping8021 p	This indicates the 802.1p user priority as configured in the VC-to-VLAN configuration <b>Type:</b> Mandatory <b>Valid values:</b> 0~7
Queue (Traffic Class)	askeySystemMib	.1.3.6.1.4.1.3646.1300.2.1.18. 1.1.2	askeyCosQueueIndex	For a specified User Priority (802.1p) value of received Ethernet packet, this indicates the corresponding CoS queue on the uplink trunk GE port  Type: Mandatory  Valid values: 1~8
DiffServ Code Point (DSCP)	ASKEY-QOS- MIB	.1.3.6.1.4.1.3646.1300.2.16.2. 2.1.1	diffServDSCP	For a specified User Priority (802.1p) value of received subscriber's Ethernet packet, this indicates the new DSCP value on the subscriber's IP frame to be forwarded via the uplink trunk GE port.  Type: Mandatory  Valid values: be (0), afl1(1), afl2(2), afl3(3), af21(4), af22(5), af23(6), af31(7), af32(8), af33(9), af41(10), af42(11), af43(12), ef (13)
Administrative State	ASKEY-QOS- MIB	.1.3.6.1.4.1.3646.1300.2.16.2.	diffServAdminStatus	Enable or disable the DSCP Re-mapping function. <b>Type:</b> Mandatory <b>Valid values:</b> Enable(0)   Disable(2)