




DSL-504

Technical Guide and Setup Examples

HQ Technical Support Department

RFC-1577 IPoA Configuration




1. There are three IP networks.
2. The IP address are statically assigned.
3. After reboot, DSL-504 can establish the connection automatically. No dial is needed.

RFC-1577 IPoA Configuration

- Needs to use Console to configure

```
==== IPoA Client (DSL-504) ====  
  
ip device add ethernet ether //edd 192.168.0.1  
ip device add ipoa1 atm //bun 192.168.1.254  
config save  
restart  
  
ip ipatm pvc add ipoa1 atm 0/39 remoteip 192.168.1.253  
ip relay all  
ip route add def 0.0.0.0 192.168.1.253 00:00:00:00 2  
ip nat add ipoa1  
config save  
restart
```

RFC-1577 IPoA Configuration



Testing:

- **PC_A** can ping **PC_B**.