


PRODUCT SETUP


SPECIFICATIONS / FEATURES



1

Connect to power

1. Attach the power adapter to the connector labeled "POWER IN" on the PoE injector.
2. Plug power adapter into an electrical outlet.



2

Power on your PoE network device

Connect the Ethernet cable from "P+DATA OUT" of the injector to LAN port of the PoE network device.

Connect to switch/router/ computer

Connect the Ethernet cable from "DATA IN" of the injector to switch/router/ computer.

Injector

- Passive PoE injector
- Input Voltage: 48V (Max.24W)
- Output Voltage: 48V (Max.24W)
- Ethernet: 10/100/1000Mbps
- Dimension: 74 x 27.8 x 20.8 mm
- Weight: 19 grams

Power adapter

- Input Voltage: 115~230V DC
- Output Voltage: 48V
- Maximum load: 0.5A
- Dimension: 83.2 x 79.8 x 33.2 mm
- Weight: 145 grams

Temperature

- Operating: 0°C to 40°C
- Storage: -20°C to 60°C

Humidity

- Operating: 20% to 95% (Non Condensing)
- Storage: 20% to 95% (Non Condensing)

Technical Support

Australia:
Tel: 1300-766-868
24/7 Technical Support
Web: <http://www.dlink.com.au>
E-mail: support@dlink.com.au

India:
Tel: +91-832-2856000
Toll Free 1800-233-0000
Web: www.dlink.co.in
E-Mail: helpdesk@dlink.co.in

Singapore, Thailand, Indonesia, Malaysia, Philippines, Vietnam:
Singapore - www.dlink.com.sg
Thailand - www.dlink.co.th
Indonesia - www.dlink.co.id
Malaysia - www.dlink.com.my
Philippines - www.dlink.com.ph
Vietnam - www.dlink.com.vn

Korea:
Tel: +82-2-2028-1810
Monday to Friday 9:00am to 6:00pm
Web: <http://d-link.co.kr>
E-mail: g2b@d-link.co.kr

New Zealand:
Tel: 0800-900-900
24/7 Technical Support
Web: <http://www.dlink.co.nz>
E-mail: support@dlink.co.nz

South Africa and Sub Sahara Region:
Tel: +27 12 661 2025
08600 DLINK (for South Africa only)
Monday to Friday 8:30am to 9:00pm
South Africa Time
Web: <http://www.d-link.co.za>

E-mail: support@d-link.co.za

Saudi Arabia [KSA]:
Tel: +966 01 217 0008
Fax: +966 01 217 0009
Saturday to Wednesday 9.30AM to 6.30PM
Thursdays 9.30AM to 2.00 PM
E-mail: Support.sa@dlink-me.com

DLink Middle East - Dubai, U.A.E.
Plot No. S31102,
Jebel Ali Free Zone South,
P.O.Box 18224, Dubai, U.A.E.
Tel: +971-4-8809022
Fax: +971-4-8809066 / 8809069
Technical Support: +971-4-8809033
General Inquiries: info.me@dlink-me.com
Tech Support: support.me@dlink-me.com

Egypt:
1, Makram Ebeid Street -
City Lights Building
Nasr City - Cairo, Egypt
Floor 6, office C2
Tel.: +2 02 26718375 - +2 02 26717280
Technical Support: +2 02 26738470
General Inquiries: info.eg@dlink-me.com
Tech Support: support.eg@dlink-me.com

Kingdom of Saudi Arabia
Office # 84 ,
Al Khaleej Building (Mujamathu Al-Khaleej)
Opp. King Fahd Road, Olaya
Riyadh - Saudi Arabia
Tel: +966 1 217 0008
Technical Support:
+966 1 2170009 / +966 2 6522951
General Inquiries:
info.sa@dlink-me.com

Tech Support:
support.sa@dlink-me.com

Pakistan
Islamabad Office:
61-A, Jinnah Avenue, Blue Area,
Suite # 11, EBC, Saudi Pak Tower,
Islamabad - Pakistan
Tel.: +92-51-2800397, 2800398
Fax: +92-51-2800399
Karachi Office:
D-147/1, KDA Scheme # 1,
Opposite Mudassar Park, Karsaz Road,
Karachi - Pakistan
Phone: +92-21-34548158, 34326649
Fax: +92-21-4375727
Technical Support: +92-21-34548310,
34305069
General Inquiries:
info.pk@dlink-me.com
Tech Support:
support.pk@dlink-me.com

Iran
Unit 5, 5th Floor, No. 20, 17th Alley ,
Bokharest St. , Argentine Sq. ,
Tehran IRAN
Postal Code : 1513833817
Tel: +98-21-88880918,19
+98-21-88706653,54
General Inquiries:
info.ir@dlink-me.com
Tech Support:
support.ir@dlink-me.com

Morocco
M.I.T.C
Route de Nouaceur angle RS et CT 1029

Bureau N° 312 ET 337
Casablanca , Maroc
Phone : +212 663 72 73 24
Email: support.na@dlink-me.com

Lebanon RMA center
Dbayah/Lebanon
PO Box:901589
Tel: +961 4 54 49 71 Ext:14
Fax: +961 4 54 49 71 Ext:12
Email: taoun@dlink-me.com

Bahrain
Technical Support: +973 1 3332904


Kuwait:
Technical Support: + 965 22453939 /
+965 22453949

Türkiye Merkez İrtibat Ofisi
Ayazaga Maslak yolu
Erdebil Cevahir İş Merkezi No: 5/A
Ayazaga / Maslak İstanbul
Tel: +90 212 2895659
Ücretsiz Müşteri Destek Hattı:
0 800 211 00 65
Web: www.dlink.com.tr
Teknik Destek:
support.tr@dlink.com.tr

ISRAEL
מסוק סוכר
רח' התגשימים 20
קריית מטרון, פ"ת 49348
ת.ד. 7060
טלפון: 073-796-2797
info@dlink.co.il
א-מאמיל כללי
support@dlink.co.il
א-מאמיל תמיכה

УСТАНОВКА


ХАРАКТЕРИСТИКИ / ФУНКЦИИ



1

Подключение питания

1. Подключите адаптер питания к разъему "POWER IN" адаптера PoE.
2. Подключите адаптер питания к электрической розетке.



2

Включение сетевого устройства PoE

Подключите Ethernet-кабель к разъему "P+DATA OUT" адаптера и к LAN-порту сетевого устройства PoE.

Подключение к коммутатору/маршрутизатору/компьютеру

Подключите Ethernet-кабель к разъему "DATA IN" адаптера и к коммутатору/маршрутизатору/компьютеру.

Адаптер

- Пассивный адаптер PoE
- Входное напряжение: 48 В (Макс. мощность: 24 Вт)
- Выходное напряжение: 48 В (Макс. мощность: 24 Вт)
- Ethernet: 10/100/1000 Мбит/с
- Размеры: 74 x 27,8 x 20,8 мм
- Вес: 19 г

Адаптер питания

- Входное напряжение: 115–230 В постоянного тока
- Выходное напряжение: 48 В
- Максимальный ток: 0,5 А
- Размеры: 83,2 x 79,8 x 33,2 мм
- Вес: 145 г

Температура

- Рабочая: от 0°C до 40°C
- Хранения: от -20°C до 60°C

Влажность

- Рабочая: от 20% до 95% (без конденсата)
- Хранения: от 20% до 95% (без конденсата)

Техническая поддержка

Обновления программного обеспечения и документация доступны на Интернет-сайте D-Link. D-Link предоставляет бесплатную поддержку для клиентов в течение гарантийного срока. Клиенты могут обратиться в группу технической поддержки D-Link по телефону или через Интернет.

Техническая поддержка D-Link:

8-800-700-5465

Техническая поддержка через Интернет:<http://www.dlink.ru>e-mail: support@dlink.ru

Офисы

Россия

129626 г. Москва
Графский пер., 14
Тел.: +7 (495) 744-0099

Украина

04080 г. Киев, ул. Межигорская, 87-А,
офис 18
Тел.: +38 (044) 545-64-40
E-mail: kiev@dlink.ru

Беларусь

220114, г. Минск, проспект
Независимости, 169, БЦ "XXI Век"
Тел.: +375(17) 218-13-65
E-mail: minsk@dlink.ru

Казахстан

050008, г. Алматы, ул. Курмангазы, 143
(уг. Муканова)
Тел./факс: +7 727 378-55-90
E-mail: almaty@dlink.ru

Армения

0038, г. Ереван, ул. Абеяна, 6/1, 4 этаж
Тел./факс: + 374 (10) 398-667
E-mail: erevan@dlink.ru

Грузия

Тел./факс: +995 (593) 98-3210

Lietuva

09120, Vilnius, Žirmūnų 139-303

Тел./факс. +370 (5) 236-3629
E-mail: info@dlink.lt**Eesti**

Mustamäe 55-314
10621, Tallinn
Тел. +372 613 9771
e-mail: info@dlink.ee

Latvija

Mazā noietņu 45/53 (ieeja no Nāras ielas)
LV-1002, Rīga
Тел.: +371 7 618-703
Факс: +371 7 618-706
e-pasts: info@dlink.lv