
D-Link ANT24-1400 Outdoor Directional Panel Antenna

Remove one default antenna from the wireless device and start to assemble!


Wall mount




Installation Note:


Required parts for wall mounting:

- 1. ANT-1400 antenna body with 2 screw holes
- 2. M-shaped metal fixing
- 3. spring washers 8mm
- 4. bolts M8 x 12
- 5. steel tubes
- 6.8mm washer
- 7. bolt M8 x 110
- 8. nut M8 with lock washer
- 9. bolts M8 x16 with lock washer, washers and nuts
- 10. bolts M6 x10 with washers
- 11. 6mm washers
- 12. triangular stand
- 13. half-round metal stand
- 14. wall screws
- 15. plastic wall anchor



Overlook





Vertical coverage

Frequency band	2400-2500 MHz
Antenna gain	14 dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	30°
HPBW / E-plane	30°
Impedence	50 Ohms
Dimensions LxWxH	240x240x69 mm
Weight	825g without joint

Package Contents:

- ANT24-1400 Antenna
- Extension Cable (50cm)
- Mounting Kit
- Surge protector
- Water-proof tape
- Quick Installation Guide



D-Link ANT24-1400 Outdoor Directional Panel Antenna

