

Quick Installation Guide DWA-510

Wireless G Desktop Adapter

Package Contents

If any of the items are missing, please contact your reseller.



DWA-510 Wireless G Desktop Adapter



CD-ROM (Installation CD, Manual and Warranty)

Quick Installation

Remove the D-Link CD-ROM.



A. Insert D-Link CD-ROM into your computer. (OS requirement: WINDOWS 98SE/ ME/ 2000/ XP/ Vista)



B. Click "Install Driver" (Follow the instruction on the screen and for more information please click "View Manual")

