

Вопрос: как настроить ADSL маршрутизатор DSL-500/504G для подключения к ISP точка.ру?

Ответ:

- Home->QuickConfiguration

Use this page to quickly configure the system.

PVC:	0
Operation Mode:	Enabled
Connection Type:	1483 Bridged IP LLC
VPI:	0
VCI:	35
Bridge:	Enabled
IGMP:	Disabled
IP Address:	0 0 0 0
Subnet Mask:	0 0 0 0
Default Route:	Disabled
Gateway IP Address:	0 0 0 0
PPP	
Username:	GSPN
Password:	
Use DNS:	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
DNS	
Primary DNS Server:	0 0 0 0
Secondary DNS Server:	0 0 0 0

Copyright © 2002 D-Link, Inc. All rights reserved.

- Connection Type - 1483 Bridged IP LLC
- VPI - 1
- VCI - 50
- Переключатель Bridge ставим в Enable
- Default Route - в disable
- Use DNS - в disable, жмем submit
- Services->Nat->Disable, жмем submit
- Admin->Commit&Reboot->Commit
- На этом настройка закончена