



**Driver Version:** 6.10  
**Published:** 1 Nov 2012

These release notes include important information about D-Link LAN adapter driver revisions. Please follow below steps for driver upgrades:

- Please refer to [Revision History and System Requirement](#) for driver and hardware version matrix.
- If you are installing a new LAN adapter, please check the hardware version on the device label; make sure that your adapter meets the requirement of this driver version.
- Please install the drivers before inserting LAN adapter into the computer's PCI/PCIe slot.

For more information regarding our LAN adapter products, please refer to [Related Documentation](#).

You can also download the LAN adapter drivers from <http://tsd.dlink.com.tw>.

### Content:

|  |   |
|--|---|
| Revision History and System Requirement: ..... | 2 |
| New Features: .....                            | 2 |
| Problem Fixed: .....                           | 3 |
| Known Issues: .....                            | 4 |
| Related Documentation: .....                   | 4 |

## Revision History and System Requirement:

| Driver Version | Date        | Model     | Hardware Version                                     |
|----------------|-------------|-----------|--|
| V6.10          | 1 Nov 2012  | DFE-520TX | C1/D1<br>(not compatible to other hardware versions) |
| V6.00          | 16 May 2012 | DFE-520TX | C1 (not compatible to other hardware versions)       |
| V5.00          | 3 Apr 2012  | DFE-520TX | B1/A2/A1   |
| V4.00          | 21 Oct 2009 | DFE-520TX | A2/A1  |
| V3.00          | 19 Mar 2007 | DFE-520TX | A2/A1  |
| V2.00          | 01 Jan 2006 | DFE-520TX | A2/A1  |

## New Features:

| Diver Version | New Features  |
|---------------|---|
| V6.10         | <p><b>Support the following Operating Systems:</b><br/>           Windows 8 : v6.111.723.2009<br/>           Windows 7 : v6.111.723.2009<br/>           Windows Vista: v6.110.1029.2008<br/>           Windows XP/2000: 5.719.325.2009<br/>           DOS NDIS2: v3.27<br/>           Netware Server v5.x/6.x: v5.03<br/>           Netware ODI Driver for DOS: v3.70</p> <p>The drivers are only for hardware version C1 and D1.<br/>           Flow Control is not supported.</p> |
| V6.00         | <p><b>Support the following Operating Systems:</b><br/>           Windows 7 : v6.111.723.2009<br/>           Windows Vista: v6.110.1029.2008<br/>           Windows XP/2000: 5.719.325.2009<br/>           DOS NDIS2: v3.27<br/>           Netware Server v5.x/6.x: v5.03<br/>           Netware ODI Driver for DOS: v3.70</p> <p>The drivers are only for hardware version C1.<br/>           Flow Control is not supported.</p>   |
| V5.00         | <p><b>Support the following Operating Systems:</b><br/>           Windows 7 : v. 1.12.0.1<br/>           Windows Server 2008 x64: v. 1.12.0.1<br/>           Windows Vista: v. 3.69.0.454</p>   |

|       |   |
|-------|---|
|       | <p>Windows Server 2003: v. 3.69.0.454<br/>         Windows XP: v.3.69.0.454<br/>         Windows 2000: v.3.69.0.454<br/>         Windows NT/98/95/ME: v.3.49.0.434<br/>         Linux : kernel v2.6.x: v5.21<br/>         MAC 10.7.x: v1.1.2<br/>         DOS NDIS2: v4.38<br/>         Netware Server v5.0/5.1/6.0/6.5: v.6.10<br/>         Netware ODI Driver for DOS Workstations: v.4.29<br/>         Packet Driver: v.4.33</p>   |
| V4.00 | <p><b>Support the following Operating Systems:</b><br/>         Windows 7 x86/64 (WHQL passed) : v. 1.12.0.0<br/>         Windows Server 2008 x86 (WHQL passed): v. 3.66<br/>         Windows Server 2008 x64 (WHQL passed): v. 3.67</p>  |
| V3.00 | <p><b>Support the following Operating Systems:</b><br/>         Microsoft Vista x86: v. 3.66<br/>         Microsoft Vista x64: v. 3.67<br/>         Netware Server v5.0/5.1/6.0/6.5: v.6.10<br/>         Netware ODI Driver for DOS Workstations: v.4.29<br/>         Microsoft Windows 98SE / ME: v. 3.49<br/>         Microsoft Windows NT4.0: v. 3.49<br/>         Microsoft Windows NT3.51: v. 3.49<br/>         Microsoft Windows XP/2000: v. 3.66<br/>         Microsoft Windows Server 2003: v. 3.66<br/>         Microsoft Windows 95a/ OSR2: v. 3.49<br/>         Microsoft Window XP 64 Edition: v. 3.67<br/>         Linux : kernel v2.4.x: v5.08<br/>         Linux : kernel v2.6.x: v5.08<br/>         Apple Mac 10.2.x (Can not setup in MAC OS. v10.2.0): v.1.09<br/>         Ndis2 for DOS driver: v4.35<br/>         Packet Driver: v.4.33</p> |
| V2.00 | <p><b>Support the following Operating Systems:</b><br/>         Netware Server v5.0/5.1/6.0/6.5: v.6.08<br/>         Netware ODI Driver for DOS Workstations: v.4.28<br/>         Microsoft Windows 98SE / ME: v. 3.42<br/>         Microsoft Windows NT4.0: v. 3.42<br/>         Microsoft Windows NT3.51: v. 3.42<br/>         Microsoft Windows XP/2000: v. 3.42<br/>         Microsoft Windows Server 2003: v. 3.42<br/>         Microsoft Windows 95a/ OSR2: v. 3.42<br/>         Linux : kernel v2.4.x: v4.39<br/>         Linux : kernel v2.6.x: v4.30<br/>         Apple Mac 10.2.x: v.1.07<br/>         Ndis2 for DOS driver: v4.33<br/>         Packet Driver: v.4.30</p>   |

## Problem Fixed:

| Driver Version | Problems Fixed |
|----------------|----------------|
|----------------|----------------|

|       |      |
|-------|------|
| V6.10 | None |
| V6.00 | None |
| V5.00 | None |
| V4.00 | None |
| V3.00 | None |
| V2.00 | None |

\* D-Link tracking number is enclosed in ()

## Known Issues:

---

| Driver Version | Problems Fixed |
|----------------|----------------|
| V6.10          | None           |
| V6.00          | None           |
| V5.00          | None           |
| V4.00          | None           |
| V3.00          | None           |
| V2.00          | None           |

## Related Documentation:

---

- DFE-520TX Quick Installation Guide