




Quick Installation Guide Outdoor Enclosure

This document will guide you through the basic installation process for your new D-Link Outdoor Enclosure.

DCS-56

DCS-56P

DCS-56W



Quick Installation Guide

Documentation also available
on CD and via the D-Link
Website

Quick Install Guide


This installation guide provides basic instructions for installing the DCS-56 Series Outdoor Enclosure. The DCS-56 series are outdoor enclosures designed for use with D-Link's box cameras. This IP66-certified enclosure protects your camera against dust and heavy jets of water. These models include a heater and a blower for a wider range of temperature-sensitive environments. The DCS-56 series consists of the DCS-56, the DCS-56P, and the DCS-56W.

Package Contents

- Camera Enclosure
- Mount Bracket
- Wireless Antenna & holder (DCS-56W only)
- Assembly Kit (Anchors, Screws, Allen key)
- Quick Installation Guide

If any of the above items are missing, please contact your reseller.



Hardware Overview




Mount Bracket
(Connects metal housing to wall)

Physical Installation

STEP 1: Open the camera enclosure and slide the camera into the holder. Tighten the camera in the holder.





STEP 2: Adjust the holder by loosening the retaining screws and tighten the screws to lock the desired position.




STEP 3: For the DCS-56 and DCS-56P models, Connect the Ethernet cable to the LAN port of the camera.


Note: Do not use the 12 V DC to power the camera via PoE.




For the DCS-56W model, connect the wireless antenna extender to the camera.




STEP 4: Mount the mount bracket to the location where you want to set up your camera. To prevent damage to the Ethernet cable, pre-install the cable to the location.



STEP 5: Install the camera enclosure onto the mount bracket and secure the joint with the screws provided.



STEP 6: Adjust the screws accordingly below the camera enclosure to control the camera position.



This screw controls the vertical position adjustment (<math>< 180^\circ</math>).

This screw controls the level position adjustment (<math>< 360^\circ</math>).

STEP 7: To install the wireless antennas (DCS-56W only), connect the wireless antennas to the camera enclosure, then attach the antenna holders to the enclosure, and tighten them in place.

