D-Link
Building Networks for People

Wireless AC1200 Dual Band USB 3.0 Adapter with External Detachable Antenna

Беспроводной двухдиапазонный USB 3.0 адаптер AC1200 с поддержкой MU-MIMO и съемной антенной

Бездротовий дводіапазонний USB 3.0 адаптер AC1200 з підтримкою MU-MIMO і змінною антеною

MU-MIMO қолдаумен және алмалы антеннамен сымсыз екі диапазонды USB 3.0 AC1200 адаптер

DWA-185

Quick Installation Guide

Краткое руководство по установке

Короткий посібник зі встановлення

Орнату бойынша қысқаша нұсқаулық

ENGLISH

PACKAGE CONTENTS

- DWA-185 Wireless USB Adapter

If any of these items are missing from your packaging, please contact your reseller.

INSTALLATION

1. Download the required driver on the DWA-185 description page from the www.dlink.com website.

2. Insert the DWA-185 with the attached antenna into any available USB port of your powered on PC.

3. If the "Driver Software Installation" dialog box appears, press "Cancel" / "Close".

4. Open a folder with the required driver and run the "setup.exe" file to install the driver.

SETUP AND CONFIGURATION PROBLEMS

1. What should I do, if I've forgotten my wireless encryption key?
The wireless encryption key is configured at the Wireless Access Point or Router. If you are unable to obtain your encryption key, the only solution would be to reconfigure your Access Point/Router to use a new encryption key. Please contact your Wireless Access Point/Router manufacturer.

2. Why can't I get a wireless connection?
- Check that your DWA-185 is plugged in properly to the USB port or try to plug the DWA-185 into another USB port if it is available.
- The LED on the DWA-185 should be lit, otherwise there could be a physical fault on the USB port or the driver is not installed properly.
- Ensure that the wireless settings on the DWA-185 match the settings on your Access Point/Router. Please check and confirm your settings for **Wireless Network Name (SSID)**
Wireless Encryption Key
Wireless Security Method (e.g. WEP, WPA2)
to check whether a Wireless connection has been made, in the Windows System Tray (bottom right).
- Check that your Internet is working fine on existing computers.
- Ensure that you have followed and completed the software installation process, otherwise, please reinstall the software. The LED on the DWA-185 should come on after software installation.