How to setup wireless CP

Topology:

HTTP server (192.168.10.10) --------(LAN) DWC (LAN) -------8600AP------- NB

DWC LAN IP:192.168.10.1/24

Setup:

(1) First, we need to manage our AP.

(2) I change SSID name, this is just easy for tested.



(3) Go to advance > AP profile and click “APPLY” button. We need to confirm profile status is “associated”.

(4) Go to Captive Portal and add which SSIDs should be enable CP function.



(5) Add Captive Portal group and user.

(6) NB connect to “Chuck” SSID then key in 192.168.10.10. You should see CP portal.



(7) You will see HTTP server page after you login correct account and password.



END