D-Link®
Building Networks for People

PCI Express 2.5G Ethernet Network Adapter
Сетевой PCI Express адаптер с 1 портом 100/1000/2.5GBase-T
Мережевий PCI Express адаптер з 1 портом 100/1000/2.5GBase-T
100/1000/2.5GBase-T 1 портымен желілік PCI Express адаптері

DGE-562T

Quick Installation Guide
Краткое руководство по установке
Короткий посібник зі встановлення
Орнату бойынша қысқаша нұсқаулық

ENGLISH

PACKAGE CONTENTS

- DGE-562T PCI Express Network Adapter
- Low-Profile Bracket
- Quick Installation Guide
- Warranty Card

If any of these items are missing from your packaging, please contact your reseller.

INSTALLATION

1. Turn off your PC and disconnect the power cable. Open the housing of your PC to get access to the motherboard.
2. Insert the DGE-562T adapter carefully and firmly into any available PCI Express slot. Secure the adapter with a screw.
3. Attach the housing of your PC and reconnect the power cable. Power on your PC.
4. If you are using Microsoft Windows 7 or higher, the driver installation will be done automatically. If the driver is not installed automatically, download the driver on the DGE-562T description page from the www.dlink.com website. Open a folder with the driver and run the "setup.exe" file to install the driver.

SETUP AND CONFIGURATION PROBLEMS

WHAT SHOULD I DO, IF THE INSTALLED ADAPTER DOES NOT FUNCTION PROPERLY?

Check whether the adapter appears under START>CONTROL PANEL> SYSTEM>HARDWARE>DEVICE MANAGER>NETWORK ADAPTERS. If it does not appear, make sure you have inserted the PCI Express adapter correctly or try inserting the adapter into another available PCIe slot. If it appears with an error “!” or “?”, remove or uninstall the device by right clicking on the device. Restart your PC, upon restart Windows will redetect it. If the error persists, try removing the adapter and uninstalling the driver. Repeat the installation process.